



iBook G4 12" 1.33 GHz Optical Drive Replacement

Written By: Walter Galan



INTRODUCTION

Upgrade or replace the CD, DVD, combo or SuperDrive.

TOOLS:

- **Coin** (1)
- **Phillips #00 Screwdriver** (1)
- **Flathead 3/32" or 2.5 mm Screwdriver** (1)
- **Spudger** (1)
- **T8 Torx Screwdriver** (1)

PARTS:

- **iBook G4 12" CD Drive** (1)
- **12.7 mm PATA Optical Bay PATA Hard Drive Enclosure** (1)
- **iBook G4 12" 24x Combo Drive** (1)
- **iBook G4 12" 24x Combo Drive (CW-8124)** (1)
- **iBook G4 12" 4x SuperDrive** (1)

Step 1 — Battery



- Lay your iBook upside down on a flat surface.
- Use a coin to rotate the battery locking screw 90 degrees clockwise.
- Lift the battery out of the computer.

Step 2 — Keyboard




- Pull the keyboard release tabs toward you and lift up on the keyboard until it pops free.
- If the keyboard does not come free, use a small flathead screwdriver to turn the keyboard locking screw 180 degrees in either direction and try again.
- Flip the keyboard over, away from the screen, and rest it face-down on the trackpad area.

Step 3



- Remove the four silver Phillips screws that secure the RAM shield.

Step 4



- Pull the keyboard cable up from the logic board, holding the cable as close to the connector as possible.
- ➡ Make sure that you reconnect the keyboard cable before replacing the RAM shield.

Step 5 — Lower Case



- Use a spudger or small flathead screwdriver to remove the three rubber feet from the lower case.

Step 6



- Remove the three newly-revealed Phillips screws.

Step 7



- Use a spudger or small flathead screwdriver to pry up the three metal rings that housed the rubber bumpers.

Step 8



- Remove the three hex screws using a T8 Torx screwdriver.

- ☒ The shorter screw is in the center of the computer.

Step 9



- Remove the two 4.5 mm Phillips screws on either sides of the battery contacts.


Step 10



i Breathe deeply. Trying times are ahead, but we promise the lower case does come off.


- Push the thin rims of the lower case surrounding the battery compartment in, bending them past the tabs, and then lift up to free that corner of the lower case.

Step 11



- There is a slot on the wall of the battery compartment that locks the lower case in place. Use a small flathead screwdriver to pry out the slot's lower rim and pull up on the lower case to free the slot from the tabs holding it.

Step 12



- Run a spudger along the seam between the lower case and upper case on the front of the computer to free the tabs locking the lower case. Pull up on the lower case and continue to use the spudger as necessary until you hear three distinct clicks.

Step 13



- Continue to run the spudger around the front right corner. There are two tabs on the port side of the computer, one near the front corner and one near the sound-out port.

Step 14



- There are three tabs over the optical drive that must be released before the lower case can come off. Slide the spudger into the lower case above the optical drive and run it toward the back of the computer until you hear three distinct clicks.


Step 15



(i) The front and sides of the lower case are now free.

- Turn the computer so that the back is facing you and pull the lower case up and toward you until the back tabs pop free.
- ▣ It may be helpful to jiggle the case up and down.

Step 16



- Remove the small greasy springs with white plastic caps from either side of the battery contacts.

Step 17




- Have patience and follow the directions, the end result is up to you. In my case it worked. But I was a Technician TRW Automotive. and worked on Air Bag modules that was returned from customer's that needed them analyzed. I just retired after 26 years.

Step 18 — Bottom Shield




- Remove the following 4 screws from the bottom shield:
 - Two 3 mm Phillips.
 - Two 7.5 mm Phillips.

Step 19





- Lift the bottom shield off.

Step 20 — DC-In Board



- Remove the two Phillips screws securing the DC-In board, removing tape as necessary.

Step 21



- Deroute the cable from around the optical drive, removing tape as necessary.
- Disconnect the DC-In cable from the logic board and angle the DC-In board out of its compartment.

Step 22 — Upper Case



- Remove the two 3 mm Phillips screws inside the left edge of the battery tray.
- Three 3 mm Phillips around the battery compartment.
- Three 4.5 mm Phillips along the optical drive bezel. (a magnetic screwdriver may help to lift these screws out)
- One 12 mm Phillips in the lower right corner.

- Four 14.5 mm Phillips.

Step 23



i We recommend placing the computer on a soft cloth from this point on to prevent damaging the logic board.

- Turn over the computer and open it.
- Use the flat side of a flathead screwdriver to remove the small magnet covering a screw near the middle of the computer.


→ The shorter screw goes in the lower left corner.

Step 24



- Remove the following 7 screws from the edges of the keyboard area.
 - Three 2 mm Phillips along the right edge.
 - One 4.5 mm Phillips underneath where the magnet was.
 - One 6 mm Phillips with a small head in the lower left corner.
- Two 6 mm Phillips with large heads, one in the upper left corner and one in the middle.


Step 25



i Before you can yank the upper case off, you must disconnect the trackpad connector, the blue and white power cable, and speaker cable as described in the next steps. Be especially careful with these cables; never pull directly on the cables, but use a spudger to pry up the connector directly.

- Carefully lift the upper case slightly and move it toward the front of the computer to reveal the trackpad connector. Use a spudger or your finger to disconnect the trackpad connector hidden beneath the white plastic tab.
- After disconnecting the track pad connector, carefully rotate the upper case away from you and rest it against the display.


Step 26



i The connectors at the ends of the following cables are attached very firmly to the sockets on the logic board. Pulling directly on the cable will either separate the cable from its connector or the socket from the logic board.

- Use the sharp end of a spudger to disconnect the speaker cable connector.

Step 27




- Using the sharp end of a spudger, disconnect the connector for the blue and white power cables. Again, be careful to pry up only on the connector.

! It is very easy to break the connector from the board, so be careful.

i The key is to apply force in two directions, down to keep the surface board connections intact, up to release the connector.

- The upper case is now free and can be removed from the computer.

Step 28 — Top Shield



- Remove the fifteen 3 mm Phillips screws securing the top shield to the computer.
- Remove the following 16 screws:
 - Thirteen 3 mm Phillips.
 - One 3 mm Phillips. (actual screw not present in image)
 - Two 4 mm Phillips.

 Be sure to fit the screw near the left hinge through the loop in the display data cable, securing the cable to the upper case.

Step 29




- Lift the top shield up from the right side, minding the upper left corner, which may catch on the metal framework.

Step 30 — Optical Drive




- Remove the following 4 screws:
 - One 3 mm Phillips in the channel between the optical drive and fan.
 - Two 6 mm Phillips from the upper and bottom end of the drive bezel.
 - One 6 mm Phillips with a collar from bracket extending from the lower left corner of the drive.

Step 31



- Use a spudger to pry up the Reed Switch Board from the optical drive, removing tape as necessary.


Step 32



(i) This is a diagram of the ribbon clamp connector you will disconnect in the next step.

- 1) With your fingernails, grasp the locking bar on either side and pull up a small amount (about 1/16" or 2 mm).
- 2) After disengaging the locking bar, slide the cable out of the connector.

Step 33




- Release the optical drive ribbon clamp as described above. Slide the optical drive ribbon out of its connector.

Step 34




- Lift the optical drive from the metal framework.

Step 35 — Optical Drive



- Remove the two Phillips screws securing the metal bracket and cable to the back of the optical drive.

Step 36



- Use a spudger to pry the white optical drive cable connector up from the top of the optical drive, removing tape as necessary.

Step 37



- Remove the single Phillips screw securing the bezel at the front of the optical drive.

 This screw is longer than the two that secure the bracket and cable at the back of the drive.

Step 38



⚠ The bezel has several small, fragile tabs that will break easily.


- Use a spudger to carefully depress the two tabs on top of the bezel.

Step 39



- Hold the optical drive on its side and depress the remaining tab to free the bezel from the drive.

Step 40



- Turn the drive over and remove the two Phillips screws from the bracket on the side of the drive.
- ➡ These screws are only partially threaded.
- ⓘ If you have a CD or any other object jammed in your optical drive, we have an [optical drive repair guide](#).

To reassemble your device, follow these instructions in reverse order.