



# iOpener Heating

Prerequisite guide to be used by any guide requiring an iOpener. Also prerequisite to the generic iOpener guide.

Written By: Andrew Optimus Goldheart



 **TOOLS:**

- iOpener (1)

## Step 1 — iOpener Heating



- ⓘ We recommend that you clean your microwave before proceeding, as any nasty gunk on the bottom may end up stuck to the iOpener.
- Place the iOpener in the center of the microwave.

**⚠** For carousel microwaves: Make sure the plate spins freely. If your iOpener gets stuck, it may overheat and burn.

## Step 2



- Heat the iOpener for **thirty seconds**.
- Throughout the repair procedure, as the iOpener cools, reheat it in the microwave for an additional thirty seconds at a time.

**⚠** Be careful not to overheat the iOpener during the repair. Overheating may cause the iOpener to burst.

**⚠** Never touch the iOpener if it appears swollen.

**⚠** If the iOpener is still too hot in the middle to touch, continue using it while waiting for it to cool down some more before reheating. A properly heated iOpener should stay warm for up to 10 minutes.

## Step 3



- Remove the iOpener from the microwave, holding it by one of the two flat ends to avoid the hot center.

**⚠** The iOpener will be very hot, so be careful when handling it. Use an oven mitt if necessary.

To reassemble your device, follow these instructions in reverse order.