



Amazon Echo Woofer Replacement

Replace the woofer of your Amazon Echo.

Written By: Alexander Albert



INTRODUCTION

This guide will show you how to replace the woofer, the speaker in the Amazon Echo responsible for the low-frequency bass. This guide should be helpful if your Echo is lacking bass or sounds otherwise distorted.

TOOLS:

- [Heavy-Duty Spudger](#) (1)
- [T10 Torx Screwdriver](#) (1)

Step 1 — Power and Speaker Driver Board



⚠ Power off and unplug your Echo before disassembly. Failure to do so could result in injury or damage to the device.

- Peel off the rubber footing from the bottom of the Echo.

⚠ Do not pull the rubber footing too hard, as it could stretch out of shape. Use a spudger to help remove the foot if you have any trouble.

Step 2




- Remove the four 42.8 mm T10 Torx screws from the bottom of the Echo.

Step 3



- Slowly lift the plate containing the board. Be careful not to disconnect any of the wires.


Step 4



- Using tweezers, carefully disconnect the two red and black cables from their sockets on the board.


⚠️ Tugging on the wires may damage the device. Pull from the plastic connectors instead.

Step 5



- Lift the brown plastic latch on the ZIF connector securing the driver board ribbon cable.
- Pull the ribbon cable from its connector. The plate and board should now be free from the Echo.

Step 6




- Using the spudger, pull back the two plastic clips on the plate.
- Lift the board up and pull it away from the plate.

Step 7 — Tweeter Assembly



- Remove the plastic plate from the bottom of the device. Then remove the plastic shrouding.


Step 8



- Peel off the black fabric wrapped around the Echo.

 Be careful not to rip the fabric.
Use a spudger to help remove the adhesive if you have any trouble.

Step 9



- Remove the four 42.8 mm T10 Torx screws around the tweeter.
- Lift the tweeter and its attached housing from the device.

Step 10 — Woofer



- Lift the woofer out of the Echo.

To reassemble your device, follow these instructions in reverse order.