iPhone SE SIM Tray Replacement

Remove the SIM tray in an iPhone SE.

Written By: Evan Noronha

This document was generated on 2019-09-17 11:59:18 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 4

INTRODUCTION

Use this guide to remove or replace your GSM iPhone's SIM card and tray.

TOOLS:
- SIM Card Eject Tool (1)

PARTS:
- iPhone 5s/SE Nano SIM Card Tray (1)

This document was generated on 2019-09-17 11:59:18 AM (MST).

Step 1 — SIM Tray

- Insert a SIM card eject tool or a paperclip into the small hole in the SIM card tray.

- Press to eject the tray. This may require a significant amount of force.

Step 2

- Remove the SIM Card tray assembly from the iPhone.

- ⚲ When reinserting the SIM card, ensure that it is in the proper orientation relative to the tray.

This document was generated on 2019-09-17 11:59:18 AM (MST).

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-17 11:59:18 AM (MST).