EQUIPMENT TEST LIST

B.S.P.	ISS	TEST OR REQT.	EQUIPMENT AND WORK DESCRIPTION	CLASS	FREQ.	JOB NO.
167-210-301	5		105D J86446 POWER PLANT			
(Page 2)		*3.12*	*Calibrate Voltmeter Relay*	*MW*	*12M*	
		4.07	*Check Float Voltage*	*MW*	*M*	
		4.08	*Check CEMF Operation Where Used*	*MW*	*3M*	
		4.09	*Check Low-Voltage Alarm*	*MW*	*12M*	
		4.10	*-4.12 Check TD Relay Operation*	*MW*	*12M*	
			Where Used			
		4.13	*Check High-Voltage Alarm*	*MW*	*12M*	
		4.14	*Check Discharge Fuse Alarm*	*MW*	*12M*	
167-210-302	2		105E J86814 POWER PLANT			
(Page 2)		*4.03*	*Check Float Voltage Alarm*	*MW*	*12M*	
		4.04	*Check Float Voltage*	*MW*	*M*	
167-217-301	7		111A POWER PLANT (J86470)			
(Page 3)		*5.03*	*Operation of Contactor*	*MW*	*3M*	
		5.08	*Operation of Countercell Control Circuit*	*MW*	*12M*	
		5.09	*Check Rectifier Current Limiting*	*MW*	*12M*	

Printed in U.S.A.

EQUIPMENT TEST LIST

B.S.P.	ISS	TEST OR REQT.	EQUIPMENT AND WORK DESCRIPTION	CLASS	FREQ.	JOB NO.
167-215-301	7		110A AND 110B PLANTS J86572 AND J86455			
(Page 2)		4.02	*Check Condition of KS-7105 Grid Battery*	MW	6M	
		4.03	*Check Panel Voltmeter*	MW	12M	
		4.04	*Check Regulator Float Voltage Adjustment*	MW	M	
		4.05	*Check Regulator Charge Voltage Adjustment*	MW	M	
		4.06	*Check Transfer of Load*	MW	3M	
		4.07	*Check for Regulation Tube Failure*	MW	6M	
		4.08	*Check for Power Failure Operation*	MW	6M	
		4.09	*Check for Rectifier Electron Tube Failure*	MW	6M	
		4.10	*-4.12 Check Discharge Circuit Operation*	MW	3M	
		4.13	*Check Rectifier Fuse Alarm Operation*	MW	12M	
		4.14	*Check Discharge Fuse Alarm Operation*	MW	12M	
		4.15	*Check High-Low Voltage Alarm Operation*	MW	12M	
		4.16	*Check Regulation Alarm Operation*	MW	12M	
			(110A 24-Volt Plant)			
		4.17	*Check Indicating Alarm Operation*	MW	12M	
			(110A 24-Volt Plant)			
167-217-301	6		111A POWER PLANT J86470			
ADDENDUM	1					
(Page 3)						
167-276-301	1		671A POWER PLANT (J86880) OPERATING METHODS			
(Page 3)		4.03	*Output Voltage Check*	MW	6M	
		4.04	*Meter Accuracy Check*	MW	12M	
		4.05	*Load Distribution Fuse Alarm Check*	MW	6M	
		4.06	*Plant Capacitor Fuse Alarm Check*	MW	6M	
		4.07	*Converter Failure Alarm Checks*	MW	6M	
		4.08	*±48 Volt Bus Low Voltage Alarm Check*	MW	6M	

Instructions: See Section 167-001-010, Par. 3.04 and 3.05.

Printed in U.S.A.