Removing the HP Elitebook 6930p Bluetooth module

This guide will show you how to locate and remove the Bluetooth module

Written By: Richdave

This document was generated on 2019-09-19 12:16:49 PM (MST).

INTRODUCTION

This guide will show you how to locate and remove the Bluetooth module

🔧 TOOLS:

- Phillips #1 Screwdriver (1)
- Spudger (1)

This document was generated on 2019-09-19 12:16:49 PM (MST).

Step 1 — Battery Removal

- Flip laptop over and locate the battery release button

- Push release button to the left to release battery and gently pull battery from the laptop

Step 2 — Bluetooth module

- Locate the Bluetooth module cover on the bottom of the laptop

- Loosen the M2.0×5.0 **captive** screw and remove the cover by by lifting it straight up

⚠️ The Bluetooth module is connected to the laptop via a small cable with very fine wires - take care not to damage the cable when you pull the module out of the case.

- Gently lift the Bluetooth module up and over the retaining clip. A plastic spudger may be useful.

- Disconnect the connector being careful not to damage the fine wires on the cable.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-19 12:16:49 PM (MST).