

**RELAYS
SENSITIVE TYPES
WESTERN ELECTRIC 260 AND 261 TYPES
KS TYPES
WESTON MODELS 30, 534, 546, 730, AND 1091
BETHLEHEM MODEL 1026
REQUIREMENTS AND ADJUSTING PROCEDURES**

1. GENERAL

1.001 This addendum supplements Section 040-254-701, Issue 9-D.

1.002 This addendum is issued to advise that the R-2262 wrench listed in 3.001, List of Tools and Test Apparatus, and referenced in 3.02 and 3.07 is no longer a mandatory tool. The number 74 wrench can be used in its place.