



308-Type Connectors Description, Use, Installation, and Repair Procedures

1. Overview

- 1.001 This addendum supplements AT&T 201-208-111, Issue 1. Place this pink sheet ahead of Page 1 of the practice.
- 1.002 This addendum is issued to correct the comcodes for the connectors and the threaded inserts. This addendum is issued also to correct and clarify the procedures for removing, replacing, and installing terminals.

2. Changes

Issue 1 Changes

- 2.001 On Page 8, in **Table A—308-Type Connectors**, remove the 24-gauge, 300-foot Stub Cable (Item Code 308A1-100-300, Comcode 103927422) from the table.
- 2.002 On Page 8, in **Table A—308-Type Connectors**, remove the 22-gauge, 300-foot Stub Cable (Item Code 308B1-100-300, Comcode 103927406) from the table.
- 2.003 On Page 23, replace paragraph 4.08 with the following:

Using B long-nose pliers, close the tangs or barbs on the terminal or break the terminal flush with the back side of the connector panel and remove the terminal from the front side of the connector panel.
- 2.004 On Page 23, replace paragraph 4.10 with the following:

Using B long-nose pliers, close the tangs on the damaged or broken 814648622 terminal or break the terminal flush with the back side of the connector panel and remove the terminal from the front side of the connector panel. For the 846587335 terminal, straighten the legs and remove the terminal from the front side of the connector panel.

2.005 On Page 23, replace paragraph 4.14 with the following:

Using the fingers, properly orient the new terminal and insert into the same hole from which the old terminal was removed. Using an orange stick, push the terminal into the hole as far as possible.

2.006 On Page 23, replace paragraph 4.17 with the following:

Using B long-nose pliers, carefully spread the barbs or tangs of the terminal to lock the terminal in place in the connector panel.

2.007 On Page 23, replace paragraph 4.20 with the following:

Using the fingers, properly orient the new terminal and insert into the same hole from which the old terminal was removed. Using an orange stick, push the terminal into the hole as far as possible.

2.008 On Page 23, replace paragraph 4.23 with the following:

Using B long-nose pliers, carefully spread the tangs of the 814648622 terminal to lock the terminal in place in the connector panel. For the 846587335 terminal, bend the legs over the ground rod.

2.009 On Page 24, replace paragraph 4.30 with the following:

The 100-pair P and R test connector attaches to the 308-type connector by means of two thumb-screw fasteners that engage threaded inserts at the top and bottom of the test contact field (Figure 16). The threaded inserts have different comcode numbers because of their different lengths. Connectors produced after 1991 use the 842357543 for both inserts. Listed below are the comcodes for the inserts used in the connectors.

- Top Insert — 842137879 [DA (Discontinued Availability)], replaced by 842357543 in connectors produced after 1991.
- Bottom Insert — 842357543