

CENTRAL OFFICE UNATTENDED OPERATION
ALARM TRANSFER PROCEDURE

1. GENERAL

1.001 This Addendum supplements Section
201-601-903SW.

1.002 This Addendum is issued to add Form
SW-9112D, Central Office Unattended
Alarm Transfer Log, (Exhibit 5).

3. PROCEDURE

(Change the following paragraph:)

3.03 Instructions for transferring alarms
to the alarm receiving location should
be posted at the originating or alarm trans-
ferring office. These instructions should
include a method of checking that the alarms
are transferred and how often this check
should be made. Alarm transfer and restoral
times shall be entered on Form SW-9112D,
Central Office Unattended Alarm Transfer Log,
or on Form E-5457, Central Office Log.

