

DROP AND BLOCK WIRING REPAIR

1. GENERAL

1.001 This addendum is issued to supplement
Section 462-800-305, Issue 3, January,
1976.

1.002 This addendum is issued to instruct
craftpersons to use the AMP drop wire
splice for drops spliced under tension. The
instructions for use of the AMP drop wire
splice is covered in Section 2 of Section
462-800-305. Splices not under tension
should be made with a 3M UDW Connector.
Instructions in the use of this connector
are furnished with the packaged product.