

PORTABLE TELEPHONE INSTALLATION

1. GENERAL
 - 1.01 This addendum is to correct descriptive and installation information when working with portable telephones.
 - 1.02 With red pencil or ink make the changes as shown in paragraph 2 of this addendum. Under the subject figures and in the margin of subject paragraph, write "See Addendum".
 - 1.03 File this addendum directly in front of CTSP 475-400-401, Issue 2, 1971.
2. CHANGES
 - 2.01 Correct Figure 1 B (left view) by crossing out "BN" and indicating that this should be "GN" (green).
 - 2.02 Correct Figure 5 as follows:
 - a.. Line out words "Neoprene Gasket" and replace with "Outlet Plate".
 - b. Line out words "Outlet Plate" and replace with "Neoprene Jacket".
 - 2.03 Change paragraph 3.02 a., (1) to read:
 - (1) Connect station wire to terminals in accordance with the color code markings shown in Figure 1 B. Position the 404B jack so that the cord of the plug is to the bottom when inserted into the jack.