

## FORMS FOR RECORDING TRANSMISSION MEASUREMENTS

### 1. GENERAL

1.01 This appendix provides information on two forms used for recording trunk transmission measurements.

1.02 This appendix is reissued to revise ordering information.

### 2. USE OF FORMS

2.01 Form P-7175, A Record of Trunk Transmission Measurements (see Fig. 1), is used to record all manual trunk loss measurements. This form is self explanatory. Form P-7175 can be used in place of Form E-3893 covered in the main section.

2.02 Form P-7176, A Log of Trunks Beyond Turn Down Limits (see Fig. 2), is used to record all circuits that are beyond the specified turn down limits. This form is used for analysis. Each office assigns its own case numbers. Complete all columns on the form for each case number.

### 3. ORDERING GUIDE – FORMS

- Form P-7175, Log of Trunks Beyond Turn Down Limits
- Form P-7176, Record of Trunk Transmission Measurements

*Note:* See your Forms Catalog.





