

EQUIPPING CROSSARMS

WIRES POINT TRANSPOSED

NOTES CONCERNING THIS ADDENDUM

This addendum supplements Section G22.120.3 and is being issued to include certain instructions where W8 type crossarms are used and also covers relocating pole pairs to provide climbing space.

"See Addendum" should be marked in Section G22.120.3 to indicate the following:

- Paragraph 3.02(b) - Supplemented
- Paragraph 5.01 - Supplemented
- Paragraph 5.02(b) - Supplemented

3. INSTALLING POINT TRANSPOSITION BRACKETS

- 3.02(b) When a W8 type crossarm is used the bracket shall be installed with B wood bushings in two 1-1/4 in. pin holes.

5. BREAK IRONS

- 5.01 S reinforcing straps may be used to keep break irons parallel where 8 in. spacing is used.
- 5.02(b) At corners, pole pairs should be relocated when necessary to provide climbing space as specified in the section on clearances for Aerial Plant.