

WOODEN POLE BRACKETS  
TRANSPPOSITIONS

NOTES CONCERNING THIS ADDENDUM

This addendum provides information which will bring this Practice into conformity with California State legal requirements.

The following should be marked "See Addendum" and treated as indicated.

- Paragraph 1.01 - Replaced.
- Paragraph 2.02 - Notes replaced.
- Paragraph 3.01 - Notes replaced.
- Paragraph 3.02 - Notes replaced.

1. GENERAL

1.01 This section covers the method of transposing wires supported by wooden pole brackets. All R-1 transposed lines expected to have an ultimate of two pairs should be constructed on crossarms.

2. TRANSPPOSITIONS IN STRAIGHT SECTIONS OF LINE

2.02 The two notes in this paragraph are replaced with the following:

- Use a 6A-40 crossarm.
- Use pins 1 and 2 or 3 and 4.

3. TRANSPPOSITIONS AT CORNERS

3.01 The notes to the left and right of the center pole are replaced with the following:

- Use a 6A-40 crossarm.
- Use pins 1 and 2 or 3 and 4.

Page 2  
2 Pages

3.02 The note between the poles and the note at the bottom of the page are replaced with the following:

Use a 6A-40 crossarm.

Use pins 1 and 2 or 3 and 4.