

DROP AND BLOCK WIRING  
EQUIPPING AND INSTALLING  
BUILDING ATTACHMENTS

NOTES CONCERNING THIS ADDENDUM

This addendum is being issued to modify the instructions on the installation of the drop wire hook and includes information on the No. 509 Universal Insulator Support.

"See Addendum" should be marked in G32.114.2 to indicate the following:

- Paragraph 2.05 - Supplemented
- Paragraph 2.06 - Cancelled
- Paragraph 10.01 - Supplemented

2. INSTALLING DROP WIRE HOOK

2.05 Wood Siding or shingle, stucco on wood, and metallic siding on wood.

Note: For restrictions on use of drop wire hook, refer to Section of the Practices entitled "Drop & Block Wiring, Planning Building Runs."

2.06 Cancel

10. EQUIPPING AND INSTALLING UNIVERSAL INSULATOR SUPPORTS

10.01 Where M bridle rings only are required, use the No. 509 Universal Insulator Support.