

Copyright, 1959, by  
The Pac. Tel. & Tel. Co.

**BELL SYSTEM PRACTICES**  
Outside Plant Construction  
and Maintenance

**ADDENDUM G32.117.1**  
Issue D, July, 1959-L  
TPT&TCo Standard

## **DROP AND BLOCK WIRING**

### **STRAND ATTACHMENTS**

#### **GENERAL**

This addendum adds instructions for running multiple drop wire from a span clamp to the pole. It is being reissued to conform with the revised main section.

Paragraph 3.01 - Replaced

Paragraph 3.02(a) - Supplemented

Write "See Addendum" at appropriate paragraphs of the main section.

#### **3. RUNNING DROP WIRE FROM D SPAN CLAMP TO POLE**

3.01 Place not more than two (2) **drop wires** between the D Span Clamp and the pole or guard arm attachment. Place not more than one (1) **multiple drop wire** between the span clamp and the pole or guard arm attachments.

3.02 (a) See Section Drop and Block Wiring, Pole-to-Building and Pole-to-Pole Runs for location of drive hooks.

**ADDENDUM**  
**G32.117.1**

Page 1  
1 Page

**DROP AND BLOCK WIRING**  
**STRAND ATTACHMENTS**