

## DROP AND BLOCK WIRING

### DROP WIRE RUNS ON BUILDINGS

#### NOTES CONCERNING THIS ADDENDUM

This addendum supplements Section G32.150.1. It is being issued to replace the information on the selection of attaching devices with a reference to the section which covers this subject.

"See Addendum" should be written at the following paragraphs which should be treated as indicated.

Supplemented: 5.01

Cancelled: 3.04, 3.05

#### 3. INTERMEDIATE ATTACHMENTS ON BUILDINGS

3.04 and 3.05 Cancelled. Refer to the section on attaching Devices for Walls in Medium and Light Loading Areas.

#### 5. CHANGING DIRECTION OF RUN

5.01 Change direction of run from horizontal to vertical as illustrated. However, on the walls of frame buildings or the commonly encountered stucco on wire, turns for one or two drops may be made with one insulated screw eye or bridle ring provided the attachment is made in the studding

Note: Drop Wire Hook may be used for making turn for not more than 2 C or NP drop wires or 3 B Block Wires.