

Prepared by
The Pacific Telephone and Telegraph Company
Southern California Area

BELL SYSTEM PRACTICES
Outside Plant Construction
and Maintenance

ADDENDUM G53.610.1
Issue A, December, 1949-S
T. P. T. & T. Co.

CABLE SPLICING - BLOCK
PREPARATION AND ARRANGEMENT

NOTES CONCERNING THIS ADDENDUM

This Addendum supplements Section G53.610.1 with information regarding arrangement of supports at a completed splice.

The cross-reference "See Addendum" should be marked in Section G53.610.1 at Paragraph 3.01 which is replaced.

3. ARRANGEMENT AT COMPLETED SPLICE

3.01 After the splice is completed place a cable clamp at the center of the lead sleeve. The first clamp on either side of the splice should be located approximately 17 inches from the center of the sleeve. On brick walls the clamp should be so placed that the anchor will be as near as possible to the center of the brick with a minimum clearance of one inch between the anchor and the edge of the brick.