

Prepared by  
The Pacific Telephone and Telegraph Company  
Southern California Area

BELL SYSTEM PRACTICES  
Outside Plant Construction  
and Maintenance

ADDENDUM G53.660.1  
Issue A, December, 1949-S  
T. P. T. & T. Co.

CABLE SPLICING - HOUSE  
PREPARATION AND ARRANGEMENT

NOTES CONCERNING THIS ADDENDUM

This Addendum supplements Section G53.660.1 with information regarding arrangement of supports at a completed splice.

The cross-reference "See Addendum" should be marked in Section G53.660.1 at Paragraph 3.01 which is replaced.

3. ARRANGEMENT OF COMPLETED SPLICE

3.01 After the splice is completed place a cable clamp at the center of the lead sleeve or taped splice. The first clamp on either side of the splice should be located approximately 17 inches from the center of the splice.