

TERMINALS

INSTALLATION OF OUTSIDE DISTRIBUTING

TERMINALS ON POLES

NOTES CONCERNING THIS ADDENDUM

This addendum supplements Section G61.102 and has been reissued to furnish instructions for placing terminals under cable crossarms.

The cross-reference, "See Addendum," should be marked after Paragraph 2.10 of Section G61.102.

2. LOCATING TERMINAL

2.11 Refer to Section G10.301-S in California or Section G10.301 in Nevada for climbing space and clearance requirements.

2.12 On jointly used poles, where a guard arm is placed over the cable or the cable is supported on a cable crossarm, locate the terminal on the side of the pole under the guard arm or cable crossarm.

NOTE: Where the messenger is supported on a cable crossarm and is located 6 ft. or more from supply conductors or if the pole is non-jointly used, locate the terminal on the side of the pole as specified in Paragraph 2.01 of Section G61.102.

2.13 Place "F" and No. 14 terminals so that the top mounting screw will be 24 inches below the bottom of the cable crossarm. An eight-foot stub on the "F" and No. 14 terminals is generally of satisfactory length.

2.14 Place "C" terminals so that the top mounting screw of the terminal is 30 inches below the bottom of the cable crossarm. An 8- $\frac{1}{2}$  foot stub on a "C" terminal will be of satisfactory length.