



1991-1996 Toyota Camry Front Shock Assembly Replacement

A video tutorial that will show you how to change the front shock strut assembly on your 1991-1996 Toyota Camry.

Written By: eCuration



This document was generated on 2019-10-01 01:01:03 AM (MST).

INTRODUCTION

If you are experiencing a bumpy ride, knocking sound, and or uneven tire wear then it may be time to replace your strut assemblies on your Toyota Camry.

Follow this video guide by YouTuber [NutzAboutbolts](#) to do the repair yourself.

TOOLS:

- Impact Wrench (1)
- 3/8" Drive Ratchet (1)
- Hydraulic Floor Jack (1)
- Jack Stand (1)
- Wheel Chocks (1)
- Socket 22 mm (1)
- 22mm Wrench (1)
- Socket 19mm (1)
- Coil Spring Compressor (1)
- 14mm socket (1)
- 12mm Socket (1)

PARTS:

- Strut and Coil Spring Assembly (1)

To reassemble your device, follow these instructions in reverse order.