



2002-2008 Dodge Ram 1500 Differential Oil Replacement

How to drain and refill a 2002-2008 Dodge Ram 1500 Chrysler LSD.

Written By: Ken



INTRODUCTION

This guide will demonstrate how to do a routine maintenance differential oil change to your 2002-2008 Dodge Ram 1500 Chrysler LSD. Due to limited resources the differential oil was not actually changed in this guide.

TOOLS:

- [Flathead Screwdriver](#) (1)
Size #2
- [vacuum oil pump](#) (1)
- [13mm Socket](#) (1)
- [Torque Wrench](#) (1)

Step 1 — Differential Oil



- Locate the twelve 10mm long 14mm hex head bolts holding on the backplate of the differential.
- Position an oil pan under the differential.
- Loosen the bottom 4 bolts first with the 14mm socket wrench. Slowly loosen the rest of the bolts in a random order until oil flows out and enters the drain pan.

(i) Due to limited resources the oil was not actually replaced in this guide.

Step 2



⚠ When tightening the bolts on the diff plate it is vital that you tighten them in a star pattern to avoid warping the plate. Do not exceed a torque of 40 ft-lbs per bolt.

- Repeat the last step in reverse to retighten the bolts on the differential cover while following the star method of tightening bolts. Use a torque wrench to ensure proper torque specifications.
- Now the differential is fully sealed and ready for new oil.

Step 3



- Locate the differential filler plug.
- Use a #2 flathead screwdriver to lift the outer lip of the plug. Pinch the outer lip of the rubber filler plug between your fingers and pull off.
- Use a vacuum pump to pump in new differential fluid until the oil level reaches the bottom of the plug hole.
- Re-insert the rubber filler plug.

(i) Due to limited resources the differential oil was not changed in this guide.

To reassemble your device, follow these instructions in reverse order.