



2008-2015 Chevrolet Cruze Sway Bar End Links Replacement

This job can be done at home. I will show you some tips and tricks to help you thru the process and also show you where things can get problematic.

Written By: OneTrick



This document was generated on 2020-01-21 02:33:56 PM (MST).

 **TOOLS:**

- Impact Wrench (1)
- Socket 18mm (1)
- 19mm Deep Socket (1)
- Mini Locking Pliers (1)
- Hydraulic Floor Jack (1)
- Jack Stand (1)
- Penetrating Lubricant (1)

 **PARTS:**

- Front Sway Bar Link Kit (1)

To reassemble your device, follow these instructions in reverse order.