



AWEI BT Earbuds & Reciever Teardown

Separate Earbud Ends & Separate Reciever For Repair on AWEI Bluetooth Earbuds

Written By: fugitiveALiEN





TOOLS:

- [Slip Joint Pliers](#) (1)
 - [Small Vise](#) (1)
-

Step 1 — Earbud Dissassembly



- Remove Earbud Cushion

Step 2 — Secure Earbud for Separation



- Secure Earbud End (eg:Vice)

Step 3 — Separate Earbud Sections



- Using Pliers Gently Twist & Pry Away Sections, Do Not Twist more than 3-4mm

Step 4 — Inspect Separated Earbud Internal Wiring



- Inspect Earbud Wiring

Step 5 — Separate Receiver Housing



- Using a small pick or pry tool, separate Receiver Housing. Each side is secured by 3 small fragile tabs. Use the space near the micro USB opening & carefully pry to separate the 3 tabs on the opposite side.

Step 6 — Inspect Receiver Internal Wiring



- Carefully Separate the PCB to inspect the headphone's left & right earbud wiring. Cleaned up any broken connections by de-soldering, re-tinning wires & re-soldering to the PCB. Each side is labeled L + L - and R + R - the colored wire is positive and the bare wire is negative.
- Assemble Unit in reverse order.