



Amazon Fire Phone Micro-USB Port Replacement

This guide will show you how to replace the Micro-USB Port.

Written By: Kent Kawahara



INTRODUCTION

Note that before removing the Micro-USB port you will need to remove the battery.

TOOLS:

- [Metal Spudger \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [Suction Handle \(1\)](#)
- [T3 Torx Screwdriver \(1\)](#)
- [Anti-Static Project Tray \(1\)](#)
- [iFixit Opening Picks set of 6 \(1\)](#)

Step 1 — Battery



(i) If the display is damaged use clear packing tape to contain any glass shards.

(i) Make sure the entire surface of the display is covered with tape.

! Wear safety glasses to protect your eyes.

Step 2



- Power off your phone.
- Remove the SIM card from the left side of the phone by pressing the small hole and allowing it to eject using the 0.8 screwdriver head.
- Remove the two 4mm screws on the bottom of the phone using the Torx T3 screwdriver.

Step 3




- Press the small suction cup just above the home button.
- While lifting up on the suction cup insert an opening pick into the crevice between the screen and back casing to pry the screen off carefully.

⚠ Carefully separate the two halves to avoid tearing the volume rocker ribbon cable.


- Using the opening tool, disconnect the volume rocker ribbon cable from the base of the phone freeing the two halves of the phone.

Step 4




- Using the J000 screwdriver head, remove the three 3mm screws holding the bracket in place.
- Remove the silver bracket that was held into place by the three screws just removed.

Step 5




- Disconnect the battery connection cable by using the plastic opening tool and applying light pressure upwards on the cable.

Step 6 — Micro-USB Port




- Unscrew the 1mm screw on the top left side of the phone
- Maneuver the bracket off slowly

Step 7




- Disconnect the 9 cables along the top and right side of motherboard using the plastic opening tool

Step 8




- Unscrew the 3mm screw located on the top left side of the phone with a flat head

Step 9




- Unscrew the four 2mm screws along the right side of the motherboard with a philips head

Step 10



- Carefully lift up the motherboard and using the spudger pry camera from the camera holder

Step 11



- Lift off bottom plastic piece with flat antenna cables

To reassemble your device, follow these instructions in reverse order.