



# BLU Advance 4.0 Screen Replacement

Written By: Jon Sclar



 **TOOLS:**

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)

## Step 1 — Removing the back cover



- With the back camera on the top side and facing you, find a notch on the bottom right side of the phone.
- Unclip the cover by raising it up from the notch and sliding a flat rigid tool along the edge.

## Step 2 — Revealing the motherboard



- Remove the battery.
- Remove 3 screws from each side with a Phillips 00 screwdriver.
- Unclip the screen by sliding a flat rigid tool between the black and the blue side-band.
- Pop off the blue side-band to be exposed to the motherboard.

## Step 3 — Separating motherboard from screen



- Remove 2 black plastic buttons from each side, exposing metallic padding.
- Gently pry the metallic padding off the motherboard with a flat rigid tool.
- Carefully separate the clip-on tabs while lifting the motherboard away from the screen.

 Forcefully separating the motherboard from the screen can further damage your device.

To reassemble your device, follow these instructions in reverse order.