



Chevy Malibu Factory BackUp Cam Camera Replacement

This guide will assist in the replacement of a factory installed backup camera.

Written By: LaTonya



INTRODUCTION

In this guide I am going to show you how to replace a factory installed backup camera in a 2013 Chevy Malibu. This guide is different than most because this camera is already installed, the cables are all routed already and that makes the guide that much simpler. Remember to work safely when dealing with any exposing wires, work with the car off (keys out of ignition). Since no technology is break proof, even factory installed technology can have problems so here is how to replace a factory installed backup camera.

TOOLS:

- [Wire stripper/crimping tool](#) (1)
- [Electrical Tape in 6 Assorted Colors](#) (1)

Step 1 — Camera



- Mount the new camera in the space provided.
- The camera routes through the bumper of the car and not the license plate.

Step 2



- Run the new wires through the holes provided, and cover with electrical tape.
- The new cords will simply connect where the faulty wires were removed.

Step 3



- Coordinate the colored wires to keep the repair simple. Match the new wires to the existing wires through the splitter. Use a wire splitter to expose the wire.
- Then simply connect the wires to the wires for reverse light.

Step 4



- The green wire is the camera connection or positive wire and the black is the ground.

ⓘ This line should already be connected correctly because you should have only switched wires that connected to the camera.

Step 5



- Make sure that the reverse light is working properly when the car is in reverse.

Step 6



- Make sure the display is clear and working properly.

To reassemble your device, follow these instructions in reverse order.