



Fast Fix Retention Pin Replacement

2016 Tacoma and I have a Tonneau Trifold Bed cover retention pin.

Written By: Christopher King



INTRODUCTION

This guide will show the user how to replace the retention pin on a 2016 Toyota Tacoma for a Tonneau Trifold Bed cover.

TOOLS:

- 6mm Allen Wrench (1)

Step 1 — Retention Pin



- Use the Allen wrench and apply constant pressure counterclockwise to loosen the pins
- The pins are tight and may require some force.

Step 2



- Repeat step one until both pins have been loosened. The pin should be loose enough to remove by hand.

Step 3



- Once loosened, grab both pins and pull them out.
- Line up the holes on the replacement part, then insert the pins.

Step 4



- Hand tighten the bolts.

Step 5



- Tighten down one side then proceed to the next step.

 Do not over tighten because you can strip the screw.

Step 6



- Tighten down the final side.

 Do not over tighten because you can break the allan wrench and strip the screw.

To reassemble your device, follow these instructions in order.