




# HP Pavilion x360 m3-u103dx Charge port Replacement

This guided tutorial will cover how to remove the charge port for replacement.

Written By: Teresita Aragon



 **TOOLS:**

- [Phillips #00 Screwdriver](#) (1)
- [Metal Spudger](#) (1)

## Step 1 — Battery



- Power off device.
- Flip the laptop over.

**⚠** Working on your device while its powered on may cause damage to your device.

## Step 2



- Remove rubber foot closest to computer hinge with a Metal Spudger.

## Step 3



- Remove all screws from base using a Phillips head 00 screwdriver.
  - 5 Phillip 2.4 x 5.7 mm screws.
  - 5 Phillips 2.8 x 5.0 mm screws.

## Step 4



- Open computer and pry open keyboard panel using the Metal Spudger. Apply little pressure then increase until keyboard pops away from motherboard.

 Be careful not to pull or disconnect ribbon cables first.

## Step 5




- Gently lift the keyboard on the mouse pad side, but do not remove.  
⚠ The keyboard is still connected by three ribbon cables.
- Remove three connected ribbon wires connecting keyboard to frame by gently disconnecting them from the motherboard.

## Step 6




- Use a Phillips #00 screwdriver to remove six screws around the battery.
  - 6 Phillips 2.0 x 4.6 mm screws.

## Step 7




- Gently lift the battery up and away from the casing.
- Carefully remove the battery from its connecting port.

## Step 8 — Charge port




- Pull the charge port connector out gently with the tweezers.

## Step 9




- The charge port connector will be released from the motherboard.

## Step 10



- The charge port is now ready to be replaced with a new piece.

## Step 11



- Once you have replaced the new charge port, insert into the motherboard

To reassemble your device, follow these instructions in reverse order.