



How to Lenovo Tab 2 A7-10 Error: PMT changed for this ROM it must be downloaded - solution

How to Lenovo Tab 2 A7-10 Error: PMT changed for this ROM it must be downloaded solution

Written By: ZFix



Name	Begin Address	End Address	Region	Location
PRELOADER	0x00000000	0x00000000	EMMC_BOOT_1	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\preloader_adam1.bin
MBR	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\MBR
EBR1	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\EBR1
UBOOT	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\Uboot
BOOTBAG	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\boot.bag
RECOVERY	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\recovery.img
SEC_ROM	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\secno.img
LOGO	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\logo.bin
TEE1	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\tee1.img
TEE2	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\tee2.img
ANDROID	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\android.img
CACHE	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\cache.img
USERDATA	0x00000000	0x00000000	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\userdata.img

PMT changed for the ROM

INTRODUCTION

MediaTek MT6572 MT6577 MT6582 MT6589 MT6735M

Sometimes when you try flashing stock firmware via SP Flash Tool you get the error. How to fix it.

Error solved

Fixing PMT Changed for the rom

- In SP Flash Tool interface, click Format tab
- Select Format whole flash except Bootloader click Start and reconnect the device.
- When the format procedure finished, go back to to Download tab
- Load scatter file of the firmware you wish to flash click Download and reconnect the device.

[video: <https://www.youtube.com/watch?v=RMOu80AXjvU>]

To reassemble your device, follow these instructions in reverse order.