



How to SAMSUNG S7 CLONE G930F

guide to flash & restore chinese firmware on chinese S7 using MTK Flashing software

Written By: EL MEHDI

INTRODUCTION

To Flash the S7 CLONE (G930F / G9300) that has a MTK CPU (MT6572) you'll need :

- MEDIATEK DRIVERS INSTALLED
- SP FLASH TOOL
- MICRO USB CABLE
- MT6572 -- S7 CLONE ROM (uploading it ...)

Follow the tutorial ...

PS : YOU DON'T NEED TO FLASH THE PRELOADER IF THE PHONE BOOTS AND FREEZES !
ONLY FLASH IT IF THE PHONE IS BRICKED OR DEAD!

following this guide will help you unbrick & revive your MEDIATEK phone, just look for the right ROM & follow the steps above!

TOOLS:

- [SP FLASHTOOL](#) (1)
- [MT6572 ROM](#) (1)
- [MEDIATEK DRIVERS](#) (1)

Step 1 — SAMSUNG S7 COPY



- S7 CLONE FLASHING PROCESS

To reassemble your device, follow these instructions in reverse order.