



How to remove swept screw with dremel mototool

I'm going to make a slot to put a flat screwdriver and take it out naturally. I used the dremel mototool and the engrave tips: 0.8 mm (108), 1.9 mm (110).

Written By: @HectorNavarroMX



INTRODUCTION

You must consider that you are going to splash metal remains, you must cover the motherboard.

TOOLS:

- [Rotary Tool \(1\)](#)

You should be carefully with this. You can damage moterboard.