



Huawei P9 Earphone Jack Replacement

This video will show you how to repair the broken Huawei P9 ear phone jack and way to replace a new one.

Written By: Witrigs

A close-up photograph of the internal components of a Huawei P9 smartphone. The yellow battery is visible at the top, with a 'Li-ion 00' label and a diagram of a battery connection. Below the battery, the motherboard and various electronic components are visible. A silver circular component, likely a microphone or earpiece, is prominent in the center. The text 'Huawei P9 Headphone Jack' is overlaid in a large, bold, black font across the middle of the image.

Huawei P9 Headphone Jack

INTRODUCTION

For the official iFixit repair guide, [click here](#). The guide you are viewing is retained for historical purposes only.

[video: https://www.youtube.com/watch?v=fg4S5l5_Pl4]

This video will show you how to repair the broken Huawei P9 ear phone jack and way to replace a new one.



TOOLS:

- [iSlack](#) (1)
- [Tweezers](#) (1)
- [Spudger](#) (1)
- [Phillips #000 Screwdriver](#) (1)
- [iFixit Opening Picks set of 6](#) (1)
- [P2 Pentalobe Screwdriver iPhone](#) (1)



PARTS:

- [Huawei P9 Headphone Jack](#) (1)

To reassemble your device, follow these instructions in reverse order.