




# Ivation IVWPDC20Y Flash Bulb Replacement

Ivation IVWPDC20Y Repair Flash bulb Replacement

Written By: Wendy Jones



## INTRODUCTION

Use this guide to replace the bulb on the flash if it is burnt out.

### TOOLS:

- [T6 Torx Screwdriver](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [Heavy-Duty Spudger](#) (1)
- [Soldering Iron](#) (1)

## Step 1 — Flash Bulb



- With the H2.0 bit screwdriver, remove the two screws on the yellow waterproof cover

## Step 2



- Apply a plastic opening tool to each of the corners and gently remove the casing

*(i)* The front casing is held down by adhesive and may require additional work to remove

**!** Apply just enough force to undo the inner latches to make sure not to damage the waterproof seal

## Step 3



- Remove the five silver screws from the inner casing using the PH00 screwdriver bit

## Step 4



- Remove the six screws from the edge of the clear inner casing with the PH00 screwdriver bit

**⚠** These screws are very small and easy to strip so apply consistent pressure when removing them

## Step 5



- Pry off back outer casing using the black spudger or the blue prying tools


## Step 6



- Carefully remove the screen from the silver casing using a prying tool or the black spudger


 There is adhesive in the center of the screen, be sure not to bend it when applying pressure

## Step 7




- Gently push out the pins holding the orange tape down using the pointy end of the spudger
- *i* Screen and orange tape should slip out as a whole

## Step 8



- Remove three screws holding the silver screen casing to the motherboard using the PH00 bit screwdriver

## Step 9



- Remove three screws holding the motherboard into the casing using the PH00 bit screwdriver bit


## Step 10



- Gently lift the corner of the motherboard out

*ⓘ Everything should come out as one component free of the casing*

## Step 11



- Remove the soldering on the three wires holding the flash bulb
- *i* The wires are different colors: red, white, and black

To reassemble your device, follow these instructions in reverse order.