



# Lenovo ThinkPad X1 Carbon 7th Gen Fingerprint Scanner Replacement

How to replace the fingerprint scanner in a Lenovo Thinkpad X1 Carbon 7th Gen.

Written By: Jaxon Haws



## INTRODUCTION

If your Lenovo ThinkPad X1 Carbon 7th Generation does not respond when you use the fingerprint scanner, use this repair guide to replace it.

A functional fingerprint scanner allows the user to log into their device or access private information without entering a password or pin. Though it is not required for the laptop to function, it is a feature that provides easy and smooth accessibility to the device.

Make sure to use non-metallic equipment to follow the guide.

### TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #0 Screwdriver](#) (1)

## Step 1 — Back Panel



**⚠** You MUST go to BIOS settings (F1 on startup) and disable the built-in battery. Disconnect laptop from power source to avoid electric shocks.

- Flip the laptop over on a flat surface with the back panel facing up.
- Remove five 5mm Phillips #0 screws from the edge of the back panel.
- Insert an opening tool between the back panel and edge. Maneuver the tool around the panel, disconnecting the clips holding the panel in place.


## Step 2



- Lift the back panel away from the device, exposing the internals.



- ★ When reassembling, prioritize the tabs on the side that does not have any screws. This ensures that the tabs do not break.

## Step 3 — Battery



- Remove five 5mm Phillips #0 screws from the edges of the battery.


## Step 4



- Remove the connector between the battery and the motherboard by using an opening tool to initially lift the back end of the connector up.


⚠ Avoid metal tweezers to remove the connector as metal to metal contact can damage the device.

## Step 5



- Lift the battery straight up and out of device.

## Step 6 — Fingerprint Scanner




- Peel back the black adhesive tape covering the ribbon cable connecting the trackpad and fingerprint scanner to the motherboard.

## Step 7





- Unclip the connector ribbon from the fingerprint scanner by lifting upwards on the clip with an opening tool.

## Step 8




- Remove one 3mm screw from the fingerprint scanner mounting bracket with a Phillips #0 screwdriver.
- Lift the fingerprint scanner mounting bracket upwards to remove it.

## Step 9



- Using an opening tool, lift the fingerprint scanner upwards.

## Step 10



- Carefully lift the fingerprint scanner to remove from the chassis.

To reassemble your device, follow these instructions in reverse order.