



Mac Pro First Generation PCIe Fan Removal

How to remove the front PCIe fan in a 2009-2012 Mac Pro Tower

Written By: Andrew Damiani



 **TOOLS:**

- Phillips #1 Screwdriver (1)

Step 1 — Side Panel Removal



- Begin by pulling up on the lever located at the back of the computer to remove the side panel.

Step 2 — Hard drive removal



- Gently pull outward on each of the four hard drive trays to remove them.

Step 3 — Fan Removal



- Remove the two 10mm PH #1 screws holding in the PCIe fan.

Step 4 — Fan Removal



- Gently pull the fan outward to remove.

To reassemble your device, follow these instructions in reverse order.