



MacBook Air 13" Early 2015 SSD Replacement

Replace the solid-state drive in your MacBook Air 13" Early 2015.

Written By: Sam Goldheart



INTRODUCTION

Use this guide to upgrade or replace the solid-state drive in a MacBook Air 13" Early 2015. This MacBook Air uses a [proprietary storage drive connector](#), and is therefore **not compatible** with common M.2 drives without the use of an adapter.

Before you perform this repair, if at all possible, [back up your existing SSD](#). Then, either familiarize yourself with [internet recovery](#) or [create a bootable external drive](#) so you'll be ready to install macOS onto your new drive and migrate your data to the new SSD.

Finally, we strongly recommend installing macOS 10.13 High Sierra (or a later macOS) before replacing the original SSD from your MacBook Air. Most new SSDs require updated storage drivers not found in versions of macOS prior to High Sierra.

TOOLS:

- P5 Pentalobe Screwdriver Retina MacBook Pro and Air (1)
- T5 Torx Screwdriver (1)

PARTS:

- OWC Aura Pro X2 SSD (1)

Step 1 — Lower Case



i Before proceeding, power down your MacBook. Close the display and lay it on a soft surface, top-side down.



- Use a [P5 Pentalobe](#) driver to remove ten screws securing the lower case, of the following lengths:
 - Two 9 mm screws
 - Eight 2.6 mm screws

Step 2



- Wedge your fingers between the display and the lower case and pull upward to pop the lower case off the Air.
- Remove the lower case and set it aside.


Step 3 — Battery Connector



- ⓘ To ensure that everything is de-energized and won't turn on while you're working, it is recommended that you disconnect the battery.
- Grab the clear plastic pull tab attached to the battery connector and pull it parallel to the board toward the front edge of the Air.

⚠ Do not lift upward on the connector as you disconnect it or you risk damage to the connector socket.

Step 4 — Solid-State Drive



- Remove the single 2.9 mm T5 Torx screw securing the SSD to the logic board.

Step 5



- Gently lift the end of the SSD about half an inch and pull it straight out of its socket on the logic board.

⚠ Don't lift the SSD more than half an inch—doing so may damage the SSD or its socket on the logic board.

★ When reinstalling the SSD, be sure it is properly seated before reinstalling its retaining screw.

To reassemble your device, follow these instructions in reverse order.