



MacBook Pro 15" Unibody Early 2011 Hard Drive Replacement

Hard Drive prereq.

Written By: Walter Galan



INTRODUCTION

This guide is a prereq only.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)

Step 1 — Hard Drive



- Remove two Phillips screws securing the hard drive bracket to the upper case.

i These screws are captive to the hard drive bracket.

Step 2



- Lift the retaining bracket out of the upper case.

Step 3



- Lift the hard drive by its pull tab and pull it out of the chassis, minding the cable attaching it to the computer.

Step 4



- Remove the hard drive cable by pulling its connector straight away from the hard drive.

To reassemble your device, follow these instructions in reverse order.