



Moto C Daughterboard Cover Replacement

prereq

Written By: Dominik Schnabelrauch



INTRODUCTION

Remove the daughterboard cover to take out the daughterboard.

TOOLS:

- [Spudger \(1\)](#)
- [iFixit Opening Picks set of 6 \(1\)](#)
- [T5 Torx Screwdriver \(1\)](#)

Step 1 — Back Cover



(i) Power off your phone before beginning disassembly.

- Insert a thumbnail, or spudger, into the notch on the bottom right corner to start separating the phone unit from the back cover.
- Move it to the bottom left corner and pry the phone unit out of the back cover until you can get a good grip.

Step 2



- Lift the phone out of the back cover.

Step 3 — Battery



- Use a finger or spudger to lever the battery out of its recess and remove it.

Step 4 — Daughterboard Cover



- Remove the four 3.5 mm long Torx T5 screws.

(i) Some screws might be covered with stickers.

Step 5



- Apply the edge of an opening pick to the bottom right corner under the daughterboard cover.
- Twist the opening pick to open the plastic clamps of the daughterboard cover.
- Slide the opening pick to the left and pry it upwards until you can get a good grip on the daughterboard cover.

Step 6



- Remove the daughterboard cover.

To reassemble your device, follow these instructions in reverse order.