



Moto C Plus Daughterboard Cover Replacement

Daughterboard cover prereq

Written By: Dominik Schnabelrauch



INTRODUCTION

Daughterboard cover prereq only

TOOLS:

- Spudger (1)
- Phillips #00 Screwdriver (1)
- iFixit Opening Picks set of 6 (1)

Step 1 — Back Cover



(i) Power off your phone before beginning disassembly.

- Insert a thumbnail, or spudger, into the notch on the bottom right to start separating the phone unit from the back cover.
- Move to the bottom left corner and pry the phone unit out of the back cover until you can get a good grip.

Step 2



- Lift the phone out of the back cover.

Step 3 — Battery



- Use a spudger or fingernail to lift the battery starting at the notch on the bottom left.
- Lever the battery out of its recess and remove it.

Step 4 — Daughterboard Cover



- Remove the six 3.1 mm Phillips #00 screws securing the daughterboard cover.

Step 5



- Apply a spudger to the right side of the daughterboard cover.
- Twist the spudger sideways to pry up the daughterboard cover until you get a good grip.
- Remove the daughterboard cover.

To reassemble your device, follow these instructions in reverse order.