



PowerBeats3 Wireless Headphones by Dr. Dre Battery Replacement

Battery replacement for PowerBeats3 Wireless Headphones by Dr. Dre

Written By: Faizan Naveed



 **TOOLS:**

- Heat Gun (1)
- Tweezers (1)
- Pry Bar (1)
- Soldering Iron (1)

 **PARTS:**

- Dr Dre Powerbeats 2 and 3 Replacement Batteries (1)

Step 1 — Locate Battery Side



- Battery is located in the right side headphone housing.

Step 2 — Heat Battery Housing



- Use a heat gun with temperature set to 140 F for about 2-3 minutes and heat the casing where it attaches together as seen in the picture.

Step 3 — Remove Housing



- After heating for about 2-3 minutes, separate the housing using a pry tool as seen in the pictures.

Step 4 — Remove/Replace Battery



- Use a soldering iron to desolder battery connection to remove battery and replace with new one.

To reassemble your device, follow these instructions in reverse order.