



# Samsung Galaxy S II Teardown

A main body teardown of the Samsung Galaxy S II

Written By: Devon Crump



 **TOOLS:**

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Picks set of 6](#) (1)

## Step 1 — Remove back of phone



- Find the small divot and use a plastic tool or your fingernail to remove the plastic cover off the back. This step requires no removal of screws.

## Step 2



- Remove the 11 screws from the back of the phone. This will require a Philips #00 screwdriver.

## Step 3



- Separate the screen and internals from the casing on the back by using a small plastic tool or your fingernail to get under the screen and lift it up. Once it has been unclipped, pull the 2 completely apart.

## Step 4



- The back of the screen should look like this. From here, we have access to any fixes that would need to be made for the phone.

