




# Sony Xperia Z1 Compact Headphone Jack Replacement

Replace the headphone jack on your Sony Xperia Z1 Compact.

Written By: Frani Morris



## INTRODUCTION

This guide will show you how you replace the headphone jack.

### TOOLS:

- [Suction Handle \(1\)](#)
- [Heat Gun \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [JIS #00 Screwdriver \(1\)](#)
- [Phillips #0 Screwdriver \(1\)](#)
- [Spudger \(1\)](#)

## Step 1 — Back Cover



- Heat along the edges of the back cover using a heat gun to soften the glue.

## Step 2



- Attach the small suction cup to the back cover near the bottom of the phone.
- Pull up on the suction cup and insert the plastic opening tool in between the back cover and the rest of the phone.

## Step 3




- Move the spudger around the edge of the back cover to separate it from the black adhesive.
- Separating the back cover from the rest of the phone ruins the adhesive which makes it no longer waterproof.

## Step 4 — Battery




- Carefully disconnect the battery from the logic board by using the plastic spudger as a lever.

## Step 5




- Remove the single 1 x 3.0 mm screw holding the battery in using the JIS #00 screwdriver.

## Step 6





- Pry the battery up from the ends using the plastic spudger until the battery pops out of the enclosure.

## Step 7




- Remove the battery from the device

## Step 8 — External Speaker




- Unscrew the four screws on the corners of the back frame using the JIS #00 screwdriver.

## Step 9





- Wedge the plastic opening tool under the back frame. Move the plastic opening tool around the entire frame to separate it from the adhesive.

## Step 10





- Remove the back frame.

## Step 11





- Wedge the spudger underneath the external speaker. Pull up on the external speaker using the spudger.

## Step 12




- Remove the external speaker.

## Step 13 — Motherboard




- Remove the square rubber gasket from the camera using the plastic spudger.

## Step 14



- Remove the black plastic corner still holding in the motherboard.

## Step 15



- Carefully pry up on the four sides of the motherboard using the plastic spudger til it separates from the base of the phone.



## Step 16



- Remove the motherboard from the device.


*(i)* There may be a small yellow adhesive underneath the motherboard still holding it in. Slide the tip of the spudger through it to sever it.

## Step 17 — Headphone Jack Replacement



- To remove the headphone jack, cut the sticker between the headphone jack and the midframe with sharp tweasers.

## Step 18



- Remove the headphone jack.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-17 03:47:45 PM (MST).

