



Vanagon Westfalia ATE Brake Replacement

A video tutorial on how to change the 1980-1985 Vanagon front ATE brakes.

Written By: eCuration



INTRODUCTION

This guide will show you how to remove the front calipers on a 1980- 1985 Vanagon so you can replace the pads, rotors and wheel bearings.

*Will not work for the Girling style.

It is best to tackle this job on a vehicle lift, however if you do not have access to one, a vehicle jack and jack stands will work just fine.

TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Socket 19mm](#) (1)
- [14mm Wrench](#) (1)
- [11mm Wrench](#) (1)
- [Flathead Screwdriver](#) (1)
- [Hammer](#) (1)
- [6 Inch C-Clamp](#) (1)
- [Groove Joint Pliers](#) (1)
- [Moly Grease](#) (1)

PARTS:

- [Brake Rotor Vanagon ATE 1980-1985](#) (2)
- [Break Pads Front Vanagon 1980-1985](#) (1)

Step 1 — 1980-1985 Front Brakes



● Part 1

Step 2



● Part 2

To reassemble your device, follow these instructions in reverse order.