



Wiko Fever (partial) Teardown

This is a partial guide - Please see point #5 Help is needed ;)

Written By: maxdibe

Step 1 — Remove the backlid



- The backlid is easily removed since the SD card and the two SIM cards need to be placed here.

Step 2 — Remove the white adhesive label



- It's the one covering the battery. It has written the model name, color, lot number, and IMEI numbers and barcodes.

Step 3 — Unscrew the 12+1 screws



- **Unscrew the 12 visible screws** You know, with the usual almost universal screwdriver
- **Unscrew the top right covered screw** This one is covered by a white round plastic patch (in the white version of this phone): it's probably a warranty patch. You can simply put the screwdriver on it, push a little and unscrew the underneath screw.

Step 4 — HELP HERE - remove the plastic frame



- Starting from the top you can detatch the plastic frame. I stopped when I got to the bottom part (the one with the micro-USB charging port).
- **...ANY HELP HERE?**

To reassemble your device, follow these instructions in reverse order.