




# iMac Intel 21.5" EMC 2428 GPU Assembly Replacement

Prereq only.

Written By: Andrew Bookholt




# INTRODUCTION

Prereq only.

## TOOLS:


- [T10 Torx Screwdriver \(1\)](#)
- [T8 Torx Screwdriver \(1\)](#)

## Step 1 — GPU Assembly




- Remove the strip of tape securing the GPU thermal sensor cable to the logic board.

## Step 2



- Remove the following three screws:
  - One 4.2 mm T10 Torx screw
  - Two 5 mm T8 Torx screws


## Step 3



- Grab the GPU thermal sensor cable connector and pull it straight up and out of its socket on the logic board.

**⚠** Do not pull the connector out by its cables.

## Step 4



- Lift the GPU heat sink slightly and pull the GPU board out of its socket on the logic board.

To reassemble your device, follow these instructions in reverse order.