









Feature operation


Call Forward			
Activate	Fwd		► Fwd
Deactivate	► Fwd		
Reinstate	Fwd	► Fwd	
View number	Display	► Fwd	


Call Pickup		Pickup	
Conference	Conf		► Conf



Handsfree			
Activate	 (Handsfree)	 (Goodbye)	(to end the call)
Switch to handset			
Handset to handsfree	 (Handsfree)		

Activate Headset	 (Headset)	 (Goodbye)	(to end the call)
------------------	---	---	-------------------





Hold	
Place a call on hold	 (Hold)
Return to a held call	 (Handsfree)

Ring Again	
Activate	RngAgn
When notified	 ► RngAgn
Deactivate	► RngAgn







Transfer	Trans		► Trans
----------	-------	---	---------

Adjust volume	 (Volume +) or  (Volume -)
---------------	--

Legend

Icon	Action
()	Indicates the key cap text label. For example, (Message).
	Lift the handset, press the line (DN) key or the Handset key.
	Replace the handset, or press  (Goodbye) to end the call.
	Dial a number.

Legend (continued)

Icon	Action
	Press the Services key once for Call Platform features, or press the Services key twice to access local tools menu options.
	Press the Up/Down Navigation keys
	Press the Enter key
	Press the Headset key.
	Press the Handsfree key.
	Press the Mute (on/off) key.




Services and Telephone Options menus

Services menu		
		

Note: The [Services](#) menu contains the [Telephone Options](#), [Password Admin](#), and [Virtual Office](#). Some options are not available on all IP Phone 1210 phones. Consult your system administrator.

The following are the most commonly used options:


Telephone Options menu



Volume adjustment		
Pick one of:		
Ringer		Select
Handset Listen		
Handsfree Listen		
Headset Listen		
Buzzer		

Contrast adjustment		
		Select

Language		
		Select

Note: This language setting controls the language used by features on your phone only. To set the language used elsewhere on your phone, press [Services](#) twice, select 1. Preferences, and select 2. Language.

Date/Time format		
		Select

Local DialPad Tone		
		Select

Ring type		
	Play	 Select

OnHook default path		
		 Select

Nortel IP Phone 1210



To provide feedback or report a problem in this document, go to www.nortel.com/documentfeedback.

LEGAL NOTICE

While the information in this document is believed to be accurate and reliable, except as otherwise expressly agreed to in writing NORTEL PROVIDES THIS DOCUMENT "AS IS" WITHOUT WARRANTY OR CONDITION OF ANY KIND, EITHER EXPRESS OR IMPLIED. The information and/or products described in this document are subject to change without notice.

Date: May 2009

Document Release: Standard 01.07

Document Number: NN43140-100

Copyright © 2005–2009 Nortel Networks

All Rights Reserved.

Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.

NORTEL

www.nortel.com

IP Phone 1210

For Nortel Communication Server 1000

Quick Reference Card

