Language: English

Final size: 7.5cm x 8.5cm closed, 15.0cm x 8.5cm open

Panel 2, Inside front cover

Format: 4 panel fanfold

Stock: Ink:

Fonts supplied:

Film:

Author & coordinator: Design & production:

DECT Handset 4060 information Handset on of for longer than 2 seconds For detail on the features of this handset, refer to the Nortel Networks DECT Handset 4060 User Guide. © for longer than 2 seconds Handset off Safety information Keypad lock Do not rely on a cordless handset in emergencies. Keypad unlock **#** Never use your handset in: In conversation Muting · the vicinity of electrical detonators Making a call: shielded rooms • areas where radio transmission is forbidden Off-hook enter number On-hook Enter number Do not place your handset near: number> Telephone Book · water, moisture, or damp areas · heat sources, direct sunlight, or unventilated areas Redial List 🧻 <number> 🕣 · devices that generate strong magnetic fields (i) <Caller List> <number> (Caller List • areas with excessive dust, shock, or temperature

Fold

Legend

Fold

Fold

Answering a call

Terminating a call

Conferencing

Modifying your Telephone Book:		
Add	Options <new> enter number, enter name</new>	
Edit	<name> Options Edit OK</name>	
Delete	<name> Options Delete OK</name>	
Adjusting the ringer settings:		
Ringer type		Menu <ringer settings=""><type>OK</type></ringer>
Ringer volume		Menu <ringer settings=""><volume>OK</volume></ringer>
Buzzer on/off		Menu 😿
Vibrator on/off		Menu <ringer settings=""><device>OK</device></ringer>
Headset on/off		Menu <ringer settings=""><device>OK</device></ringer>
Mute incoming call		Silence

Copyright © 2004 Nortel Networks and licensers. Nortel Networks: P1014050

DECT4060 Standard 1.00

Panel 4, back cover

DECT Handset 4060 Quick Reference Card

<number> R <number> R

Panel 3, Inside back cover



NETWORKS*

Panel 1, front cover