

5. Appendixes

5.1 Physical-Logical Device Matrixes (2.5 INCH BOX)

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (1/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-000	HDD000-00	00/00	01-01	01-01	01-01
	HDD000-01	00/01	01-02	01-02	
	HDD000-02	00/02	01-03	01-03	01-03
	HDD000-03	00/03	01-04	01-04	
	HDD000-04	00/04	01-05	01-05	01-05
	HDD000-05	00/05	01-06	01-06	
	HDD000-06	00/06	01-07	01-07	01-07
	HDD000-07	00/07	01-08	01-08	
	HDD000-08	00/08	01-09	01-09	01-09
	HDD000-09	00/09	01-10	01-10	
	HDD000-0A	00/0A	01-11	01-11	01-11
	HDD000-0B	00/0B	01-12	01-12	
	HDD000-0C	00/0C	01-13	01-13	01-13
	HDD000-0D	00/0D	01-14	01-14	
	HDD000-0E	00/0E	01-15	01-15	01-15
	HDD000-0F	00/0F	01-16/Spare	01-16/Spare	01-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (2/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-001	HDD001-00	01/00	01-01	01-01	01-01
	HDD001-01	01/01	01-02	01-02	
	HDD001-02	01/02	01-03	01-03	01-03
	HDD001-03	01/03	01-04	01-04	
	HDD001-04	01/04	01-05	01-05	01-05
	HDD001-05	01/05	01-06	01-06	
	HDD001-06	01/06	01-07	01-07	01-07
	HDD001-07	01/07	01-08	01-08	
	HDD001-08	01/08	01-09	01-09	01-09
	HDD001-09	01/09	01-10	01-10	
	HDD001-0A	01/0A	01-11	01-11	01-11
	HDD001-0B	01/0B	01-12	01-12	
	HDD001-0C	01/0C	01-13	01-13	01-13
	HDD001-0D	01/0D	01-14	01-14	
	HDD001-0E	01/0E	01-15	01-15	01-15
	HDD001-0F	01/0F	01-16/Spare	01-16/Spare	01-15/Spare

THEORY05-20**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(3/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD002	HDD002-00	02/00	01-01	01-01	01-01
	HDD002-01	02/01	01-02	01-02	
	HDD002-02	02/02	01-03	01-03	01-03
	HDD002-03	02/03	01-04	01-04	
	HDD002-04	02/04	01-05	01-05	01-05
	HDD002-05	02/05	01-06	01-06	
	HDD002-06	02/06	01-07	01-07	01-07
	HDD002-07	02/07	01-08	01-08	
	HDD002-08	02/08	01-09	01-09	01-09
	HDD002-09	02/09	01-10	01-10	
	HDD002-0A	02/0A	01-11	01-11	01-11
	HDD002-0B	02/0B	01-12	01-12	
	HDD002-0C	02/0C	01-13	01-13	01-13
	HDD002-0D	02/0D	01-14	01-14	
	HDD002-0E	02/0E	01-15	01-15	01-15
	HDD002-0F	02/0F	01-16/Spare	01-16/Spare	01-15/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(4/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD003	HDD003-00	03/00	01-01	01-01	01-01
	HDD003-01	03/01	01-02	01-02	
	HDD003-02	03/02	01-03	01-03	01-03
	HDD003-03	03/03	01-04	01-04	
	HDD003-04	03/04	01-05	01-05	01-05
	HDD003-05	03/05	01-06	01-06	
	HDD003-06	03/06	01-07	01-07	01-07
	HDD003-07	03/07	01-08	01-08	
	HDD003-08	03/08	01-09	01-09	01-09
	HDD003-09	03/09	01-10	01-10	
	HDD003-0A	03/0A	01-11	01-11	01-11
	HDD003-0B	03/0B	01-12	01-12	
	HDD003-0C	03/0C	01-13	01-13	01-13
	HDD003-0D	03/0D	01-14	01-14	
	HDD003-0E	03/0E	01-15	01-15	01-15
	HDD003-0F	03/0F	01-16/Spare	01-16/Spare	01-15/Spare

THEORY05-30**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(5/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD004	HDD004-00	04/00	02-01	01-01	01-01
	HDD004-01	04/01	02-02	01-02	
	HDD004-02	04/02	02-03	01-03	01-03
	HDD004-03	04/03	02-04	01-04	
	HDD004-04	04/04	02-05	01-05	01-05
	HDD004-05	04/05	02-06	01-06	
	HDD004-06	04/06	02-07	01-07	01-07
	HDD004-07	04/07	02-08	01-08	
	HDD004-08	04/08	02-09	01-09	01-09
	HDD004-09	04/09	02-10	01-10	
	HDD004-0A	04/0A	02-11	01-11	01-11
	HDD004-0B	04/0B	02-12	01-12	
	HDD004-0C	04/0C	02-13	01-13	01-13
	HDD004-0D	04/0D	02-14	01-14	
	HDD004-0E	04/0E	02-15	01-15	01-15
	HDD004-0F	04/0F	02-16/Spare	01-16/Spare	01-15/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(6/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD005	HDD005-00	05/00	02-01	01-01	01-01
	HDD005-01	05/01	02-02	01-02	
	HDD005-02	05/02	02-03	01-03	01-03
	HDD005-03	05/03	02-04	01-04	
	HDD005-04	05/04	02-05	01-05	01-05
	HDD005-05	05/05	02-06	01-06	
	HDD005-06	05/06	02-07	01-07	01-07
	HDD005-07	05/07	02-08	01-08	
	HDD005-08	05/08	02-09	01-09	01-09
	HDD005-09	05/09	02-10	01-10	
	HDD005-0A	05/0A	02-11	01-11	01-11
	HDD005-0B	05/0B	02-12	01-12	
	HDD005-0C	05/0C	02-13	01-13	01-13
	HDD005-0D	05/0D	02-14	01-14	
	HDD005-0E	05/0E	02-15	01-15	01-15
	HDD005-0F	05/0F	02-16/Spare	01-16/Spare	01-15/Spare

THEORY05-40**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(7/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-006	HDD006-00	06/00	02-01	01-01	01-01
	HDD006-01	06/01	02-02	01-02	
	HDD006-02	06/02	02-03	01-03	01-03
	HDD006-03	06/03	02-04	01-04	
	HDD006-04	06/04	02-05	01-05	01-05
	HDD006-05	06/05	02-06	01-06	
	HDD006-06	06/06	02-07	01-07	01-07
	HDD006-07	06/07	02-08	01-08	
	HDD006-08	06/08	02-09	01-09	01-09
	HDD006-09	06/09	02-10	01-10	
	HDD006-0A	06/0A	02-11	01-11	01-11
	HDD006-0B	06/0B	02-12	01-12	
	HDD006-0C	06/0C	02-13	01-13	01-13
	HDD006-0D	06/0D	02-14	01-14	
	HDD006-0E	06/0E	02-15	01-15	01-15
	HDD006-0F	06/0F	02-16/Spare	01-16/Spare	01-15/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(8/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-007	HDD007-00	07/00	02-01	01-01	01-01
	HDD007-01	07/01	02-02	01-02	
	HDD007-02	07/02	02-03	01-03	01-03
	HDD007-03	07/03	02-04	01-04	
	HDD007-04	07/04	02-05	01-05	01-05
	HDD007-05	07/05	02-06	01-06	
	HDD007-06	07/06	02-07	01-07	01-07
	HDD007-07	07/07	02-08	01-08	
	HDD007-08	07/08	02-09	01-09	01-09
	HDD007-09	07/09	02-10	01-10	
	HDD007-0A	07/0A	02-11	01-11	01-11
	HDD007-0B	07/0B	02-12	01-12	
	HDD007-0C	07/0C	02-13	01-13	01-13
	HDD007-0D	07/0D	02-14	01-14	
	HDD007-0E	07/0E	02-15	01-15	01-15
	HDD007-0F	07/0F	02-16/Spare	01-16/Spare	01-15/Spare

THEORY05-50**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(9/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-100	HDD100-00	08/00	03-01	03-01	03-01
	HDD100-01	08/01	03-02	03-02	
	HDD100-02	08/02	03-03	03-03	03-03
	HDD100-03	08/03	03-04	03-04	
	HDD100-04	08/04	03-05	03-05	03-05
	HDD100-05	08/05	03-06	03-06	
	HDD100-06	08/06	03-07	03-07	03-07
	HDD100-07	08/07	03-08	03-08	
	HDD100-08	08/08	03-09	03-09	03-09
	HDD100-09	08/09	03-10	03-10	
	HDD100-0A	08/0A	03-11	03-11	03-11
	HDD100-0B	08/0B	03-12	03-12	
	HDD100-0C	08/0C	03-13	03-13	03-13
	HDD100-0D	08/0D	03-14	03-14	
	HDD100-0E	08/0E	03-15	03-15	03-15
	HDD100-0F	08/0F	03-16/Spare	03-16/Spare	03-15/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(10/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-101	HDD101-00	09/00	03-01	03-01	03-01
	HDD101-01	09/01	03-02	03-02	
	HDD101-02	09/02	03-03	03-03	03-03
	HDD101-03	09/03	03-04	03-04	
	HDD101-04	09/04	03-05	03-05	03-05
	HDD101-05	09/05	03-06	03-06	
	HDD101-06	09/06	03-07	03-07	03-07
	HDD101-07	09/07	03-08	03-08	
	HDD101-08	09/08	03-09	03-09	03-09
	HDD101-09	09/09	03-10	03-10	
	HDD101-0A	09/0A	03-11	03-11	03-11
	HDD101-0B	09/0B	03-12	03-12	
	HDD101-0C	09/0C	03-13	03-13	03-13
	HDD101-0D	09/0D	03-14	03-14	
	HDD101-0E	09/0E	03-15	03-15	03-15
	HDD101-0F	09/0F	03-16/Spare	03-16/Spare	03-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (11/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-102	HDD102-00	0A/00	03-01	03-01	03-01
	HDD102-01	0A/01	03-02	03-02	
	HDD102-02	0A/02	03-03	03-03	03-03
	HDD102-03	0A/03	03-04	03-04	
	HDD102-04	0A/04	03-05	03-05	03-05
	HDD102-05	0A/05	03-06	03-06	
	HDD102-06	0A/06	03-07	03-07	03-07
	HDD102-07	0A/07	03-08	03-08	
	HDD102-08	0A/08	03-09	03-09	03-09
	HDD102-09	0A/09	03-10	03-10	
	HDD102-0A	0A/0A	03-11	03-11	03-11
	HDD102-0B	0A/0B	03-12	03-12	
	HDD102-0C	0A/0C	03-13	03-13	03-13
	HDD102-0D	0A/0D	03-14	03-14	
	HDD102-0E	0A/0E	03-15	03-15	03-15
	HDD102-0F	0A/0F	03-16/Spare	03-16/Spare	03-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (12/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-103	HDD103-00	0B/00	03-01	03-01	03-01
	HDD103-01	0B/01	03-02	03-02	
	HDD103-02	0B/02	03-03	03-03	03-03
	HDD103-03	0B/03	03-04	03-04	
	HDD103-04	0B/04	03-05	03-05	03-05
	HDD103-05	0B/05	03-06	03-06	
	HDD103-06	0B/06	03-07	03-07	03-07
	HDD103-07	0B/07	03-08	03-08	
	HDD103-08	0B/08	03-09	03-09	03-09
	HDD103-09	0B/09	03-10	03-10	
	HDD103-0A	0B/0A	03-11	03-11	03-11
	HDD103-0B	0B/0B	03-12	03-12	
	HDD103-0C	0B/0C	03-13	03-13	03-13
	HDD103-0D	0B/0D	03-14	03-14	
	HDD103-0E	0B/0E	03-15	03-15	03-15
	HDD103-0F	0B/0F	03-16/Spare	03-16/Spare	03-15/Spare

THEORY05-70**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(13/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-104	HDD104-00	0C/00	04-01	03-01	03-01
	HDD104-01	0C/01	04-02	03-02	
	HDD104-02	0C/02	04-03	03-03	03-03
	HDD104-03	0C/03	04-04	03-04	
	HDD104-04	0C/04	04-05	03-05	03-05
	HDD104-05	0C/05	04-06	03-06	
	HDD104-06	0C/06	04-07	03-07	03-07
	HDD104-07	0C/07	04-08	03-08	
	HDD104-08	0C/08	04-09	03-09	03-09
	HDD104-09	0C/09	04-10	03-10	
	HDD104-0A	0C/0A	04-11	03-11	03-11
	HDD104-0B	0C/0B	04-12	03-12	
	HDD104-0C	0C/0C	04-13	03-13	03-13
	HDD104-0D	0C/0D	04-14	03-14	
	HDD104-0E	0C/0E	04-15	03-15	03-15
	HDD104-0F	0C/0F	04-16/Spare	03-16/Spare	03-15/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(14/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-105	HDD105-00	0D/00	04-01	03-01	03-01
	HDD105-01	0D/01	04-02	03-02	
	HDD105-02	0D/02	04-03	03-03	03-03
	HDD105-03	0D/03	04-04	03-04	
	HDD105-04	0D/04	04-05	03-05	03-05
	HDD105-05	0D/05	04-06	03-06	
	HDD105-06	0D/06	04-07	03-07	03-07
	HDD105-07	0D/07	04-08	03-08	
	HDD105-08	0D/08	04-09	03-09	03-09
	HDD105-09	0D/09	04-10	03-10	
	HDD105-0A	0D/0A	04-11	03-11	03-11
	HDD105-0B	0D/0B	04-12	03-12	
	HDD105-0C	0D/0C	04-13	03-13	03-13
	HDD105-0D	0D/0D	04-14	03-14	
	HDD105-0E	0D/0E	04-15	03-15	03-15
	HDD105-0F	0D/0F	04-16/Spare	03-16/Spare	03-15/Spare

THEORY05-80**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(15/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-106	HDD106-00	0E/00	04-01	03-01	03-01
	HDD106-01	0E/01	04-02	03-02	
	HDD106-02	0E/02	04-03	03-03	03-03
	HDD106-03	0E/03	04-04	03-04	
	HDD106-04	0E/04	04-05	03-05	03-05
	HDD106-05	0E/05	04-06	03-06	
	HDD106-06	0E/06	04-07	03-07	03-07
	HDD106-07	0E/07	04-08	03-08	
	HDD106-08	0E/08	04-09	03-09	03-09
	HDD106-09	0E/09	04-10	03-10	
	HDD106-0A	0E/0A	04-11	03-11	03-11
	HDD106-0B	0E/0B	04-12	03-12	
	HDD106-0C	0E/0C	04-13	03-13	03-13
	HDD106-0D	0E/0D	04-14	03-14	
	HDD106-0E	0E/0E	04-15	03-15	03-15
	HDD106-0F	0E/0F	04-16/Spare	03-16/Spare	03-15/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX)
(16/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-107	HDD107-00	0F/00	04-01	03-01	03-01
	HDD107-01	0F/01	04-02	03-02	
	HDD107-02	0F/02	04-03	03-03	03-03
	HDD107-03	0F/03	04-04	03-04	
	HDD107-04	0F/04	04-05	03-05	03-05
	HDD107-05	0F/05	04-06	03-06	
	HDD107-06	0F/06	04-07	03-07	03-07
	HDD107-07	0F/07	04-08	03-08	
	HDD107-08	0F/08	04-09	03-09	03-09
	HDD107-09	0F/09	04-10	03-10	
	HDD107-0A	0F/0A	04-11	03-11	03-11
	HDD107-0B	0F/0B	04-12	03-12	
	HDD107-0C	0F/0C	04-13	03-13	03-13
	HDD107-0D	0F/0D	04-14	03-14	
	HDD107-0E	0F/0E	04-15	03-15	03-15
	HDD107-0F	0F/0F	04-16/Spare	03-16/Spare	03-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (17/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-010	HDD010-00	00/10	05-01	05-01	05-01
	HDD010-01	00/11	05-02	05-02	
	HDD010-02	00/12	05-03	05-03	05-03
	HDD010-03	00/13	05-04	05-04	
	HDD010-04	00/14	05-05	05-05	05-05
	HDD010-05	00/15	05-06	05-06	
	HDD010-06	00/16	05-07	05-07	05-07
	HDD010-07	00/17	05-08	05-08	
	HDD010-08	00/18	05-09	05-09	05-09
	HDD010-09	00/19	05-10	05-10	
	HDD010-0A	00/1A	05-11	05-11	05-11
	HDD010-0B	00/1B	05-12	05-12	
	HDD010-0C	00/1C	05-13	05-13	05-13
	HDD010-0D	00/1D	05-14	05-14	
	HDD010-0E	00/1E	05-15	05-15	05-15
	HDD010-0F	00/1F	05-16/Spare	05-16/Spare	05-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (18/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-011	HDD011-00	01/10	05-01	05-01	05-01
	HDD011-01	01/11	05-02	05-02	
	HDD011-02	01/12	05-03	05-03	05-03
	HDD011-03	01/13	05-04	05-04	
	HDD011-04	01/14	05-05	05-05	05-05
	HDD011-05	01/15	05-06	05-06	
	HDD011-06	01/16	05-07	05-07	05-07
	HDD011-07	01/17	05-08	05-08	
	HDD011-08	01/18	05-09	05-09	05-09
	HDD011-09	01/19	05-10	05-10	
	HDD011-0A	01/1A	05-11	05-11	05-11
	HDD011-0B	01/1B	05-12	05-12	
	HDD011-0C	01/1C	05-13	05-13	05-13
	HDD011-0D	01/1D	05-14	05-14	
	HDD011-0E	01/1E	05-15	05-15	05-15
	HDD011-0F	01/1F	05-16/Spare	05-16/Spare	05-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (19/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-012	HDD012-00	02/10	05-01	05-01	05-01
	HDD012-01	02/11	05-02	05-02	
	HDD012-02	02/12	05-03	05-03	05-03
	HDD012-03	02/13	05-04	05-04	
	HDD012-04	02/14	05-05	05-05	05-05
	HDD012-05	02/15	05-06	05-06	
	HDD012-06	02/16	05-07	05-07	05-07
	HDD012-07	02/17	05-08	05-08	
	HDD012-08	02/18	05-09	05-09	05-09
	HDD012-09	02/19	05-10	05-10	
	HDD012-0A	02/1A	05-11	05-11	05-11
	HDD012-0B	02/1B	05-12	05-12	
	HDD012-0C	02/1C	05-13	05-13	05-13
	HDD012-0D	02/1D	05-14	05-14	
	HDD012-0E	02/1E	05-15	05-15	05-15
	HDD012-0F	02/1F	05-16/Spare	05-16/Spare	05-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (20/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-013	HDD013-00	03/10	05-01	05-01	05-01
	HDD013-01	03/11	05-02	05-02	
	HDD013-02	03/12	05-03	05-03	05-03
	HDD013-03	03/13	05-04	05-04	
	HDD013-04	03/14	05-05	05-05	05-05
	HDD013-05	03/15	05-06	05-06	
	HDD013-06	03/16	05-07	05-07	05-07
	HDD013-07	03/17	05-08	05-08	
	HDD013-08	03/18	05-09	05-09	05-09
	HDD013-09	03/19	05-10	05-10	
	HDD013-0A	03/1A	05-11	05-11	05-11
	HDD013-0B	03/1B	05-12	05-12	
	HDD013-0C	03/1C	05-13	05-13	05-13
	HDD013-0D	03/1D	05-14	05-14	
	HDD013-0E	03/1E	05-15	05-15	05-15
	HDD013-0F	03/1F	05-16/Spare	05-16/Spare	05-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (21/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-014	HDD014-00	04/10	06-01	05-01	05-01
	HDD014-01	04/11	06-02	05-02	
	HDD014-02	04/12	06-03	05-03	05-03
	HDD014-03	04/13	06-04	05-04	
	HDD014-04	04/14	06-05	05-05	05-05
	HDD014-05	04/15	06-06	05-06	
	HDD014-06	04/16	06-07	05-07	05-07
	HDD014-07	04/17	06-08	05-08	
	HDD014-08	04/18	06-09	05-09	05-09
	HDD014-09	04/19	06-10	05-10	
	HDD014-0A	04/1A	06-11	05-11	05-11
	HDD014-0B	04/1B	06-12	05-12	
	HDD014-0C	04/1C	06-13	05-13	05-13
	HDD014-0D	04/1D	06-14	05-14	
	HDD014-0E	04/1E	06-15	05-15	05-15
	HDD014-0F	04/1F	06-16/Spare	05-16/Spare	05-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (22/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-015	HDD015-00	05/10	06-01	05-01	05-01
	HDD015-01	05/11	06-02	05-02	
	HDD015-02	05/12	06-03	05-03	05-03
	HDD015-03	05/13	06-04	05-04	
	HDD015-04	05/14	06-05	05-05	05-05
	HDD015-05	05/15	06-06	05-06	
	HDD015-06	05/16	06-07	05-07	05-07
	HDD015-07	05/17	06-08	05-08	
	HDD015-08	05/18	06-09	05-09	05-09
	HDD015-09	05/19	06-10	05-10	
	HDD015-0A	05/1A	06-11	05-11	05-11
	HDD015-0B	05/1B	06-12	05-12	
	HDD015-0C	05/1C	06-13	05-13	05-13
	HDD015-0D	05/1D	06-14	05-14	
	HDD015-0E	05/1E	06-15	05-15	05-15
	HDD015-0F	05/1F	06-16/Spare	05-16/Spare	05-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (23/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-016	HDD016-00	06/10	06-01	05-01	05-01
	HDD016-01	06/11	06-02	05-02	
	HDD016-02	06/12	06-03	05-03	05-03
	HDD016-03	06/13	06-04	05-04	
	HDD016-04	06/14	06-05	05-05	05-05
	HDD016-05	06/15	06-06	05-06	
	HDD016-06	06/16	06-07	05-07	05-07
	HDD016-07	06/17	06-08	05-08	
	HDD016-08	06/18	06-09	05-09	05-09
	HDD016-09	06/19	06-10	05-10	
	HDD016-0A	06/1A	06-11	05-11	05-11
	HDD016-0B	06/1B	06-12	05-12	
	HDD016-0C	06/1C	06-13	05-13	05-13
	HDD016-0D	06/1D	06-14	05-14	
	HDD016-0E	06/1E	06-15	05-15	05-15
	HDD016-0F	06/1F	06-16/Spare	05-16/Spare	05-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (24/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-017	HDD017-00	07/10	06-01	05-01	05-01
	HDD017-01	07/11	06-02	05-02	
	HDD017-02	07/12	06-03	05-03	05-03
	HDD017-03	07/13	06-04	05-04	
	HDD017-04	07/14	06-05	05-05	05-05
	HDD017-05	07/15	06-06	05-06	
	HDD017-06	07/16	06-07	05-07	05-07
	HDD017-07	07/17	06-08	05-08	
	HDD017-08	07/18	06-09	05-09	05-09
	HDD017-09	07/19	06-10	05-10	
	HDD017-0A	07/1A	06-11	05-11	05-11
	HDD017-0B	07/1B	06-12	05-12	
	HDD017-0C	07/1C	06-13	05-13	05-13
	HDD017-0D	07/1D	06-14	05-14	
	HDD017-0E	07/1E	06-15	05-15	05-15
	HDD017-0F	07/1F	06-16/Spare	05-16/Spare	05-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (25/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-110	HDD110-00	08/10	07-01	07-01	07-01
	HDD110-01	08/11	07-02	07-02	
	HDD110-02	08/12	07-03	07-03	07-03
	HDD110-03	08/13	07-04	07-04	
	HDD110-04	08/14	07-05	07-05	07-05
	HDD110-05	08/15	07-06	07-06	
	HDD110-06	08/16	07-07	07-07	07-07
	HDD110-07	08/17	07-08	07-08	
	HDD110-08	08/18	07-09	07-09	07-09
	HDD110-09	08/19	07-10	07-10	
	HDD110-0A	08/1A	07-11	07-11	07-11
	HDD110-0B	08/1B	07-12	07-12	
	HDD110-0C	08/1C	07-13	07-13	07-13
	HDD110-0D	08/1D	07-14	07-14	
	HDD110-0E	08/1E	07-15	07-15	07-15
	HDD110-0F	08/1F	07-16/Spare	07-16/Spare	07-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (26/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-111	HDD111-00	09/10	07-01	07-01	07-01
	HDD111-01	09/11	07-02	07-02	
	HDD111-02	09/12	07-03	07-03	07-03
	HDD111-03	09/13	07-04	07-04	
	HDD111-04	09/14	07-05	07-05	07-05
	HDD111-05	09/15	07-06	07-06	
	HDD111-06	09/16	07-07	07-07	07-07
	HDD111-07	09/17	07-08	07-08	
	HDD111-08	09/18	07-09	07-09	07-09
	HDD111-09	09/19	07-10	07-10	
	HDD111-0A	09/1A	07-11	07-11	07-11
	HDD111-0B	09/1B	07-12	07-12	
	HDD111-0C	09/1C	07-13	07-13	07-13
	HDD111-0D	09/1D	07-14	07-14	
	HDD111-0E	09/1E	07-15	07-15	07-15
	HDD111-0F	09/1F	07-16/Spare	07-16/Spare	07-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (27/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-112	HDD112-00	0A/10	07-01	07-01	07-01
	HDD112-01	0A/11	07-02	07-02	
	HDD112-02	0A/12	07-03	07-03	07-03
	HDD112-03	0A/13	07-04	07-04	
	HDD112-04	0A/14	07-05	07-05	07-05
	HDD112-05	0A/15	07-06	07-06	
	HDD112-06	0A/16	07-07	07-07	07-07
	HDD112-07	0A/17	07-08	07-08	
	HDD112-08	0A/18	07-09	07-09	07-09
	HDD112-09	0A/19	07-10	07-10	
	HDD112-0A	0A/1A	07-11	07-11	07-11
	HDD112-0B	0A/1B	07-12	07-12	
	HDD112-0C	0A/1C	07-13	07-13	07-13
	HDD112-0D	0A/1D	07-14	07-14	
	HDD112-0E	0A/1E	07-15	07-15	07-15
	HDD112-0F	0A/1F	07-16/Spare	07-16/Spare	07-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (28/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-113	HDD113-00	0B/10	07-01	07-01	07-01
	HDD113-01	0B/11	07-02	07-02	
	HDD113-02	0B/12	07-03	07-03	07-03
	HDD113-03	0B/13	07-04	07-04	
	HDD113-04	0B/14	07-05	07-05	07-05
	HDD113-05	0B/15	07-06	07-06	
	HDD113-06	0B/16	07-07	07-07	07-07
	HDD113-07	0B/17	07-08	07-08	
	HDD113-08	0B/18	07-09	07-09	07-09
	HDD113-09	0B/19	07-10	07-10	
	HDD113-0A	0B/1A	07-11	07-11	07-11
	HDD113-0B	0B/1B	07-12	07-12	
	HDD113-0C	0B/1C	07-13	07-13	07-13
	HDD113-0D	0B/1D	07-14	07-14	
	HDD113-0E	0B/1E	07-15	07-15	07-15
	HDD113-0F	0B/1F	07-16/Spare	07-16/Spare	07-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (29/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-114	HDD114-00	0C/10	08-01	07-01	07-01
	HDD114-01	0C/11	08-02	07-02	
	HDD114-02	0C/12	08-03	07-03	07-03
	HDD114-03	0C/13	08-04	07-04	
	HDD114-04	0C/14	08-05	07-05	07-05
	HDD114-05	0C/15	08-06	07-06	
	HDD114-06	0C/16	08-07	07-07	07-07
	HDD114-07	0C/17	08-08	07-08	
	HDD114-08	0C/18	08-09	07-09	07-09
	HDD114-09	0C/19	08-10	07-10	
	HDD114-0A	0C/1A	08-11	07-11	07-11
	HDD114-0B	0C/1B	08-12	07-12	
	HDD114-0C	0C/1C	08-13	07-13	07-13
	HDD114-0D	0C/1D	08-14	07-14	
	HDD114-0E	0C/1E	08-15	07-15	07-15
	HDD114-0F	0C/1F	08-16/Spare	07-16/Spare	07-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (30/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-115	HDD115-00	0D/10	08-01	07-01	07-01
	HDD115-01	0D/11	08-02	07-02	
	HDD115-02	0D/12	08-03	07-03	07-03
	HDD115-03	0D/13	08-04	07-04	
	HDD115-04	0D/14	08-05	07-05	07-05
	HDD115-05	0D/15	08-06	07-06	
	HDD115-06	0D/16	08-07	07-07	07-07
	HDD115-07	0D/17	08-08	07-08	
	HDD115-08	0D/18	08-09	07-09	07-09
	HDD115-09	0D/19	08-10	07-10	
	HDD115-0A	0D/1A	08-11	07-11	07-11
	HDD115-0B	0D/1B	08-12	07-12	
	HDD115-0C	0D/1C	08-13	07-13	07-13
	HDD115-0D	0D/1D	08-14	07-14	
	HDD115-0E	0D/1E	08-15	07-15	07-15
	HDD115-0F	0D/1F	08-16/Spare	07-16/Spare	07-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (31/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-116	HDD116-00	0E/10	08-01	07-01	07-01
	HDD116-01	0E/11	08-02	07-02	
	HDD116-02	0E/12	08-03	07-03	07-03
	HDD116-03	0E/13	08-04	07-04	
	HDD116-04	0E/14	08-05	07-05	07-05
	HDD116-05	0E/15	08-06	07-06	
	HDD116-06	0E/16	08-07	07-07	07-07
	HDD116-07	0E/17	08-08	07-08	
	HDD116-08	0E/18	08-09	07-09	07-09
	HDD116-09	0E/19	08-10	07-10	
	HDD116-0A	0E/1A	08-11	07-11	07-11
	HDD116-0B	0E/1B	08-12	07-12	
	HDD116-0C	0E/1C	08-13	07-13	07-13
	HDD116-0D	0E/1D	08-14	07-14	
	HDD116-0E	0E/1E	08-15	07-15	07-15
	HDD116-0F	0E/1F	08-16/Spare	07-16/Spare	07-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (32/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-117	HDD117-00	0F/10	08-01	07-01	07-01
	HDD117-01	0F/11	08-02	07-02	
	HDD117-02	0F/12	08-03	07-03	07-03
	HDD117-03	0F/13	08-04	07-04	
	HDD117-04	0F/14	08-05	07-05	07-05
	HDD117-05	0F/15	08-06	07-06	
	HDD117-06	0F/16	08-07	07-07	07-07
	HDD117-07	0F/17	08-08	07-08	
	HDD117-08	0F/18	08-09	07-09	07-09
	HDD117-09	0F/19	08-10	07-10	
	HDD117-0A	0F/1A	08-11	07-11	07-11
	HDD117-0B	0F/1B	08-12	07-12	
	HDD117-0C	0F/1C	08-13	07-13	07-13
	HDD117-0D	0F/1D	08-14	07-14	
	HDD117-0E	0F/1E	08-15	07-15	07-15
	HDD117-0F	0F/1F	08-16/Spare	07-16/Spare	07-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (33/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-020	HDD020-00	00/20	09-01	09-01	09-01
	HDD020-01	00/21	09-02	09-02	
	HDD020-02	00/22	09-03	09-03	09-03
	HDD020-03	00/23	09-04	09-04	
	HDD020-04	00/24	09-05	09-05	09-05
	HDD020-05	00/25	09-06	09-06	
	HDD020-06	00/26	09-07	09-07	09-07
	HDD020-07	00/27	09-08	09-08	
	HDD020-08	00/28	09-09	09-09	09-09
	HDD020-09	00/29	09-10	09-10	
	HDD020-0A	00/2A	09-11	09-11	09-11
	HDD020-0B	00/2B	09-12	09-12	
	HDD020-0C	00/2C	09-13	09-13	09-13
	HDD020-0D	00/2D	09-14	09-14	
	HDD020-0E	00/2E	09-15	09-15	09-15
	HDD020-0F	00/2F	09-16/Spare	09-16/Spare	09-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (34/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-021	HDD021-00	01/20	09-01	09-01	09-01
	HDD021-01	01/21	09-02	09-02	
	HDD021-02	01/22	09-03	09-03	09-03
	HDD021-03	01/23	09-04	09-04	
	HDD021-04	01/24	09-05	09-05	09-05
	HDD021-05	01/25	09-06	09-06	
	HDD021-06	01/26	09-07	09-07	09-07
	HDD021-07	01/27	09-08	09-08	
	HDD021-08	01/28	09-09	09-09	09-09
	HDD021-09	01/29	09-10	09-10	
	HDD021-0A	01/2A	09-11	09-11	09-11
	HDD021-0B	01/2B	09-12	09-12	
	HDD021-0C	01/2C	09-13	09-13	09-13
	HDD021-0D	01/2D	09-14	09-14	
	HDD021-0E	01/2E	09-15	09-15	09-15
	HDD021-0F	01/2F	09-16/Spare	09-16/Spare	09-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (35/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-022	HDD022-00	02/20	09-01	09-01	09-01
	HDD022-01	02/21	09-02	09-02	
	HDD022-02	02/22	09-03	09-03	09-03
	HDD022-03	02/23	09-04	09-04	
	HDD022-04	02/24	09-05	09-05	09-05
	HDD022-05	02/25	09-06	09-06	
	HDD022-06	02/26	09-07	09-07	09-07
	HDD022-07	02/27	09-08	09-08	
	HDD022-08	02/28	09-09	09-09	09-09
	HDD022-09	02/29	09-10	09-10	
	HDD022-0A	02/2A	09-11	09-11	09-11
	HDD022-0B	02/2B	09-12	09-12	
	HDD022-0C	02/2C	09-13	09-13	09-13
	HDD022-0D	02/2D	09-14	09-14	
	HDD022-0E	02/2E	09-15	09-15	09-15
	HDD022-0F	02/2F	09-16/Spare	09-16/Spare	09-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (36/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-023	HDD023-00	03/20	09-01	09-01	09-01
	HDD023-01	03/21	09-02	09-02	
	HDD023-02	03/22	09-03	09-03	09-03
	HDD023-03	03/23	09-04	09-04	
	HDD023-04	03/24	09-05	09-05	09-05
	HDD023-05	03/25	09-06	09-06	
	HDD023-06	03/26	09-07	09-07	09-07
	HDD023-07	03/27	09-08	09-08	
	HDD023-08	03/28	09-09	09-09	09-09
	HDD023-09	03/29	09-10	09-10	
	HDD023-0A	03/2A	09-11	09-11	09-11
	HDD023-0B	03/2B	09-12	09-12	
	HDD023-0C	03/2C	09-13	09-13	09-13
	HDD023-0D	03/2D	09-14	09-14	
	HDD023-0E	03/2E	09-15	09-15	09-15
	HDD023-0F	03/2F	09-16/Spare	09-16/Spare	09-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (37/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-024	HDD024-00	04/20	10-01	09-01	09-01
	HDD024-01	04/21	10-02	09-02	
	HDD024-02	04/22	10-03	09-03	09-03
	HDD024-03	04/23	10-04	09-04	
	HDD024-04	04/24	10-05	09-05	09-05
	HDD024-05	04/25	10-06	09-06	
	HDD024-06	04/26	10-07	09-07	09-07
	HDD024-07	04/27	10-08	09-08	
	HDD024-08	04/28	10-09	09-09	09-09
	HDD024-09	04/29	10-10	09-10	
	HDD024-0A	04/2A	10-11	09-11	09-11
	HDD024-0B	04/2B	10-12	09-12	
	HDD024-0C	04/2C	10-13	09-13	09-13
	HDD024-0D	04/2D	10-14	09-14	
	HDD024-0E	04/2E	10-15	09-15	09-15
	HDD024-0F	04/2F	10-16/Spare	09-16/Spare	09-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (38/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-025	HDD025-00	05/20	10-01	09-01	09-01
	HDD025-01	05/21	10-02	09-02	
	HDD025-02	05/22	10-03	09-03	09-03
	HDD025-03	05/23	10-04	09-04	
	HDD025-04	05/24	10-05	09-05	09-05
	HDD025-05	05/25	10-06	09-06	
	HDD025-06	05/26	10-07	09-07	09-07
	HDD025-07	05/27	10-08	09-08	
	HDD025-08	05/28	10-09	09-09	09-09
	HDD025-09	05/29	10-10	09-10	
	HDD025-0A	05/2A	10-11	09-11	09-11
	HDD025-0B	05/2B	10-12	09-12	
	HDD025-0C	05/2C	10-13	09-13	09-13
	HDD025-0D	05/2D	10-14	09-14	
	HDD025-0E	05/2E	10-15	09-15	09-15
	HDD025-0F	05/2F	10-16/Spare	09-16/Spare	09-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (39/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-026	HDD026-00	06/20	10-01	09-01	09-01
	HDD026-01	06/21	10-02	09-02	
	HDD026-02	06/22	10-03	09-03	09-03
	HDD026-03	06/23	10-04	09-04	
	HDD026-04	06/24	10-05	09-05	09-05
	HDD026-05	06/25	10-06	09-06	
	HDD026-06	06/26	10-07	09-07	09-07
	HDD026-07	06/27	10-08	09-08	
	HDD026-08	06/28	10-09	09-09	09-09
	HDD026-09	06/29	10-10	09-10	
	HDD026-0A	06/2A	10-11	09-11	09-11
	HDD026-0B	06/2B	10-12	09-12	
	HDD026-0C	06/2C	10-13	09-13	09-13
	HDD026-0D	06/2D	10-14	09-14	
	HDD026-0E	06/2E	10-15	09-15	09-15
	HDD026-0F	06/2F	10-16/Spare	09-16/Spare	09-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (40/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-027	HDD027-00	07/20	10-01	09-01	09-01
	HDD027-01	07/21	10-02	09-02	
	HDD027-02	07/22	10-03	09-03	09-03
	HDD027-03	07/23	10-04	09-04	
	HDD027-04	07/24	10-05	09-05	09-05
	HDD027-05	07/25	10-06	09-06	
	HDD027-06	07/26	10-07	09-07	09-07
	HDD027-07	07/27	10-08	09-08	
	HDD027-08	07/28	10-09	09-09	09-09
	HDD027-09	07/29	10-10	09-10	
	HDD027-0A	07/2A	10-11	09-11	09-11
	HDD027-0B	07/2B	10-12	09-12	
	HDD027-0C	07/2C	10-13	09-13	09-13
	HDD027-0D	07/2D	10-14	09-14	
	HDD027-0E	07/2E	10-15	09-15	09-15
	HDD027-0F	07/2F	10-16/Spare	09-16/Spare	09-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (41/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-120	HDD120-00	08/20	11-01	11-01	11-01
	HDD120-01	08/21	11-02	11-02	
	HDD120-02	08/22	11-03	11-03	11-03
	HDD120-03	08/23	11-04	11-04	
	HDD120-04	08/24	11-05	11-05	11-05
	HDD120-05	08/25	11-06	11-06	
	HDD120-06	08/26	11-07	11-07	11-07
	HDD120-07	08/27	11-08	11-08	
	HDD120-08	08/28	11-09	11-09	11-09
	HDD120-09	08/29	11-10	11-10	
	HDD120-0A	08/2A	11-11	11-11	11-11
	HDD120-0B	08/2B	11-12	11-12	
	HDD120-0C	08/2C	11-13	11-13	11-13
	HDD120-0D	08/2D	11-14	11-14	
	HDD120-0E	08/2E	11-15	11-15	11-15
	HDD120-0F	08/2F	11-16/Spare	11-16/Spare	11-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (42/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-121	HDD121-00	09/20	11-01	11-01	11-01
	HDD121-01	09/21	11-02	11-02	
	HDD121-02	09/22	11-03	11-03	11-03
	HDD121-03	09/23	11-04	11-04	
	HDD121-04	09/24	11-05	11-05	11-05
	HDD121-05	09/25	11-06	11-06	
	HDD121-06	09/26	11-07	11-07	11-07
	HDD121-07	09/27	11-08	11-08	
	HDD121-08	09/28	11-09	11-09	11-09
	HDD121-09	09/29	11-10	11-10	
	HDD121-0A	09/2A	11-11	11-11	11-11
	HDD121-0B	09/2B	11-12	11-12	
	HDD121-0C	09/2C	11-13	11-13	11-13
	HDD121-0D	09/2D	11-14	11-14	
	HDD121-0E	09/2E	11-15	11-15	11-15
	HDD121-0F	09/2F	11-16/Spare	11-16/Spare	11-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (43/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-122	HDD122-00	0A/20	11-01	11-01	11-01
	HDD122-01	0A/21	11-02	11-02	
	HDD122-02	0A/22	11-03	11-03	11-03
	HDD122-03	0A/23	11-04	11-04	
	HDD122-04	0A/24	11-05	11-05	11-05
	HDD122-05	0A/25	11-06	11-06	
	HDD122-06	0A/26	11-07	11-07	11-07
	HDD122-07	0A/27	11-08	11-08	
	HDD122-08	0A/28	11-09	11-09	11-09
	HDD122-09	0A/29	11-10	11-10	
	HDD122-0A	0A/2A	11-11	11-11	11-11
	HDD122-0B	0A/2B	11-12	11-12	
	HDD122-0C	0A/2C	11-13	11-13	11-13
	HDD122-0D	0A/2D	11-14	11-14	
	HDD122-0E	0A/2E	11-15	11-15	11-15
	HDD122-0F	0A/2F	11-16/Spare	11-16/Spare	11-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (44/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-123	HDD123-00	0B/20	11-01	11-01	11-01
	HDD123-01	0B/21	11-02	11-02	
	HDD123-02	0B/22	11-03	11-03	11-03
	HDD123-03	0B/23	11-04	11-04	
	HDD123-04	0B/24	11-05	11-05	11-05
	HDD123-05	0B/25	11-06	11-06	
	HDD123-06	0B/26	11-07	11-07	11-07
	HDD123-07	0B/27	11-08	11-08	
	HDD123-08	0B/28	11-09	11-09	11-09
	HDD123-09	0B/29	11-10	11-10	
	HDD123-0A	0B/2A	11-11	11-11	11-11
	HDD123-0B	0B/2B	11-12	11-12	
	HDD123-0C	0B/2C	11-13	11-13	11-13
	HDD123-0D	0B/2D	11-14	11-14	
	HDD123-0E	0B/2E	11-15	11-15	11-15
	HDD123-0F	0B/2F	11-16/Spare	11-16/Spare	11-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (45/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-124	HDD124-00	0C/20	12-01	11-01	11-01
	HDD124-01	0C/21	12-02	11-02	
	HDD124-02	0C/22	12-03	11-03	11-03
	HDD124-03	0C/23	12-04	11-04	
	HDD124-04	0C/24	12-05	11-05	11-05
	HDD124-05	0C/25	12-06	11-06	
	HDD124-06	0C/26	12-07	11-07	11-07
	HDD124-07	0C/27	12-08	11-08	
	HDD124-08	0C/28	12-09	11-09	11-09
	HDD124-09	0C/29	12-10	11-10	
	HDD124-0A	0C/2A	12-11	11-11	11-11
	HDD124-0B	0C/2B	12-12	11-12	
	HDD124-0C	0C/2C	12-13	11-13	11-13
	HDD124-0D	0C/2D	12-14	11-14	
	HDD124-0E	0C/2E	12-15	11-15	11-15
	HDD124-0F	0C/2F	12-16/Spare	11-16/Spare	11-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (46/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-125	HDD125-00	0D/20	12-01	11-01	11-01
	HDD125-01	0D/21	12-02	11-02	
	HDD125-02	0D/22	12-03	11-03	11-03
	HDD125-03	0D/23	12-04	11-04	
	HDD125-04	0D/24	12-05	11-05	11-05
	HDD125-05	0D/25	12-06	11-06	
	HDD125-06	0D/26	12-07	11-07	11-07
	HDD125-07	0D/27	12-08	11-08	
	HDD125-08	0D/28	12-09	11-09	11-09
	HDD125-09	0D/29	12-10	11-10	
	HDD125-0A	0D/2A	12-11	11-11	11-11
	HDD125-0B	0D/2B	12-12	11-12	
	HDD125-0C	0D/2C	12-13	11-13	11-13
	HDD125-0D	0D/2D	12-14	11-14	
	HDD125-0E	0D/2E	12-15	11-15	11-15
	HDD125-0F	0D/2F	12-16/Spare	11-16/Spare	11-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (47/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-126	HDD126-00	0E/20	12-01	11-01	11-01
	HDD126-01	0E/21	12-02	11-02	
	HDD126-02	0E/22	12-03	11-03	11-03
	HDD126-03	0E/23	12-04	11-04	
	HDD126-04	0E/24	12-05	11-05	11-05
	HDD126-05	0E/25	12-06	11-06	
	HDD126-06	0E/26	12-07	11-07	11-07
	HDD126-07	0E/27	12-08	11-08	
	HDD126-08	0E/28	12-09	11-09	11-09
	HDD126-09	0E/29	12-10	11-10	
	HDD126-0A	0E/2A	12-11	11-11	11-11
	HDD126-0B	0E/2B	12-12	11-12	
	HDD126-0C	0E/2C	12-13	11-13	11-13
	HDD126-0D	0E/2D	12-14	11-14	
	HDD126-0E	0E/2E	12-15	11-15	11-15
	HDD126-0F	0E/2F	12-16/Spare	11-16/Spare	11-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (48/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-127	HDD127-00	0F/20	12-01	11-01	11-01
	HDD127-01	0F/21	12-02	11-02	
	HDD127-02	0F/22	12-03	11-03	11-03
	HDD127-03	0F/23	12-04	11-04	
	HDD127-04	0F/24	12-05	11-05	11-05
	HDD127-05	0F/25	12-06	11-06	
	HDD127-06	0F/26	12-07	11-07	11-07
	HDD127-07	0F/27	12-08	11-08	
	HDD127-08	0F/28	12-09	11-09	11-09
	HDD127-09	0F/29	12-10	11-10	
	HDD127-0A	0F/2A	12-11	11-11	11-11
	HDD127-0B	0F/2B	12-12	11-12	
	HDD127-0C	0F/2C	12-13	11-13	11-13
	HDD127-0D	0F/2D	12-14	11-14	
	HDD127-0E	0F/2E	12-15	11-15	11-15
	HDD127-0F	0F/2F	12-16/Spare	11-16/Spare	11-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (49/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-030	HDD030-00	00/30	13-01	13-01	13-01
	HDD030-01	00/31	13-02	13-02	
	HDD030-02	00/32	13-03	13-03	13-03
	HDD030-03	00/33	13-04	13-04	
	HDD030-04	00/34	13-05	13-05	13-05
	HDD030-05	00/35	13-06	13-06	
	HDD030-06	00/36	13-07	13-07	13-07
	HDD030-07	00/37	13-08	13-08	
	HDD030-08	00/38	13-09	13-09	13-09
	HDD030-09	00/39	13-10	13-10	
	HDD030-0A	00/3A	13-11	13-11	13-11
	HDD030-0B	00/3B	13-12	13-12	
	HDD030-0C	00/3C	13-13	13-13	13-13
	HDD030-0D	00/3D	13-14	13-14	
	HDD030-0E	00/3E	13-15	13-15	13-15
	HDD030-0F	00/3F	13-16/Spare	13-16/Spare	13-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (50/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-031	HDD031-00	01/30	13-01	13-01	13-01
	HDD031-01	01/31	13-02	13-02	
	HDD031-02	01/32	13-03	13-03	13-03
	HDD031-03	01/33	13-04	13-04	
	HDD031-04	01/34	13-05	13-05	13-05
	HDD031-05	01/35	13-06	13-06	
	HDD031-06	01/36	13-07	13-07	13-07
	HDD031-07	01/37	13-08	13-08	
	HDD031-08	01/38	13-09	13-09	13-09
	HDD031-09	01/39	13-10	13-10	
	HDD031-0A	01/3A	13-11	13-11	13-11
	HDD031-0B	01/3B	13-12	13-12	
	HDD031-0C	01/3C	13-13	13-13	13-13
	HDD031-0D	01/3D	13-14	13-14	
	HDD031-0E	01/3E	13-15	13-15	13-15
	HDD031-0F	01/3F	13-16/Spare	13-16/Spare	13-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (51/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-032	HDD032-00	02/30	13-01	13-01	13-01
	HDD032-01	02/31	13-02	13-02	
	HDD032-02	02/32	13-03	13-03	13-03
	HDD032-03	02/33	13-04	13-04	
	HDD032-04	02/34	13-05	13-05	13-05
	HDD032-05	02/35	13-06	13-06	
	HDD032-06	02/36	13-07	13-07	13-07
	HDD032-07	02/37	13-08	13-08	
	HDD032-08	02/38	13-09	13-09	13-09
	HDD032-09	02/39	13-10	13-10	
	HDD032-0A	02/3A	13-11	13-11	13-11
	HDD032-0B	02/3B	13-12	13-12	
	HDD032-0C	02/3C	13-13	13-13	13-13
	HDD032-0D	02/3D	13-14	13-14	
	HDD032-0E	02/3E	13-15	13-15	13-15
	HDD032-0F	02/3F	13-16/Spare	13-16/Spare	13-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (52/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-033	HDD033-00	03/30	13-01	13-01	13-01
	HDD033-01	03/31	13-02	13-02	
	HDD033-02	03/32	13-03	13-03	13-03
	HDD033-03	03/33	13-04	13-04	
	HDD033-04	03/34	13-05	13-05	13-05
	HDD033-05	03/35	13-06	13-06	
	HDD033-06	03/36	13-07	13-07	13-07
	HDD033-07	03/37	13-08	13-08	
	HDD033-08	03/38	13-09	13-09	13-09
	HDD033-09	03/39	13-10	13-10	
	HDD033-0A	03/3A	13-11	13-11	13-11
	HDD033-0B	03/3B	13-12	13-12	
	HDD033-0C	03/3C	13-13	13-13	13-13
	HDD033-0D	03/3D	13-14	13-14	
	HDD033-0E	03/3E	13-15	13-15	13-15
	HDD033-0F	03/3F	13-16/Spare	13-16/Spare	13-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (53/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-034	HDD034-00	04/30	14-01	13-01	13-01
	HDD034-01	04/31	14-02	13-02	
	HDD034-02	04/32	14-03	13-03	13-03
	HDD034-03	04/33	14-04	13-04	
	HDD034-04	04/34	14-05	13-05	13-05
	HDD034-05	04/35	14-06	13-06	
	HDD034-06	04/36	14-07	13-07	13-07
	HDD034-07	04/37	14-08	13-08	
	HDD034-08	04/38	14-09	13-09	13-09
	HDD034-09	04/39	14-10	13-10	
	HDD034-0A	04/3A	14-11	13-11	13-11
	HDD034-0B	04/3B	14-12	13-12	
	HDD034-0C	04/3C	14-13	13-13	13-13
	HDD034-0D	04/3D	14-14	13-14	
	HDD034-0E	04/3E	14-15	13-15	13-15
	HDD034-0F	04/3F	14-16/Spare	13-16/Spare	13-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (54/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-035	HDD035-00	05/30	14-01	13-01	13-01
	HDD035-01	05/31	14-02	13-02	
	HDD035-02	05/32	14-03	13-03	13-03
	HDD035-03	05/33	14-04	13-04	
	HDD035-04	05/34	14-05	13-05	13-05
	HDD035-05	05/35	14-06	13-06	
	HDD035-06	05/36	14-07	13-07	13-07
	HDD035-07	05/37	14-08	13-08	
	HDD035-08	05/38	14-09	13-09	13-09
	HDD035-09	05/39	14-10	13-10	
	HDD035-0A	05/3A	14-11	13-11	13-11
	HDD035-0B	05/3B	14-12	13-12	
	HDD035-0C	05/3C	14-13	13-13	13-13
	HDD035-0D	05/3D	14-14	13-14	
	HDD035-0E	05/3E	14-15	13-15	13-15
	HDD035-0F	05/3F	14-16/Spare	13-16/Spare	13-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (55/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-036	HDD036-00	06/30	14-01	13-01	13-01
	HDD036-01	06/31	14-02	13-02	
	HDD036-02	06/32	14-03	13-03	13-03
	HDD036-03	06/33	14-04	13-04	
	HDD036-04	06/34	14-05	13-05	13-05
	HDD036-05	06/35	14-06	13-06	
	HDD036-06	06/36	14-07	13-07	13-07
	HDD036-07	06/37	14-08	13-08	
	HDD036-08	06/38	14-09	13-09	13-09
	HDD036-09	06/39	14-10	13-10	
	HDD036-0A	06/3A	14-11	13-11	13-11
	HDD036-0B	06/3B	14-12	13-12	
	HDD036-0C	06/3C	14-13	13-13	13-13
	HDD036-0D	06/3D	14-14	13-14	
	HDD036-0E	06/3E	14-15	13-15	13-15
	HDD036-0F	06/3F	14-16/Spare	13-16/Spare	13-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (56/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-037	HDD037-00	07/30	14-01	13-01	13-01
	HDD037-01	07/31	14-02	13-02	
	HDD037-02	07/32	14-03	13-03	13-03
	HDD037-03	07/33	14-04	13-04	
	HDD037-04	07/34	14-05	13-05	13-05
	HDD037-05	07/35	14-06	13-06	
	HDD037-06	07/36	14-07	13-07	13-07
	HDD037-07	07/37	14-08	13-08	
	HDD037-08	07/38	14-09	13-09	13-09
	HDD037-09	07/39	14-10	13-10	
	HDD037-0A	07/3A	14-11	13-11	13-11
	HDD037-0B	07/3B	14-12	13-12	
	HDD037-0C	07/3C	14-13	13-13	13-13
	HDD037-0D	07/3D	14-14	13-14	
	HDD037-0E	07/3E	14-15	13-15	13-15
	HDD037-0F	07/3F	14-16/Spare	13-16/Spare	13-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (57/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-130	HDD130-00	08/30	15-01	15-01	15-01
	HDD130-01	08/31	15-02	15-02	
	HDD130-02	08/32	15-03	15-03	15-03
	HDD130-03	08/33	15-04	15-04	
	HDD130-04	08/34	15-05	15-05	15-05
	HDD130-05	08/35	15-06	15-06	
	HDD130-06	08/36	15-07	15-07	15-07
	HDD130-07	08/37	15-08	15-08	
	HDD130-08	08/38	15-09	15-09	15-09
	HDD130-09	08/39	15-10	15-10	
	HDD130-0A	08/3A	15-11	15-11	15-11
	HDD130-0B	08/3B	15-12	15-12	
	HDD130-0C	08/3C	15-13	15-13	15-13
	HDD130-0D	08/3D	15-14	15-14	
	HDD130-0E	08/3E	15-15	15-15	15-15
	HDD130-0F	08/3F	15-16/Spare	15-16/Spare	15-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (58/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-131	HDD131-00	09/30	15-01	15-01	15-01
	HDD131-01	09/31	15-02	15-02	
	HDD131-02	09/32	15-03	15-03	15-03
	HDD131-03	09/33	15-04	15-04	
	HDD131-04	09/34	15-05	15-05	15-05
	HDD131-05	09/35	15-06	15-06	
	HDD131-06	09/36	15-07	15-07	15-07
	HDD131-07	09/37	15-08	15-08	
	HDD131-08	09/38	15-09	15-09	15-09
	HDD131-09	09/39	15-10	15-10	
	HDD131-0A	09/3A	15-11	15-11	15-11
	HDD131-0B	09/3B	15-12	15-12	
	HDD131-0C	09/3C	15-13	15-13	15-13
	HDD131-0D	09/3D	15-14	15-14	
	HDD131-0E	09/3E	15-15	15-15	15-15
	HDD131-0F	09/3F	15-16/Spare	15-16/Spare	15-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (59/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-132	HDD132-00	0A/30	15-01	15-01	15-01
	HDD132-01	0A/31	15-02	15-02	
	HDD132-02	0A/32	15-03	15-03	15-03
	HDD132-03	0A/33	15-04	15-04	
	HDD132-04	0A/34	15-05	15-05	15-05
	HDD132-05	0A/35	15-06	15-06	
	HDD132-06	0A/36	15-07	15-07	15-07
	HDD132-07	0A/37	15-08	15-08	
	HDD132-08	0A/38	15-09	15-09	15-09
	HDD132-09	0A/39	15-10	15-10	
	HDD132-0A	0A/3A	15-11	15-11	15-11
	HDD132-0B	0A/3B	15-12	15-12	
	HDD132-0C	0A/3C	15-13	15-13	15-13
	HDD132-0D	0A/3D	15-14	15-14	
	HDD132-0E	0A/3E	15-15	15-15	15-15
	HDD132-0F	0A/3F	15-16/Spare	15-16/Spare	15-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (60/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-133	HDD133-00	0B/30	15-01	15-01	15-01
	HDD133-01	0B/31	15-02	15-02	
	HDD133-02	0B/32	15-03	15-03	15-03
	HDD133-03	0B/33	15-04	15-04	
	HDD133-04	0B/34	15-05	15-05	15-05
	HDD133-05	0B/35	15-06	15-06	
	HDD133-06	0B/36	15-07	15-07	15-07
	HDD133-07	0B/37	15-08	15-08	
	HDD133-08	0B/38	15-09	15-09	15-09
	HDD133-09	0B/39	15-10	15-10	
	HDD133-0A	0B/3A	15-11	15-11	15-11
	HDD133-0B	0B/3B	15-12	15-12	
	HDD133-0C	0B/3C	15-13	15-13	15-13
	HDD133-0D	0B/3D	15-14	15-14	
	HDD133-0E	0B/3E	15-15	15-15	15-15
	HDD133-0F	0B/3F	15-16/Spare	15-16/Spare	15-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (61/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-134	HDD134-00	0C/30	16-01	15-01	15-01
	HDD134-01	0C/31	16-02	15-02	
	HDD134-02	0C/32	16-03	15-03	15-03
	HDD134-03	0C/33	16-04	15-04	
	HDD134-04	0C/34	16-05	15-05	15-05
	HDD134-05	0C/35	16-06	15-06	
	HDD134-06	0C/36	16-07	15-07	15-07
	HDD134-07	0C/37	16-08	15-08	
	HDD134-08	0C/38	16-09	15-09	15-09
	HDD134-09	0C/39	16-10	15-10	
	HDD134-0A	0C/3A	16-11	15-11	15-11
	HDD134-0B	0C/3B	16-12	15-12	
	HDD134-0C	0C/3C	16-13	15-13	15-13
	HDD134-0D	0C/3D	16-14	15-14	
	HDD134-0E	0C/3E	16-15	15-15	15-15
	HDD134-0F	0C/3F	16-16/Spare	15-16/Spare	15-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (62/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-135	HDD135-00	0D/30	16-01	15-01	15-01
	HDD135-01	0D/31	16-02	15-02	
	HDD135-02	0D/32	16-03	15-03	15-03
	HDD135-03	0D/33	16-04	15-04	
	HDD135-04	0D/34	16-05	15-05	15-05
	HDD135-05	0D/35	16-06	15-06	
	HDD135-06	0D/36	16-07	15-07	15-07
	HDD135-07	0D/37	16-08	15-08	
	HDD135-08	0D/38	16-09	15-09	15-09
	HDD135-09	0D/39	16-10	15-10	
	HDD135-0A	0D/3A	16-11	15-11	15-11
	HDD135-0B	0D/3B	16-12	15-12	
	HDD135-0C	0D/3C	16-13	15-13	15-13
	HDD135-0D	0D/3D	16-14	15-14	
	HDD135-0E	0D/3E	16-15	15-15	15-15
	HDD135-0F	0D/3F	16-16/Spare	15-16/Spare	15-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (63/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-136	HDD136-00	0E/30	16-01	15-01	15-01
	HDD136-01	0E/31	16-02	15-02	
	HDD136-02	0E/32	16-03	15-03	15-03
	HDD136-03	0E/33	16-04	15-04	
	HDD136-04	0E/34	16-05	15-05	15-05
	HDD136-05	0E/35	16-06	15-06	
	HDD136-06	0E/36	16-07	15-07	15-07
	HDD136-07	0E/37	16-08	15-08	
	HDD136-08	0E/38	16-09	15-09	15-09
	HDD136-09	0E/39	16-10	15-10	
	HDD136-0A	0E/3A	16-11	15-11	15-11
	HDD136-0B	0E/3B	16-12	15-12	
	HDD136-0C	0E/3C	16-13	15-13	15-13
	HDD136-0D	0E/3D	16-14	15-14	
	HDD136-0E	0E/3E	16-15	15-15	15-15
	HDD136-0F	0E/3F	16-16/Spare	15-16/Spare	15-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (64/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-137	HDD137-00	0F/30	16-01	15-01	15-01
	HDD137-01	0F/31	16-02	15-02	
	HDD137-02	0F/32	16-03	15-03	15-03
	HDD137-03	0F/33	16-04	15-04	
	HDD137-04	0F/34	16-05	15-05	15-05
	HDD137-05	0F/35	16-06	15-06	
	HDD137-06	0F/36	16-07	15-07	15-07
	HDD137-07	0F/37	16-08	15-08	
	HDD137-08	0F/38	16-09	15-09	15-09
	HDD137-09	0F/39	16-10	15-10	
	HDD137-0A	0F/3A	16-11	15-11	15-11
	HDD137-0B	0F/3B	16-12	15-12	
	HDD137-0C	0F/3C	16-13	15-13	15-13
	HDD137-0D	0F/3D	16-14	15-14	
	HDD137-0E	0F/3E	16-15	15-15	15-15
	HDD137-0F	0F/3F	16-16/Spare	15-16/Spare	15-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (65/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-040	HDD040-00	00/40	17-01	17-01	17-01
	HDD040-01	00/41	17-02	17-02	
	HDD040-02	00/42	17-03	17-03	17-03
	HDD040-03	00/43	17-04	17-04	
	HDD040-04	00/44	17-05	17-05	17-05
	HDD040-05	00/45	17-06	17-06	
	HDD040-06	00/46	17-07	17-07	17-07
	HDD040-07	00/47	17-08	17-08	
	HDD040-08	00/48	17-09	17-09	17-09
	HDD040-09	00/49	17-10	17-10	
	HDD040-0A	00/4A	17-11	17-11	17-11
	HDD040-0B	00/4B	17-12	17-12	
	HDD040-0C	00/4C	17-13	17-13	17-13
	HDD040-0D	00/4D	17-14	17-14	
	HDD040-0E	00/4E	17-15	17-15	17-15
	HDD040-0F	00/4F	17-16/Spare	17-16/Spare	17-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (66/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-041	HDD041-00	01/40	17-01	17-01	17-01
	HDD041-01	01/41	17-02	17-02	
	HDD041-02	01/42	17-03	17-03	17-03
	HDD041-03	01/43	17-04	17-04	
	HDD041-04	01/44	17-05	17-05	17-05
	HDD041-05	01/45	17-06	17-06	
	HDD041-06	01/46	17-07	17-07	17-07
	HDD041-07	01/47	17-08	17-08	
	HDD041-08	01/48	17-09	17-09	17-09
	HDD041-09	01/49	17-10	17-10	
	HDD041-0A	01/4A	17-11	17-11	17-11
	HDD041-0B	01/4B	17-12	17-12	
	HDD041-0C	01/4C	17-13	17-13	17-13
	HDD041-0D	01/4D	17-14	17-14	
	HDD041-0E	01/4E	17-15	17-15	17-15
	HDD041-0F	01/4F	17-16/Spare	17-16/Spare	17-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (67/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-042	HDD042-00	02/40	17-01	17-01	17-01
	HDD042-01	02/41	17-02	17-02	
	HDD042-02	02/42	17-03	17-03	17-03
	HDD042-03	02/43	17-04	17-04	
	HDD042-04	02/44	17-05	17-05	17-05
	HDD042-05	02/45	17-06	17-06	
	HDD042-06	02/46	17-07	17-07	17-07
	HDD042-07	02/47	17-08	17-08	
	HDD042-08	02/48	17-09	17-09	17-09
	HDD042-09	02/49	17-10	17-10	
	HDD042-0A	02/4A	17-11	17-11	17-11
	HDD042-0B	02/4B	17-12	17-12	
	HDD042-0C	02/4C	17-13	17-13	17-13
	HDD042-0D	02/4D	17-14	17-14	
	HDD042-0E	02/4E	17-15	17-15	17-15
	HDD042-0F	02/4F	17-16/Spare	17-16/Spare	17-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (68/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-043	HDD043-00	03/40	17-01	17-01	17-01
	HDD043-01	03/41	17-02	17-02	
	HDD043-02	03/42	17-03	17-03	17-03
	HDD043-03	03/43	17-04	17-04	
	HDD043-04	03/44	17-05	17-05	17-05
	HDD043-05	03/45	17-06	17-06	
	HDD043-06	03/46	17-07	17-07	17-07
	HDD043-07	03/47	17-08	17-08	
	HDD043-08	03/48	17-09	17-09	17-09
	HDD043-09	03/49	17-10	17-10	
	HDD043-0A	03/4A	17-11	17-11	17-11
	HDD043-0B	03/4B	17-12	17-12	
	HDD043-0C	03/4C	17-13	17-13	17-13
	HDD043-0D	03/4D	17-14	17-14	
	HDD043-0E	03/4E	17-15	17-15	17-15
	HDD043-0F	03/4F	17-16/Spare	17-16/Spare	17-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (69/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-044	HDD044-00	04/40	18-01	17-01	17-01
	HDD044-01	04/41	18-02	17-02	
	HDD044-02	04/42	18-03	17-03	17-03
	HDD044-03	04/43	18-04	17-04	
	HDD044-04	04/44	18-05	17-05	17-05
	HDD044-05	04/45	18-06	17-06	
	HDD044-06	04/46	18-07	17-07	17-07
	HDD044-07	04/47	18-08	17-08	
	HDD044-08	04/48	18-09	17-09	17-09
	HDD044-09	04/49	18-10	17-10	
	HDD044-0A	04/4A	18-11	17-11	17-11
	HDD044-0B	04/4B	18-12	17-12	
	HDD044-0C	04/4C	18-13	17-13	17-13
	HDD044-0D	04/4D	18-14	17-14	
	HDD044-0E	04/4E	18-15	17-15	17-15
	HDD044-0F	04/4F	18-16/Spare	17-16/Spare	17-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (70/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-045	HDD045-00	05/40	18-01	17-01	17-01
	HDD045-01	05/41	18-02	17-02	
	HDD045-02	05/42	18-03	17-03	17-03
	HDD045-03	05/43	18-04	17-04	
	HDD045-04	05/44	18-05	17-05	17-05
	HDD045-05	05/45	18-06	17-06	
	HDD045-06	05/46	18-07	17-07	17-07
	HDD045-07	05/47	18-08	17-08	
	HDD045-08	05/48	18-09	17-09	17-09
	HDD045-09	05/49	18-10	17-10	
	HDD045-0A	05/4A	18-11	17-11	17-11
	HDD045-0B	05/4B	18-12	17-12	
	HDD045-0C	05/4C	18-13	17-13	17-13
	HDD045-0D	05/4D	18-14	17-14	
	HDD045-0E	05/4E	18-15	17-15	17-15
	HDD045-0F	05/4F	18-16/Spare	17-16/Spare	17-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (71/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-046	HDD046-00	06/40	18-01	17-01	17-01
	HDD046-01	06/41	18-02	17-02	
	HDD046-02	06/42	18-03	17-03	17-03
	HDD046-03	06/43	18-04	17-04	
	HDD046-04	06/44	18-05	17-05	17-05
	HDD046-05	06/45	18-06	17-06	
	HDD046-06	06/46	18-07	17-07	17-07
	HDD046-07	06/47	18-08	17-08	
	HDD046-08	06/48	18-09	17-09	17-09
	HDD046-09	06/49	18-10	17-10	
	HDD046-0A	06/4A	18-11	17-11	17-11
	HDD046-0B	06/4B	18-12	17-12	
	HDD046-0C	06/4C	18-13	17-13	17-13
	HDD046-0D	06/4D	18-14	17-14	
	HDD046-0E	06/4E	18-15	17-15	17-15
	HDD046-0F	06/4F	18-16/Spare	17-16/Spare	17-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (72/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-047	HDD047-00	07/40	18-01	17-01	17-01
	HDD047-01	07/41	18-02	17-02	
	HDD047-02	07/42	18-03	17-03	17-03
	HDD047-03	07/43	18-04	17-04	
	HDD047-04	07/44	18-05	17-05	17-05
	HDD047-05	07/45	18-06	17-06	
	HDD047-06	07/46	18-07	17-07	17-07
	HDD047-07	07/47	18-08	17-08	
	HDD047-08	07/48	18-09	17-09	17-09
	HDD047-09	07/49	18-10	17-10	
	HDD047-0A	07/4A	18-11	17-11	17-11
	HDD047-0B	07/4B	18-12	17-12	
	HDD047-0C	07/4C	18-13	17-13	17-13
	HDD047-0D	07/4D	18-14	17-14	
	HDD047-0E	07/4E	18-15	17-15	17-15
	HDD047-0F	07/4F	18-16/Spare	17-16/Spare	17-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (73/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-140	HDD140-00	08/40	19-01	19-01	19-01
	HDD140-01	08/41	19-02	19-02	
	HDD140-02	08/42	19-03	19-03	19-03
	HDD140-03	08/43	19-04	19-04	
	HDD140-04	08/44	19-05	19-05	19-05
	HDD140-05	08/45	19-06	19-06	
	HDD140-06	08/46	19-07	19-07	19-07
	HDD140-07	08/47	19-08	19-08	
	HDD140-08	08/48	19-09	19-09	19-09
	HDD140-09	08/49	19-10	19-10	
	HDD140-0A	08/4A	19-11	19-11	19-11
	HDD140-0B	08/4B	19-12	19-12	
	HDD140-0C	08/4C	19-13	19-13	19-13
	HDD140-0D	08/4D	19-14	19-14	
	HDD140-0E	08/4E	19-15	19-15	19-15
	HDD140-0F	08/4F	19-16/Spare	19-16/Spare	19-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (74/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-141	HDD141-00	09/40	19-01	19-01	19-01
	HDD141-01	09/41	19-02	19-02	
	HDD141-02	09/42	19-03	19-03	19-03
	HDD141-03	09/43	19-04	19-04	
	HDD141-04	09/44	19-05	19-05	19-05
	HDD141-05	09/45	19-06	19-06	
	HDD141-06	09/46	19-07	19-07	19-07
	HDD141-07	09/47	19-08	19-08	
	HDD141-08	09/48	19-09	19-09	19-09
	HDD141-09	09/49	19-10	19-10	
	HDD141-0A	09/4A	19-11	19-11	19-11
	HDD141-0B	09/4B	19-12	19-12	
	HDD141-0C	09/4C	19-13	19-13	19-13
	HDD141-0D	09/4D	19-14	19-14	
	HDD141-0E	09/4E	19-15	19-15	19-15
	HDD141-0F	09/4F	19-16/Spare	19-16/Spare	19-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (75/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-142	HDD142-00	0A/40	19-01	19-01	19-01
	HDD142-01	0A/41	19-02	19-02	
	HDD142-02	0A/42	19-03	19-03	19-03
	HDD142-03	0A/43	19-04	19-04	
	HDD142-04	0A/44	19-05	19-05	19-05
	HDD142-05	0A/45	19-06	19-06	
	HDD142-06	0A/46	19-07	19-07	19-07
	HDD142-07	0A/47	19-08	19-08	
	HDD142-08	0A/48	19-09	19-09	19-09
	HDD142-09	0A/49	19-10	19-10	
	HDD142-0A	0A/4A	19-11	19-11	19-11
	HDD142-0B	0A/4B	19-12	19-12	
	HDD142-0C	0A/4C	19-13	19-13	19-13
	HDD142-0D	0A/4D	19-14	19-14	
	HDD142-0E	0A/4E	19-15	19-15	19-15
	HDD142-0F	0A/4F	19-16/Spare	19-16/Spare	19-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (76/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-143	HDD143-00	0B/40	19-01	19-01	19-01
	HDD143-01	0B/41	19-02	19-02	
	HDD143-02	0B/42	19-03	19-03	19-03
	HDD143-03	0B/43	19-04	19-04	
	HDD143-04	0B/44	19-05	19-05	19-05
	HDD143-05	0B/45	19-06	19-06	
	HDD143-06	0B/46	19-07	19-07	19-07
	HDD143-07	0B/47	19-08	19-08	
	HDD143-08	0B/48	19-09	19-09	19-09
	HDD143-09	0B/49	19-10	19-10	
	HDD143-0A	0B/4A	19-11	19-11	19-11
	HDD143-0B	0B/4B	19-12	19-12	
	HDD143-0C	0B/4C	19-13	19-13	19-13
	HDD143-0D	0B/4D	19-14	19-14	
	HDD143-0E	0B/4E	19-15	19-15	19-15
	HDD143-0F	0B/4F	19-16/Spare	19-16/Spare	19-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (77/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-144	HDD144-00	0C/40	20-01	19-01	19-01
	HDD144-01	0C/41	20-02	19-02	
	HDD144-02	0C/42	20-03	19-03	19-03
	HDD144-03	0C/43	20-04	19-04	
	HDD144-04	0C/44	20-05	19-05	19-05
	HDD144-05	0C/45	20-06	19-06	
	HDD144-06	0C/46	20-07	19-07	19-07
	HDD144-07	0C/47	20-08	19-08	
	HDD144-08	0C/48	20-09	19-09	19-09
	HDD144-09	0C/49	20-10	19-10	
	HDD144-0A	0C/4A	20-11	19-11	19-11
	HDD144-0B	0C/4B	20-12	19-12	
	HDD144-0C	0C/4C	20-13	19-13	19-13
	HDD144-0D	0C/4D	20-14	19-14	
	HDD144-0E	0C/4E	20-15	19-15	19-15
	HDD144-0F	0C/4F	20-16/Spare	19-16/Spare	19-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (78/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-145	HDD145-00	0D/40	20-01	19-01	19-01
	HDD145-01	0D/41	20-02	19-02	
	HDD145-02	0D/42	20-03	19-03	19-03
	HDD145-03	0D/43	20-04	19-04	
	HDD145-04	0D/44	20-05	19-05	19-05
	HDD145-05	0D/45	20-06	19-06	
	HDD145-06	0D/46	20-07	19-07	19-07
	HDD145-07	0D/47	20-08	19-08	
	HDD145-08	0D/48	20-09	19-09	19-09
	HDD145-09	0D/49	20-10	19-10	
	HDD145-0A	0D/4A	20-11	19-11	19-11
	HDD145-0B	0D/4B	20-12	19-12	
	HDD145-0C	0D/4C	20-13	19-13	19-13
	HDD145-0D	0D/4D	20-14	19-14	
	HDD145-0E	0D/4E	20-15	19-15	19-15
	HDD145-0F	0D/4F	20-16/Spare	19-16/Spare	19-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (79/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-146	HDD146-00	0E/40	20-01	19-01	19-01
	HDD146-01	0E/41	20-02	19-02	
	HDD146-02	0E/42	20-03	19-03	19-03
	HDD146-03	0E/43	20-04	19-04	
	HDD146-04	0E/44	20-05	19-05	19-05
	HDD146-05	0E/45	20-06	19-06	
	HDD146-06	0E/46	20-07	19-07	19-07
	HDD146-07	0E/47	20-08	19-08	
	HDD146-08	0E/48	20-09	19-09	19-09
	HDD146-09	0E/49	20-10	19-10	
	HDD146-0A	0E/4A	20-11	19-11	19-11
	HDD146-0B	0E/4B	20-12	19-12	
	HDD146-0C	0E/4C	20-13	19-13	19-13
	HDD146-0D	0E/4D	20-14	19-14	
	HDD146-0E	0E/4E	20-15	19-15	19-15
	HDD146-0F	0E/4F	20-16/Spare	19-16/Spare	19-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (80/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-147	HDD147-00	0F/40	20-01	19-01	19-01
	HDD147-01	0F/41	20-02	19-02	
	HDD147-02	0F/42	20-03	19-03	19-03
	HDD147-03	0F/43	20-04	19-04	
	HDD147-04	0F/44	20-05	19-05	19-05
	HDD147-05	0F/45	20-06	19-06	
	HDD147-06	0F/46	20-07	19-07	19-07
	HDD147-07	0F/47	20-08	19-08	
	HDD147-08	0F/48	20-09	19-09	19-09
	HDD147-09	0F/49	20-10	19-10	
	HDD147-0A	0F/4A	20-11	19-11	19-11
	HDD147-0B	0F/4B	20-12	19-12	
	HDD147-0C	0F/4C	20-13	19-13	19-13
	HDD147-0D	0F/4D	20-14	19-14	
	HDD147-0E	0F/4E	20-15	19-15	19-15
	HDD147-0F	0F/4F	20-16/Spare	19-16/Spare	19-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (81/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-050	HDD050-00	00/50	21-01	21-01	21-01
	HDD050-01	00/51	21-02	21-02	
	HDD050-02	00/52	21-03	21-03	21-03
	HDD050-03	00/53	21-04	21-04	
	HDD050-04	00/54	21-05	21-05	21-05
	HDD050-05	00/55	21-06	21-06	
	HDD050-06	00/56	21-07	21-07	21-07
	HDD050-07	00/57	21-08	21-08	
	HDD050-08	00/58	21-09	21-09	21-09
	HDD050-09	00/59	21-10	21-10	
	HDD050-0A	00/5A	21-11	21-11	21-11
	HDD050-0B	00/5B	21-12	21-12	
	HDD050-0C	00/5C	21-13	21-13	21-13
	HDD050-0D	00/5D	21-14	21-14	
	HDD050-0E	00/5E	21-15	21-15	21-15
	HDD050-0F	00/5F	21-16/Spare	21-16/Spare	21-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (82/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-051	HDD051-00	01/50	21-01	21-01	21-01
	HDD051-01	01/51	21-02	21-02	
	HDD051-02	01/52	21-03	21-03	21-03
	HDD051-03	01/53	21-04	21-04	
	HDD051-04	01/54	21-05	21-05	21-05
	HDD051-05	01/55	21-06	21-06	
	HDD051-06	01/56	21-07	21-07	21-07
	HDD051-07	01/57	21-08	21-08	
	HDD051-08	01/58	21-09	21-09	21-09
	HDD051-09	01/59	21-10	21-10	
	HDD051-0A	01/5A	21-11	21-11	21-11
	HDD051-0B	01/5B	21-12	21-12	
	HDD051-0C	01/5C	21-13	21-13	21-13
	HDD051-0D	01/5D	21-14	21-14	
	HDD051-0E	01/5E	21-15	21-15	21-15
	HDD051-0F	01/5F	21-16/Spare	21-16/Spare	21-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (83/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-052	HDD052-00	02/50	21-01	21-01	21-01
	HDD052-01	02/51	21-02	21-02	
	HDD052-02	02/52	21-03	21-03	21-03
	HDD052-03	02/53	21-04	21-04	
	HDD052-04	02/54	21-05	21-05	21-05
	HDD052-05	02/55	21-06	21-06	
	HDD052-06	02/56	21-07	21-07	21-07
	HDD052-07	02/57	21-08	21-08	
	HDD052-08	02/58	21-09	21-09	21-09
	HDD052-09	02/59	21-10	21-10	
	HDD052-0A	02/5A	21-11	21-11	21-11
	HDD052-0B	02/5B	21-12	21-12	
	HDD052-0C	02/5C	21-13	21-13	21-13
	HDD052-0D	02/5D	21-14	21-14	
	HDD052-0E	02/5E	21-15	21-15	21-15
	HDD052-0F	02/5F	21-16/Spare	21-16/Spare	21-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (84/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-053	HDD053-00	03/50	21-01	21-01	21-01
	HDD053-01	03/51	21-02	21-02	
	HDD053-02	03/52	21-03	21-03	21-03
	HDD053-03	03/53	21-04	21-04	
	HDD053-04	03/54	21-05	21-05	21-05
	HDD053-05	03/55	21-06	21-06	
	HDD053-06	03/56	21-07	21-07	21-07
	HDD053-07	03/57	21-08	21-08	
	HDD053-08	03/58	21-09	21-09	21-09
	HDD053-09	03/59	21-10	21-10	
	HDD053-0A	03/5A	21-11	21-11	21-11
	HDD053-0B	03/5B	21-12	21-12	
	HDD053-0C	03/5C	21-13	21-13	21-13
	HDD053-0D	03/5D	21-14	21-14	
	HDD053-0E	03/5E	21-15	21-15	21-15
	HDD053-0F	03/5F	21-16/Spare	21-16/Spare	21-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (85/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-054	HDD054-00	04/50	22-01	21-01	21-01
	HDD054-01	04/51	22-02	21-02	
	HDD054-02	04/52	22-03	21-03	21-03
	HDD054-03	04/53	22-04	21-04	
	HDD054-04	04/54	22-05	21-05	21-05
	HDD054-05	04/55	22-06	21-06	
	HDD054-06	04/56	22-07	21-07	21-07
	HDD054-07	04/57	22-08	21-08	
	HDD054-08	04/58	22-09	21-09	21-09
	HDD054-09	04/59	22-10	21-10	
	HDD054-0A	04/5A	22-11	21-11	21-11
	HDD054-0B	04/5B	22-12	21-12	
	HDD054-0C	04/5C	22-13	21-13	21-13
	HDD054-0D	04/5D	22-14	21-14	
	HDD054-0E	04/5E	22-15	21-15	21-15
	HDD054-0F	04/5F	22-16/Spare	21-16/Spare	21-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (86/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-055	HDD055-00	05/50	22-01	21-01	21-01
	HDD055-01	05/51	22-02	21-02	
	HDD055-02	05/52	22-03	21-03	21-03
	HDD055-03	05/53	22-04	21-04	
	HDD055-04	05/54	22-05	21-05	21-05
	HDD055-05	05/55	22-06	21-06	
	HDD055-06	05/56	22-07	21-07	21-07
	HDD055-07	05/57	22-08	21-08	
	HDD055-08	05/58	22-09	21-09	21-09
	HDD055-09	05/59	22-10	21-10	
	HDD055-0A	05/5A	22-11	21-11	21-11
	HDD055-0B	05/5B	22-12	21-12	
	HDD055-0C	05/5C	22-13	21-13	21-13
	HDD055-0D	05/5D	22-14	21-14	
	HDD055-0E	05/5E	22-15	21-15	21-15
	HDD055-0F	05/5F	22-16/Spare	21-16/Spare	21-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (87/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-056	HDD056-00	06/50	22-01	21-01	21-01
	HDD056-01	06/51	22-02	21-02	
	HDD056-02	06/52	22-03	21-03	21-03
	HDD056-03	06/53	22-04	21-04	
	HDD056-04	06/54	22-05	21-05	21-05
	HDD056-05	06/55	22-06	21-06	
	HDD056-06	06/56	22-07	21-07	21-07
	HDD056-07	06/57	22-08	21-08	
	HDD056-08	06/58	22-09	21-09	21-09
	HDD056-09	06/59	22-10	21-10	
	HDD056-0A	06/5A	22-11	21-11	21-11
	HDD056-0B	06/5B	22-12	21-12	
	HDD056-0C	06/5C	22-13	21-13	21-13
	HDD056-0D	06/5D	22-14	21-14	
	HDD056-0E	06/5E	22-15	21-15	21-15
	HDD056-0F	06/5F	22-16/Spare	21-16/Spare	21-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (88/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-057	HDD057-00	07/50	22-01	21-01	21-01
	HDD057-01	07/51	22-02	21-02	
	HDD057-02	07/52	22-03	21-03	21-03
	HDD057-03	07/53	22-04	21-04	
	HDD057-04	07/54	22-05	21-05	21-05
	HDD057-05	07/55	22-06	21-06	
	HDD057-06	07/56	22-07	21-07	21-07
	HDD057-07	07/57	22-08	21-08	
	HDD057-08	07/58	22-09	21-09	21-09
	HDD057-09	07/59	22-10	21-10	
	HDD057-0A	07/5A	22-11	21-11	21-11
	HDD057-0B	07/5B	22-12	21-12	
	HDD057-0C	07/5C	22-13	21-13	21-13
	HDD057-0D	07/5D	22-14	21-14	
	HDD057-0E	07/5E	22-15	21-15	21-15
	HDD057-0F	07/5F	22-16/Spare	21-16/Spare	21-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (89/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-150	HDD150-00	08/50	23-01	23-01	23-01
	HDD150-01	08/51	23-02	23-02	
	HDD150-02	08/52	23-03	23-03	23-03
	HDD150-03	08/53	23-04	23-04	
	HDD150-04	08/54	23-05	23-05	23-05
	HDD150-05	08/55	23-06	23-06	
	HDD150-06	08/56	23-07	23-07	23-07
	HDD150-07	08/57	23-08	23-08	
	HDD150-08	08/58	23-09	23-09	23-09
	HDD150-09	08/59	23-10	23-10	
	HDD150-0A	08/5A	23-11	23-11	23-11
	HDD150-0B	08/5B	23-12	23-12	
	HDD150-0C	08/5C	23-13	23-13	23-13
	HDD150-0D	08/5D	23-14	23-14	
	HDD150-0E	08/5E	23-15	23-15	23-15
	HDD150-0F	08/5F	23-16/Spare	23-16/Spare	23-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (90/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-151	HDD151-00	09/50	23-01	23-01	23-01
	HDD151-01	09/51	23-02	23-02	
	HDD151-02	09/52	23-03	23-03	23-03
	HDD151-03	09/53	23-04	23-04	
	HDD151-04	09/54	23-05	23-05	23-05
	HDD151-05	09/55	23-06	23-06	
	HDD151-06	09/56	23-07	23-07	23-07
	HDD151-07	09/57	23-08	23-08	
	HDD151-08	09/58	23-09	23-09	23-09
	HDD151-09	09/59	23-10	23-10	
	HDD151-0A	09/5A	23-11	23-11	23-11
	HDD151-0B	09/5B	23-12	23-12	
	HDD151-0C	09/5C	23-13	23-13	23-13
	HDD151-0D	09/5D	23-14	23-14	
	HDD151-0E	09/5E	23-15	23-15	23-15
	HDD151-0F	09/5F	23-16/Spare	23-16/Spare	23-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (91/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-152	HDD152-00	0A/50	23-01	23-01	23-01
	HDD152-01	0A/51	23-02	23-02	
	HDD152-02	0A/52	23-03	23-03	23-03
	HDD152-03	0A/53	23-04	23-04	
	HDD152-04	0A/54	23-05	23-05	23-05
	HDD152-05	0A/55	23-06	23-06	
	HDD152-06	0A/56	23-07	23-07	23-07
	HDD152-07	0A/57	23-08	23-08	
	HDD152-08	0A/58	23-09	23-09	23-09
	HDD152-09	0A/59	23-10	23-10	
	HDD152-0A	0A/5A	23-11	23-11	23-11
	HDD152-0B	0A/5B	23-12	23-12	
	HDD152-0C	0A/5C	23-13	23-13	23-13
	HDD152-0D	0A/5D	23-14	23-14	
	HDD152-0E	0A/5E	23-15	23-15	23-15
	HDD152-0F	0A/5F	23-16/Spare	23-16/Spare	23-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (92/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-153	HDD153-00	0B/50	23-01	23-01	23-01
	HDD153-01	0B/51	23-02	23-02	
	HDD153-02	0B/52	23-03	23-03	23-03
	HDD153-03	0B/53	23-04	23-04	
	HDD153-04	0B/54	23-05	23-05	23-05
	HDD153-05	0B/55	23-06	23-06	
	HDD153-06	0B/56	23-07	23-07	23-07
	HDD153-07	0B/57	23-08	23-08	
	HDD153-08	0B/58	23-09	23-09	23-09
	HDD153-09	0B/59	23-10	23-10	
	HDD153-0A	0B/5A	23-11	23-11	23-11
	HDD153-0B	0B/5B	23-12	23-12	
	HDD153-0C	0B/5C	23-13	23-13	23-13
	HDD153-0D	0B/5D	23-14	23-14	
	HDD153-0E	0B/5E	23-15	23-15	23-15
	HDD153-0F	0B/5F	23-16/Spare	23-16/Spare	23-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (93/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-154	HDD154-00	0C/50	24-01	23-01	23-01
	HDD154-01	0C/51	24-02	23-02	
	HDD154-02	0C/52	24-03	23-03	23-03
	HDD154-03	0C/53	24-04	23-04	
	HDD154-04	0C/54	24-05	23-05	23-05
	HDD154-05	0C/55	24-06	23-06	
	HDD154-06	0C/56	24-07	23-07	23-07
	HDD154-07	0C/57	24-08	23-08	
	HDD154-08	0C/58	24-09	23-09	23-09
	HDD154-09	0C/59	24-10	23-10	
	HDD154-0A	0C/5A	24-11	23-11	23-11
	HDD154-0B	0C/5B	24-12	23-12	
	HDD154-0C	0C/5C	24-13	23-13	23-13
	HDD154-0D	0C/5D	24-14	23-14	
	HDD154-0E	0C/5E	24-15	23-15	23-15
	HDD154-0F	0C/5F	24-16/Spare	23-16/Spare	23-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (94/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-155	HDD155-00	0D/50	24-01	23-01	23-01
	HDD155-01	0D/51	24-02	23-02	
	HDD155-02	0D/52	24-03	23-03	23-03
	HDD155-03	0D/53	24-04	23-04	
	HDD155-04	0D/54	24-05	23-05	23-05
	HDD155-05	0D/55	24-06	23-06	
	HDD155-06	0D/56	24-07	23-07	23-07
	HDD155-07	0D/57	24-08	23-08	
	HDD155-08	0D/58	24-09	23-09	23-09
	HDD155-09	0D/59	24-10	23-10	
	HDD155-0A	0D/5A	24-11	23-11	23-11
	HDD155-0B	0D/5B	24-12	23-12	
	HDD155-0C	0D/5C	24-13	23-13	23-13
	HDD155-0D	0D/5D	24-14	23-14	
	HDD155-0E	0D/5E	24-15	23-15	23-15
	HDD155-0F	0D/5F	24-16/Spare	23-16/Spare	23-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (95/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-156	HDD156-00	0E/50	24-01	23-01	23-01
	HDD156-01	0E/51	24-02	23-02	
	HDD156-02	0E/52	24-03	23-03	23-03
	HDD156-03	0E/53	24-04	23-04	
	HDD156-04	0E/54	24-05	23-05	23-05
	HDD156-05	0E/55	24-06	23-06	
	HDD156-06	0E/56	24-07	23-07	23-07
	HDD156-07	0E/57	24-08	23-08	
	HDD156-08	0E/58	24-09	23-09	23-09
	HDD156-09	0E/59	24-10	23-10	
	HDD156-0A	0E/5A	24-11	23-11	23-11
	HDD156-0B	0E/5B	24-12	23-12	
	HDD156-0C	0E/5C	24-13	23-13	23-13
	HDD156-0D	0E/5D	24-14	23-14	
	HDD156-0E	0E/5E	24-15	23-15	23-15
	HDD156-0F	0E/5F	24-16/Spare	23-16/Spare	23-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (96/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-157	HDD157-00	0F/50	24-01	23-01	23-01
	HDD157-01	0F/51	24-02	23-02	
	HDD157-02	0F/52	24-03	23-03	23-03
	HDD157-03	0F/53	24-04	23-04	
	HDD157-04	0F/54	24-05	23-05	23-05
	HDD157-05	0F/55	24-06	23-06	
	HDD157-06	0F/56	24-07	23-07	23-07
	HDD157-07	0F/57	24-08	23-08	
	HDD157-08	0F/58	24-09	23-09	23-09
	HDD157-09	0F/59	24-10	23-10	
	HDD157-0A	0F/5A	24-11	23-11	23-11
	HDD157-0B	0F/5B	24-12	23-12	
	HDD157-0C	0F/5C	24-13	23-13	23-13
	HDD157-0D	0F/5D	24-14	23-14	
	HDD157-0E	0F/5E	24-15	23-15	23-15
	HDD157-0F	0F/5F	24-16/Spare	23-16/Spare	23-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (97/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-060	HDD060-00	00/60	25-01	25-01	25-01
	HDD060-01	00/61	25-02	25-02	
	HDD060-02	00/62	25-03	25-03	25-03
	HDD060-03	00/63	25-04	25-04	
	HDD060-04	00/64	25-05	25-05	25-05
	HDD060-05	00/65	25-06	25-06	
	HDD060-06	00/66	25-07	25-07	25-07
	HDD060-07	00/67	25-08	25-08	
	HDD060-08	00/68	25-09	25-09	25-09
	HDD060-09	00/69	25-10	25-10	
	HDD060-0A	00/6A	25-11	25-11	25-11
	HDD060-0B	00/6B	25-12	25-12	
	HDD060-0C	00/6C	25-13	25-13	25-13
	HDD060-0D	00/6D	25-14	25-14	
	HDD060-0E	00/6E	25-15	25-15	25-15
	HDD060-0F	00/6F	25-16/Spare	25-16/Spare	25-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (98/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-061	HDD061-00	01/60	25-01	25-01	25-01
	HDD061-01	01/61	25-02	25-02	
	HDD061-02	01/62	25-03	25-03	25-03
	HDD061-03	01/63	25-04	25-04	
	HDD061-04	01/64	25-05	25-05	25-05
	HDD061-05	01/65	25-06	25-06	
	HDD061-06	01/66	25-07	25-07	25-07
	HDD061-07	01/67	25-08	25-08	
	HDD061-08	01/68	25-09	25-09	25-09
	HDD061-09	01/69	25-10	25-10	
	HDD061-0A	01/6A	25-11	25-11	25-11
	HDD061-0B	01/6B	25-12	25-12	
	HDD061-0C	01/6C	25-13	25-13	25-13
	HDD061-0D	01/6D	25-14	25-14	
	HDD061-0E	01/6E	25-15	25-15	25-15
	HDD061-0F	01/6F	25-16/Spare	25-16/Spare	25-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (99/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-062	HDD062-00	02/60	25-01	25-01	25-01
	HDD062-01	02/61	25-02	25-02	
	HDD062-02	02/62	25-03	25-03	25-03
	HDD062-03	02/63	25-04	25-04	
	HDD062-04	02/64	25-05	25-05	25-05
	HDD062-05	02/65	25-06	25-06	
	HDD062-06	02/66	25-07	25-07	25-07
	HDD062-07	02/67	25-08	25-08	
	HDD062-08	02/68	25-09	25-09	25-09
	HDD062-09	02/69	25-10	25-10	
	HDD062-0A	02/6A	25-11	25-11	25-11
	HDD062-0B	02/6B	25-12	25-12	
	HDD062-0C	02/6C	25-13	25-13	25-13
	HDD062-0D	02/6D	25-14	25-14	
	HDD062-0E	02/6E	25-15	25-15	25-15
	HDD062-0F	02/6F	25-16/Spare	25-16/Spare	25-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (100/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-063	HDD063-00	03/60	25-01	25-01	25-01
	HDD063-01	03/61	25-02	25-02	
	HDD063-02	03/62	25-03	25-03	25-03
	HDD063-03	03/63	25-04	25-04	
	HDD063-04	03/64	25-05	25-05	25-05
	HDD063-05	03/65	25-06	25-06	
	HDD063-06	03/66	25-07	25-07	25-07
	HDD063-07	03/67	25-08	25-08	
	HDD063-08	03/68	25-09	25-09	25-09
	HDD063-09	03/69	25-10	25-10	
	HDD063-0A	03/6A	25-11	25-11	25-11
	HDD063-0B	03/6B	25-12	25-12	
	HDD063-0C	03/6C	25-13	25-13	25-13
	HDD063-0D	03/6D	25-14	25-14	
	HDD063-0E	03/6E	25-15	25-15	25-15
	HDD063-0F	03/6F	25-16/Spare	25-16/Spare	25-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (101/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-064	HDD064-00	04/60	26-01	25-01	25-01
	HDD064-01	04/61	26-02	25-02	
	HDD064-02	04/62	26-03	25-03	25-03
	HDD064-03	04/63	26-04	25-04	
	HDD064-04	04/64	26-05	25-05	25-05
	HDD064-05	04/65	26-06	25-06	
	HDD064-06	04/66	26-07	25-07	25-07
	HDD064-07	04/67	26-08	25-08	
	HDD064-08	04/68	26-09	25-09	25-09
	HDD064-09	04/69	26-10	25-10	
	HDD064-0A	04/6A	26-11	25-11	25-11
	HDD064-0B	04/6B	26-12	25-12	
	HDD064-0C	04/6C	26-13	25-13	25-13
	HDD064-0D	04/6D	26-14	25-14	
	HDD064-0E	04/6E	26-15	25-15	25-15
	HDD064-0F	04/6F	26-16/Spare	25-16/Spare	25-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (102/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-065	HDD065-00	05/60	26-01	25-01	25-01
	HDD065-01	05/61	26-02	25-02	
	HDD065-02	05/62	26-03	25-03	25-03
	HDD065-03	05/63	26-04	25-04	
	HDD065-04	05/64	26-05	25-05	25-05
	HDD065-05	05/65	26-06	25-06	
	HDD065-06	05/66	26-07	25-07	25-07
	HDD065-07	05/67	26-08	25-08	
	HDD065-08	05/68	26-09	25-09	25-09
	HDD065-09	05/69	26-10	25-10	
	HDD065-0A	05/6A	26-11	25-11	25-11
	HDD065-0B	05/6B	26-12	25-12	
	HDD065-0C	05/6C	26-13	25-13	25-13
	HDD065-0D	05/6D	26-14	25-14	
	HDD065-0E	05/6E	26-15	25-15	25-15
	HDD065-0F	05/6F	26-16/Spare	25-16/Spare	25-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (103/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-066	HDD066-00	06/60	26-01	25-01	25-01
	HDD066-01	06/61	26-02	25-02	
	HDD066-02	06/62	26-03	25-03	25-03
	HDD066-03	06/63	26-04	25-04	
	HDD066-04	06/64	26-05	25-05	25-05
	HDD066-05	06/65	26-06	25-06	
	HDD066-06	06/66	26-07	25-07	25-07
	HDD066-07	06/67	26-08	25-08	
	HDD066-08	06/68	26-09	25-09	25-09
	HDD066-09	06/69	26-10	25-10	
	HDD066-0A	06/6A	26-11	25-11	25-11
	HDD066-0B	06/6B	26-12	25-12	
	HDD066-0C	06/6C	26-13	25-13	25-13
	HDD066-0D	06/6D	26-14	25-14	
	HDD066-0E	06/6E	26-15	25-15	25-15
	HDD066-0F	06/6F	26-16/Spare	25-16/Spare	25-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (104/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-067	HDD067-00	07/60	26-01	25-01	25-01
	HDD067-01	07/61	26-02	25-02	
	HDD067-02	07/62	26-03	25-03	25-03
	HDD067-03	07/63	26-04	25-04	
	HDD067-04	07/64	26-05	25-05	25-05
	HDD067-05	07/65	26-06	25-06	
	HDD067-06	07/66	26-07	25-07	25-07
	HDD067-07	07/67	26-08	25-08	
	HDD067-08	07/68	26-09	25-09	25-09
	HDD067-09	07/69	26-10	25-10	
	HDD067-0A	07/6A	26-11	25-11	25-11
	HDD067-0B	07/6B	26-12	25-12	
	HDD067-0C	07/6C	26-13	25-13	25-13
	HDD067-0D	07/6D	26-14	25-14	
	HDD067-0E	07/6E	26-15	25-15	25-15
	HDD067-0F	07/6F	26-16/Spare	25-16/Spare	25-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (105/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-160	HDD160-00	08/60	27-01	27-01	27-01
	HDD160-01	08/61	27-02	27-02	
	HDD160-02	08/62	27-03	27-03	27-03
	HDD160-03	08/63	27-04	27-04	
	HDD160-04	08/64	27-05	27-05	27-05
	HDD160-05	08/65	27-06	27-06	
	HDD160-06	08/66	27-07	27-07	27-07
	HDD160-07	08/67	27-08	27-08	
	HDD160-08	08/68	27-09	27-09	27-09
	HDD160-09	08/69	27-10	27-10	
	HDD160-0A	08/6A	27-11	27-11	27-11
	HDD160-0B	08/6B	27-12	27-12	
	HDD160-0C	08/6C	27-13	27-13	27-13
	HDD160-0D	08/6D	27-14	27-14	
	HDD160-0E	08/6E	27-15	27-15	27-15
	HDD160-0F	08/6F	27-16/Spare	27-16/Spare	27-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (106/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-161	HDD161-00	09/60	27-01	27-01	27-01
	HDD161-01	09/61	27-02	27-02	
	HDD161-02	09/62	27-03	27-03	27-03
	HDD161-03	09/63	27-04	27-04	
	HDD161-04	09/64	27-05	27-05	27-05
	HDD161-05	09/65	27-06	27-06	
	HDD161-06	09/66	27-07	27-07	27-07
	HDD161-07	09/67	27-08	27-08	
	HDD161-08	09/68	27-09	27-09	27-09
	HDD161-09	09/69	27-10	27-10	
	HDD161-0A	09/6A	27-11	27-11	27-11
	HDD161-0B	09/6B	27-12	27-12	
	HDD161-0C	09/6C	27-13	27-13	27-13
	HDD161-0D	09/6D	27-14	27-14	
	HDD161-0E	09/6E	27-15	27-15	27-15
	HDD161-0F	09/6F	27-16/Spare	27-16/Spare	27-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (107/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-162	HDD162-00	0A/60	27-01	27-01	27-01
	HDD162-01	0A/61	27-02	27-02	
	HDD162-02	0A/62	27-03	27-03	27-03
	HDD162-03	0A/63	27-04	27-04	
	HDD162-04	0A/64	27-05	27-05	27-05
	HDD162-05	0A/65	27-06	27-06	
	HDD162-06	0A/66	27-07	27-07	27-07
	HDD162-07	0A/67	27-08	27-08	
	HDD162-08	0A/68	27-09	27-09	27-09
	HDD162-09	0A/69	27-10	27-10	
	HDD162-0A	0A/6A	27-11	27-11	27-11
	HDD162-0B	0A/6B	27-12	27-12	
	HDD162-0C	0A/6C	27-13	27-13	27-13
	HDD162-0D	0A/6D	27-14	27-14	
	HDD162-0E	0A/6E	27-15	27-15	27-15
	HDD162-0F	0A/6F	27-16/Spare	27-16/Spare	27-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (108/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-163	HDD163-00	0B/60	27-01	27-01	27-01
	HDD163-01	0B/61	27-02	27-02	
	HDD163-02	0B/62	27-03	27-03	27-03
	HDD163-03	0B/63	27-04	27-04	
	HDD163-04	0B/64	27-05	27-05	27-05
	HDD163-05	0B/65	27-06	27-06	
	HDD163-06	0B/66	27-07	27-07	27-07
	HDD163-07	0B/67	27-08	27-08	
	HDD163-08	0B/68	27-09	27-09	27-09
	HDD163-09	0B/69	27-10	27-10	
	HDD163-0A	0B/6A	27-11	27-11	27-11
	HDD163-0B	0B/6B	27-12	27-12	
	HDD163-0C	0B/6C	27-13	27-13	27-13
	HDD163-0D	0B/6D	27-14	27-14	
	HDD163-0E	0B/6E	27-15	27-15	27-15
	HDD163-0F	0B/6F	27-16/Spare	27-16/Spare	27-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (109/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-164	HDD164-00	0C/60	28-01	27-01	27-01
	HDD164-01	0C/61	28-02	27-02	
	HDD164-02	0C/62	28-03	27-03	27-03
	HDD164-03	0C/63	28-04	27-04	
	HDD164-04	0C/64	28-05	27-05	27-05
	HDD164-05	0C/65	28-06	27-06	
	HDD164-06	0C/66	28-07	27-07	27-07
	HDD164-07	0C/67	28-08	27-08	
	HDD164-08	0C/68	28-09	27-09	27-09
	HDD164-09	0C/69	28-10	27-10	
	HDD164-0A	0C/6A	28-11	27-11	27-11
	HDD164-0B	0C/6B	28-12	27-12	
	HDD164-0C	0C/6C	28-13	27-13	27-13
	HDD164-0D	0C/6D	28-14	27-14	
	HDD164-0E	0C/6E	28-15	27-15	27-15
	HDD164-0F	0C/6F	28-16/Spare	27-16/Spare	27-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (110/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-165	HDD165-00	0D/60	28-01	27-01	27-01
	HDD165-01	0D/61	28-02	27-02	
	HDD165-02	0D/62	28-03	27-03	27-03
	HDD165-03	0D/63	28-04	27-04	
	HDD165-04	0D/64	28-05	27-05	27-05
	HDD165-05	0D/65	28-06	27-06	
	HDD165-06	0D/66	28-07	27-07	27-07
	HDD165-07	0D/67	28-08	27-08	
	HDD165-08	0D/68	28-09	27-09	27-09
	HDD165-09	0D/69	28-10	27-10	
	HDD165-0A	0D/6A	28-11	27-11	27-11
	HDD165-0B	0D/6B	28-12	27-12	
	HDD165-0C	0D/6C	28-13	27-13	27-13
	HDD165-0D	0D/6D	28-14	27-14	
	HDD165-0E	0D/6E	28-15	27-15	27-15
	HDD165-0F	0D/6F	28-16/Spare	27-16/Spare	27-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (111/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-166	HDD166-00	0E/60	28-01	27-01	27-01
	HDD166-01	0E/61	28-02	27-02	
	HDD166-02	0E/62	28-03	27-03	27-03
	HDD166-03	0E/63	28-04	27-04	
	HDD166-04	0E/64	28-05	27-05	27-05
	HDD166-05	0E/65	28-06	27-06	
	HDD166-06	0E/66	28-07	27-07	27-07
	HDD166-07	0E/67	28-08	27-08	
	HDD166-08	0E/68	28-09	27-09	27-09
	HDD166-09	0E/69	28-10	27-10	
	HDD166-0A	0E/6A	28-11	27-11	27-11
	HDD166-0B	0E/6B	28-12	27-12	
	HDD166-0C	0E/6C	28-13	27-13	27-13
	HDD166-0D	0E/6D	28-14	27-14	
	HDD166-0E	0E/6E	28-15	27-15	27-15
	HDD166-0F	0E/6F	28-16/Spare	27-16/Spare	27-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (112/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-167	HDD167-00	0F/60	28-01	27-01	27-01
	HDD167-01	0F/61	28-02	27-02	
	HDD167-02	0F/62	28-03	27-03	27-03
	HDD167-03	0F/63	28-04	27-04	
	HDD167-04	0F/64	28-05	27-05	27-05
	HDD167-05	0F/65	28-06	27-06	
	HDD167-06	0F/66	28-07	27-07	27-07
	HDD167-07	0F/67	28-08	27-08	
	HDD167-08	0F/68	28-09	27-09	27-09
	HDD167-09	0F/69	28-10	27-10	
	HDD167-0A	0F/6A	28-11	27-11	27-11
	HDD167-0B	0F/6B	28-12	27-12	
	HDD167-0C	0F/6C	28-13	27-13	27-13
	HDD167-0D	0F/6D	28-14	27-14	
	HDD167-0E	0F/6E	28-15	27-15	27-15
	HDD167-0F	0F/6F	28-16/Spare	27-16/Spare	27-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (113/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-070	HDD070-00	00/70	29-01	29-01	29-01
	HDD070-01	00/71	29-02	29-02	
	HDD070-02	00/72	29-03	29-03	29-03
	HDD070-03	00/73	29-04	29-04	
	HDD070-04	00/74	29-05	29-05	29-05
	HDD070-05	00/75	29-06	29-06	
	HDD070-06	00/76	29-07	29-07	29-07
	HDD070-07	00/77	29-08	29-08	
	HDD070-08	00/78	29-09	29-09	29-09
	HDD070-09	00/79	29-10	29-10	
	HDD070-0A	00/7A	29-11	29-11	29-11
	HDD070-0B	00/7B	29-12	29-12	
	HDD070-0C	00/7C	29-13	29-13	29-13
	HDD070-0D	00/7D	29-14	29-14	
	HDD070-0E	00/7E	29-15	29-15	29-15
	HDD070-0F	00/7F	29-16/Spare	29-16/Spare	29-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (114/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-071	HDD071-00	01/70	29-01	29-01	29-01
	HDD071-01	01/71	29-02	29-02	
	HDD071-02	01/72	29-03	29-03	29-03
	HDD071-03	01/73	29-04	29-04	
	HDD071-04	01/74	29-05	29-05	29-05
	HDD071-05	01/75	29-06	29-06	
	HDD071-06	01/76	29-07	29-07	29-07
	HDD071-07	01/77	29-08	29-08	
	HDD071-08	01/78	29-09	29-09	29-09
	HDD071-09	01/79	29-10	29-10	
	HDD071-0A	01/7A	29-11	29-11	29-11
	HDD071-0B	01/7B	29-12	29-12	
	HDD071-0C	01/7C	29-13	29-13	29-13
	HDD071-0D	01/7D	29-14	29-14	
	HDD071-0E	01/7E	29-15	29-15	29-15
	HDD071-0F	01/7F	29-16/Spare	29-16/Spare	29-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (115/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-072	HDD072-00	02/70	29-01	29-01	29-01
	HDD072-01	02/71	29-02	29-02	
	HDD072-02	02/72	29-03	29-03	29-03
	HDD072-03	02/73	29-04	29-04	
	HDD072-04	02/74	29-05	29-05	29-05
	HDD072-05	02/75	29-06	29-06	
	HDD072-06	02/76	29-07	29-07	29-07
	HDD072-07	02/77	29-08	29-08	
	HDD072-08	02/78	29-09	29-09	29-09
	HDD072-09	02/79	29-10	29-10	
	HDD072-0A	02/7A	29-11	29-11	29-11
	HDD072-0B	02/7B	29-12	29-12	
	HDD072-0C	02/7C	29-13	29-13	29-13
	HDD072-0D	02/7D	29-14	29-14	
	HDD072-0E	02/7E	29-15	29-15	29-15
	HDD072-0F	02/7F	29-16/Spare	29-16/Spare	29-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (116/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-073	HDD073-00	03/70	29-01	29-01	29-01
	HDD073-01	03/71	29-02	29-02	
	HDD073-02	03/72	29-03	29-03	29-03
	HDD073-03	03/73	29-04	29-04	
	HDD073-04	03/74	29-05	29-05	29-05
	HDD073-05	03/75	29-06	29-06	
	HDD073-06	03/76	29-07	29-07	29-07
	HDD073-07	03/77	29-08	29-08	
	HDD073-08	03/78	29-09	29-09	29-09
	HDD073-09	03/79	29-10	29-10	
	HDD073-0A	03/7A	29-11	29-11	29-11
	HDD073-0B	03/7B	29-12	29-12	
	HDD073-0C	03/7C	29-13	29-13	29-13
	HDD073-0D	03/7D	29-14	29-14	
	HDD073-0E	03/7E	29-15	29-15	29-15
	HDD073-0F	03/7F	29-16/Spare	29-16/Spare	29-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (117/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-074	HDD074-00	04/70	30-01	29-01	29-01
	HDD074-01	04/71	30-02	29-02	
	HDD074-02	04/72	30-03	29-03	29-03
	HDD074-03	04/73	30-04	29-04	
	HDD074-04	04/74	30-05	29-05	29-05
	HDD074-05	04/75	30-06	29-06	
	HDD074-06	04/76	30-07	29-07	29-07
	HDD074-07	04/77	30-08	29-08	
	HDD074-08	04/78	30-09	29-09	29-09
	HDD074-09	04/79	30-10	29-10	
	HDD074-0A	04/7A	30-11	29-11	29-11
	HDD074-0B	04/7B	30-12	29-12	
	HDD074-0C	04/7C	30-13	29-13	29-13
	HDD074-0D	04/7D	30-14	29-14	
	HDD074-0E	04/7E	30-15	29-15	29-15
	HDD074-0F	04/7F	30-16/Spare	29-16/Spare	29-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (118/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-075	HDD075-00	05/70	30-01	29-01	29-01
	HDD075-01	05/71	30-02	29-02	
	HDD075-02	05/72	30-03	29-03	29-03
	HDD075-03	05/73	30-04	29-04	
	HDD075-04	05/74	30-05	29-05	29-05
	HDD075-05	05/75	30-06	29-06	
	HDD075-06	05/76	30-07	29-07	29-07
	HDD075-07	05/77	30-08	29-08	
	HDD075-08	05/78	30-09	29-09	29-09
	HDD075-09	05/79	30-10	29-10	
	HDD075-0A	05/7A	30-11	29-11	29-11
	HDD075-0B	05/7B	30-12	29-12	
	HDD075-0C	05/7C	30-13	29-13	29-13
	HDD075-0D	05/7D	30-14	29-14	
	HDD075-0E	05/7E	30-15	29-15	29-15
	HDD075-0F	05/7F	30-16/Spare	29-16/Spare	29-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (119/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-076	HDD076-00	06/70	30-01	29-01	29-01
	HDD076-01	06/71	30-02	29-02	
	HDD076-02	06/72	30-03	29-03	29-03
	HDD076-03	06/73	30-04	29-04	
	HDD076-04	06/74	30-05	29-05	29-05
	HDD076-05	06/75	30-06	29-06	
	HDD076-06	06/76	30-07	29-07	29-07
	HDD076-07	06/77	30-08	29-08	
	HDD076-08	06/78	30-09	29-09	29-09
	HDD076-09	06/79	30-10	29-10	
	HDD076-0A	06/7A	30-11	29-11	29-11
	HDD076-0B	06/7B	30-12	29-12	
	HDD076-0C	06/7C	30-13	29-13	29-13
	HDD076-0D	06/7D	30-14	29-14	
	HDD076-0E	06/7E	30-15	29-15	29-15
	HDD076-0F	06/7F	30-16/Spare	29-16/Spare	29-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (120/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-077	HDD077-00	07/70	30-01	29-01	29-01
	HDD077-01	07/71	30-02	29-02	
	HDD077-02	07/72	30-03	29-03	29-03
	HDD077-03	07/73	30-04	29-04	
	HDD077-04	07/74	30-05	29-05	29-05
	HDD077-05	07/75	30-06	29-06	
	HDD077-06	07/76	30-07	29-07	29-07
	HDD077-07	07/77	30-08	29-08	
	HDD077-08	07/78	30-09	29-09	29-09
	HDD077-09	07/79	30-10	29-10	
	HDD077-0A	07/7A	30-11	29-11	29-11
	HDD077-0B	07/7B	30-12	29-12	
	HDD077-0C	07/7C	30-13	29-13	29-13
	HDD077-0D	07/7D	30-14	29-14	
	HDD077-0E	07/7E	30-15	29-15	29-15
	HDD077-0F	07/7F	30-16/Spare	29-16/Spare	29-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (121/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-170	HDD170-00	08/70	31-01	31-01	31-01
	HDD170-01	08/71	31-02	31-02	
	HDD170-02	08/72	31-03	31-03	31-03
	HDD170-03	08/73	31-04	31-04	
	HDD170-04	08/74	31-05	31-05	31-05
	HDD170-05	08/75	31-06	31-06	
	HDD170-06	08/76	31-07	31-07	31-07
	HDD170-07	08/77	31-08	31-08	
	HDD170-08	08/78	31-09	31-09	31-09
	HDD170-09	08/79	31-10	31-10	
	HDD170-0A	08/7A	31-11	31-11	31-11
	HDD170-0B	08/7B	31-12	31-12	
	HDD170-0C	08/7C	31-13	31-13	31-13
	HDD170-0D	08/7D	31-14	31-14	
	HDD170-0E	08/7E	31-15	31-15	31-15
	HDD170-0F	08/7F	31-16/Spare	31-16/Spare	31-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (122/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-171	HDD171-00	09/70	31-01	31-01	31-01
	HDD171-01	09/71	31-02	31-02	
	HDD171-02	09/72	31-03	31-03	31-03
	HDD171-03	09/73	31-04	31-04	
	HDD171-04	09/74	31-05	31-05	31-05
	HDD171-05	09/75	31-06	31-06	
	HDD171-06	09/76	31-07	31-07	31-07
	HDD171-07	09/77	31-08	31-08	
	HDD171-08	09/78	31-09	31-09	31-09
	HDD171-09	09/79	31-10	31-10	
	HDD171-0A	09/7A	31-11	31-11	31-11
	HDD171-0B	09/7B	31-12	31-12	
	HDD171-0C	09/7C	31-13	31-13	31-13
	HDD171-0D	09/7D	31-14	31-14	
	HDD171-0E	09/7E	31-15	31-15	31-15
	HDD171-0F	09/7F	31-16/Spare	31-16/Spare	31-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (123/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-172	HDD172-00	0A/70	31-01	31-01	31-01
	HDD172-01	0A/71	31-02	31-02	
	HDD172-02	0A/72	31-03	31-03	31-03
	HDD172-03	0A/73	31-04	31-04	
	HDD172-04	0A/74	31-05	31-05	31-05
	HDD172-05	0A/75	31-06	31-06	
	HDD172-06	0A/76	31-07	31-07	31-07
	HDD172-07	0A/77	31-08	31-08	
	HDD172-08	0A/78	31-09	31-09	31-09
	HDD172-09	0A/79	31-10	31-10	
	HDD172-0A	0A/7A	31-11	31-11	31-11
	HDD172-0B	0A/7B	31-12	31-12	
	HDD172-0C	0A/7C	31-13	31-13	31-13
	HDD172-0D	0A/7D	31-14	31-14	
	HDD172-0E	0A/7E	31-15	31-15	31-15
	HDD172-0F	0A/7F	31-16/Spare	31-16/Spare	31-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (124/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-173	HDD173-00	0B/70	31-01	31-01	31-01
	HDD173-01	0B/71	31-02	31-02	
	HDD173-02	0B/72	31-03	31-03	31-03
	HDD173-03	0B/73	31-04	31-04	
	HDD173-04	0B/74	31-05	31-05	31-05
	HDD173-05	0B/75	31-06	31-06	
	HDD173-06	0B/76	31-07	31-07	31-07
	HDD173-07	0B/77	31-08	31-08	
	HDD173-08	0B/78	31-09	31-09	31-09
	HDD173-09	0B/79	31-10	31-10	
	HDD173-0A	0B/7A	31-11	31-11	31-11
	HDD173-0B	0B/7B	31-12	31-12	
	HDD173-0C	0B/7C	31-13	31-13	31-13
	HDD173-0D	0B/7D	31-14	31-14	
	HDD173-0E	0B/7E	31-15	31-15	31-15
	HDD173-0F	0B/7F	31-16/Spare	31-16/Spare	31-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (125/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-174	HDD174-00	0C/70	32-01	31-01	31-01
	HDD174-01	0C/71	32-02	31-02	
	HDD174-02	0C/72	32-03	31-03	31-03
	HDD174-03	0C/73	32-04	31-04	
	HDD174-04	0C/74	32-05	31-05	31-05
	HDD174-05	0C/75	32-06	31-06	
	HDD174-06	0C/76	32-07	31-07	31-07
	HDD174-07	0C/77	32-08	31-08	
	HDD174-08	0C/78	32-09	31-09	31-09
	HDD174-09	0C/79	32-10	31-10	
	HDD174-0A	0C/7A	32-11	31-11	31-11
	HDD174-0B	0C/7B	32-12	31-12	
	HDD174-0C	0C/7C	32-13	31-13	31-13
	HDD174-0D	0C/7D	32-14	31-14	
	HDD174-0E	0C/7E	32-15	31-15	31-15
	HDD174-0F	0C/7F	32-16/Spare	31-16/Spare	31-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (126/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-175	HDD175-00	0D/70	32-01	31-01	31-01
	HDD175-01	0D/71	32-02	31-02	
	HDD175-02	0D/72	32-03	31-03	31-03
	HDD175-03	0D/73	32-04	31-04	
	HDD175-04	0D/74	32-05	31-05	31-05
	HDD175-05	0D/75	32-06	31-06	
	HDD175-06	0D/76	32-07	31-07	31-07
	HDD175-07	0D/77	32-08	31-08	
	HDD175-08	0D/78	32-09	31-09	31-09
	HDD175-09	0D/79	32-10	31-10	
	HDD175-0A	0D/7A	32-11	31-11	31-11
	HDD175-0B	0D/7B	32-12	31-12	
	HDD175-0C	0D/7C	32-13	31-13	31-13
	HDD175-0D	0D/7D	32-14	31-14	
	HDD175-0E	0D/7E	32-15	31-15	31-15
	HDD175-0F	0D/7F	32-16/Spare	31-16/Spare	31-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (127/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-176	HDD176-00	0E/70	32-01	31-01	31-01
	HDD176-01	0E/71	32-02	31-02	
	HDD176-02	0E/72	32-03	31-03	31-03
	HDD176-03	0E/73	32-04	31-04	
	HDD176-04	0E/74	32-05	31-05	31-05
	HDD176-05	0E/75	32-06	31-06	
	HDD176-06	0E/76	32-07	31-07	31-07
	HDD176-07	0E/77	32-08	31-08	
	HDD176-08	0E/78	32-09	31-09	31-09
	HDD176-09	0E/79	32-10	31-10	
	HDD176-0A	0E/7A	32-11	31-11	31-11
	HDD176-0B	0E/7B	32-12	31-12	
	HDD176-0C	0E/7C	32-13	31-13	31-13
	HDD176-0D	0E/7D	32-14	31-14	
	HDD176-0E	0E/7E	32-15	31-15	31-15
	HDD176-0F	0E/7F	32-16/Spare	31-16/Spare	31-15/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (2.5 INCH BOX) (128/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-177	HDD177-00	0F/70	32-01	31-01	31-01
	HDD177-01	0F/71	32-02	31-02	
	HDD177-02	0F/72	32-03	31-03	31-03
	HDD177-03	0F/73	32-04	31-04	
	HDD177-04	0F/74	32-05	31-05	31-05
	HDD177-05	0F/75	32-06	31-06	
	HDD177-06	0F/76	32-07	31-07	31-07
	HDD177-07	0F/77	32-08	31-08	
	HDD177-08	0F/78	32-09	31-09	31-09
	HDD177-09	0F/79	32-10	31-10	
	HDD177-0A	0F/7A	32-11	31-11	31-11
	HDD177-0B	0F/7B	32-12	31-12	
	HDD177-0C	0F/7C	32-13	31-13	31-13
	HDD177-0D	0F/7D	32-14	31-14	
	HDD177-0E	0F/7E	32-15	31-15	31-15
	HDD177-0F	0F/7F	32-16/Spare	31-16/Spare	31-15/Spare

5.2 Physical-Logical Device Matrixes (3.5 INCH BOX)**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX)
(1/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-000	HDD000-00	00/00	01-01	01-01	01-01
	HDD000-01	00/01	01-02	01-02	
	HDD000-02	00/02	01-03	01-03	01-03
	HDD000-03	00/03	01-04	01-04	
	HDD000-04	00/04	01-05	01-05	01-05
	HDD000-05	00/05	01-06	01-06	
	HDD000-06	00/06	01-07	01-07	01-07
	HDD000-07	00/07	01-08	01-08	
	HDD000-08	00/08	01-09	01-09	01-09
	HDD000-09	00/09	01-10/Spare	01-10/Spare	01-09/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX)
(2/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-001	HDD001-00	01/00	01-01	01-01	01-01
	HDD001-01	01/01	01-02	01-02	
	HDD001-02	01/02	01-03	01-03	01-03
	HDD001-03	01/03	01-04	01-04	
	HDD001-04	01/04	01-05	01-05	01-05
	HDD001-05	01/05	01-06	01-06	
	HDD001-06	01/06	01-07	01-07	01-07
	HDD001-07	01/07	01-08	01-08	
	HDD001-08	01/08	01-09	01-09	01-09
	HDD001-09	01/09	01-10/Spare	01-10/Spare	01-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (3/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-002	HDD002-00	02/00	01-01	01-01	01-01
	HDD002-01	02/01	01-02	01-02	
	HDD002-02	02/02	01-03	01-03	01-03
	HDD002-03	02/03	01-04	01-04	
	HDD002-04	02/04	01-05	01-05	01-05
	HDD002-05	02/05	01-06	01-06	
	HDD002-06	02/06	01-07	01-07	01-07
	HDD002-07	02/07	01-08	01-08	
	HDD002-08	02/08	01-09	01-09	01-09
	HDD002-09	02/09	01-10/Spare	01-10/Spare	01-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (4/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-003	HDD003-00	03/00	01-01	01-01	01-01
	HDD003-01	03/01	01-02	01-02	
	HDD003-02	03/02	01-03	01-03	01-03
	HDD003-03	03/03	01-04	01-04	
	HDD003-04	03/04	01-05	01-05	01-05
	HDD003-05	03/05	01-06	01-06	
	HDD003-06	03/06	01-07	01-07	01-07
	HDD003-07	03/07	01-08	01-08	
	HDD003-08	03/08	01-09	01-09	01-09
	HDD003-09	03/09	01-10/Spare	01-10/Spare	01-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (5/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD004	HDD004-00	04/00	02-01	01-01	01-01
	HDD004-01	04/01	02-02	01-02	
	HDD004-02	04/02	02-03	01-03	01-03
	HDD004-03	04/03	02-04	01-04	
	HDD004-04	04/04	02-05	01-05	01-05
	HDD004-05	04/05	02-06	01-06	
	HDD004-06	04/06	02-07	01-07	01-07
	HDD004-07	04/07	02-08	01-08	
	HDD004-08	04/08	02-09	01-09	01-09
	HDD004-09	04/09	02-10/Spare	01-10/Spare	01-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (6/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD005	HDD005-00	05/00	02-01	01-01	01-01
	HDD005-01	05/01	02-02	01-02	
	HDD005-02	05/02	02-03	01-03	01-03
	HDD005-03	05/03	02-04	01-04	
	HDD005-04	05/04	02-05	01-05	01-05
	HDD005-05	05/05	02-06	01-06	
	HDD005-06	05/06	02-07	01-07	01-07
	HDD005-07	05/07	02-08	01-08	
	HDD005-08	05/08	02-09	01-09	01-09
	HDD005-09	05/09	02-10/Spare	01-10/Spare	01-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (7/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-006	HDD006-00	06/00	02-01	01-01	01-01
	HDD006-01	06/01	02-02	01-02	
	HDD006-02	06/02	02-03	01-03	01-03
	HDD006-03	06/03	02-04	01-04	
	HDD006-04	06/04	02-05	01-05	01-05
	HDD006-05	06/05	02-06	01-06	
	HDD006-06	06/06	02-07	01-07	01-07
	HDD006-07	06/07	02-08	01-08	
	HDD006-08	06/08	02-09	01-09	01-09
	HDD006-09	06/09	02-10/Spare	01-10/Spare	01-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (8/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-007	HDD007-00	07/00	02-01	01-01	01-01
	HDD007-01	07/01	02-02	01-02	
	HDD007-02	07/02	02-03	01-03	01-03
	HDD007-03	07/03	02-04	01-04	
	HDD007-04	07/04	02-05	01-05	01-05
	HDD007-05	07/05	02-06	01-06	
	HDD007-06	07/06	02-07	01-07	01-07
	HDD007-07	07/07	02-08	01-08	
	HDD007-08	07/08	02-09	01-09	01-09
	HDD007-09	07/09	02-10/Spare	01-10/Spare	01-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (9/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-100	HDD100-00	08/00	03-01	03-01	03-01
	HDD100-01	08/01	03-02	03-02	
	HDD100-02	08/02	03-03	03-03	03-03
	HDD100-03	08/03	03-04	03-04	
	HDD100-04	08/04	03-05	03-05	03-05
	HDD100-05	08/05	03-06	03-06	
	HDD100-06	08/06	03-07	03-07	03-07
	HDD100-07	08/07	03-08	03-08	
	HDD100-08	08/08	03-09	03-09	03-09
	HDD100-09	08/09	03-10/Spare	03-10/Spare	03-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (10/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-101	HDD101-00	09/00	03-01	03-01	03-01
	HDD101-01	09/01	03-02	03-02	
	HDD101-02	09/02	03-03	03-03	03-03
	HDD101-03	09/03	03-04	03-04	
	HDD101-04	09/04	03-05	03-05	03-05
	HDD101-05	09/05	03-06	03-06	
	HDD101-06	09/06	03-07	03-07	03-07
	HDD101-07	09/07	03-08	03-08	
	HDD101-08	09/08	03-09	03-09	03-09
	HDD101-09	09/09	03-10/Spare	03-10/Spare	03-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (11/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-102	HDD102-00	0A/00	03-01	03-01	03-01
	HDD102-01	0A/01	03-02	03-02	
	HDD102-02	0A/02	03-03	03-03	03-03
	HDD102-03	0A/03	03-04	03-04	
	HDD102-04	0A/04	03-05	03-05	03-05
	HDD102-05	0A/05	03-06	03-06	
	HDD102-06	0A/06	03-07	03-07	03-07
	HDD102-07	0A/07	03-08	03-08	
	HDD102-08	0A/08	03-09	03-09	03-09
	HDD102-09	0A/09	03-10/Spare	03-10/Spare	03-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (12/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-103	HDD103-00	0B/00	03-01	03-01	03-01
	HDD103-01	0B/01	03-02	03-02	
	HDD103-02	0B/02	03-03	03-03	03-03
	HDD103-03	0B/03	03-04	03-04	
	HDD103-04	0B/04	03-05	03-05	03-05
	HDD103-05	0B/05	03-06	03-06	
	HDD103-06	0B/06	03-07	03-07	03-07
	HDD103-07	0B/07	03-08	03-08	
	HDD103-08	0B/08	03-09	03-09	03-09
	HDD103-09	0B/09	03-10/Spare	03-10/Spare	03-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (13/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-104	HDD104-00	0C/00	04-01	03-01	03-01
	HDD104-01	0C/01	04-02	03-02	
	HDD104-02	0C/02	04-03	03-03	03-03
	HDD104-03	0C/03	04-04	03-04	
	HDD104-04	0C/04	04-05	03-05	03-05
	HDD104-05	0C/05	04-06	03-06	
	HDD104-06	0C/06	04-07	03-07	03-07
	HDD104-07	0C/07	04-08	03-08	
	HDD104-08	0C/08	04-09	03-09	03-09
	HDD104-09	0C/09	04-10/Spare	03-10/Spare	03-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (14/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-105	HDD105-00	0D/00	04-01	03-01	03-01
	HDD105-01	0D/01	04-02	03-02	
	HDD105-02	0D/02	04-03	03-03	03-03
	HDD105-03	0D/03	04-04	03-04	
	HDD105-04	0D/04	04-05	03-05	03-05
	HDD105-05	0D/05	04-06	03-06	
	HDD105-06	0D/06	04-07	03-07	03-07
	HDD105-07	0D/07	04-08	03-08	
	HDD105-08	0D/08	04-09	03-09	03-09
	HDD105-09	0D/09	04-10/Spare	03-10/Spare	03-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (15/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-106	HDD106-00	0E/00	04-01	03-01	03-01
	HDD106-01	0E/01	04-02	03-02	
	HDD106-02	0E/02	04-03	03-03	03-03
	HDD106-03	0E/03	04-04	03-04	
	HDD106-04	0E/04	04-05	03-05	03-05
	HDD106-05	0E/05	04-06	03-06	
	HDD106-06	0E/06	04-07	03-07	03-07
	HDD106-07	0E/07	04-08	03-08	
	HDD106-08	0E/08	04-09	03-09	03-09
	HDD106-09	0E/09	04-10/Spare	03-10/Spare	03-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (16/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-107	HDD107-00	0F/00	04-01	03-01	03-01
	HDD107-01	0F/01	04-02	03-02	
	HDD107-02	0F/02	04-03	03-03	03-03
	HDD107-03	0F/03	04-04	03-04	
	HDD107-04	0F/04	04-05	03-05	03-05
	HDD107-05	0F/05	04-06	03-06	
	HDD107-06	0F/06	04-07	03-07	03-07
	HDD107-07	0F/07	04-08	03-08	
	HDD107-08	0F/08	04-09	03-09	03-09
	HDD107-09	0F/09	04-10/Spare	03-10/Spare	03-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (17/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD010	HDD010-00	00/10	05-01	05-01	05-01
	HDD010-01	00/11	05-02	05-02	
	HDD010-02	00/12	05-03	05-03	05-03
	HDD010-03	00/13	05-04	05-04	
	HDD010-04	00/14	05-05	05-05	05-05
	HDD010-05	00/15	05-06	05-06	
	HDD010-06	00/16	05-07	05-07	05-07
	HDD010-07	00/17	05-08	05-08	
	HDD010-08	00/18	05-09	05-09	05-09
	HDD010-09	00/19	05-10/Spare	05-10/Spare	05-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (18/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD011	HDD011-00	01/10	05-01	05-01	05-01
	HDD011-01	01/11	05-02	05-02	
	HDD011-02	01/12	05-03	05-03	05-03
	HDD011-03	01/13	05-04	05-04	
	HDD011-04	01/14	05-05	05-05	05-05
	HDD011-05	01/15	05-06	05-06	
	HDD011-06	01/16	05-07	05-07	05-07
	HDD011-07	01/17	05-08	05-08	
	HDD011-08	01/18	05-09	05-09	05-09
	HDD011-09	01/19	05-10/Spare	05-10/Spare	05-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (19/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD012	HDD012-00	02/10	05-01	05-01	05-01
	HDD012-01	02/11	05-02	05-02	
	HDD012-02	02/12	05-03	05-03	05-03
	HDD012-03	02/13	05-04	05-04	
	HDD012-04	02/14	05-05	05-05	05-05
	HDD012-05	02/15	05-06	05-06	
	HDD012-06	02/16	05-07	05-07	05-07
	HDD012-07	02/17	05-08	05-08	
	HDD012-08	02/18	05-09	05-09	05-09
	HDD012-09	02/19	05-10/Spare	05-10/Spare	05-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (20/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD013	HDD013-00	03/10	05-01	05-01	05-01
	HDD013-01	03/11	05-02	05-02	
	HDD013-02	03/12	05-03	05-03	05-03
	HDD013-03	03/13	05-04	05-04	
	HDD013-04	03/14	05-05	05-05	05-05
	HDD013-05	03/15	05-06	05-06	
	HDD013-06	03/16	05-07	05-07	05-07
	HDD013-07	03/17	05-08	05-08	
	HDD013-08	03/18	05-09	05-09	05-09
	HDD013-09	03/19	05-10/Spare	05-10/Spare	05-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (21/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-014	HDD014-00	04/10	06-01	05-01	05-01
	HDD014-01	04/11	06-02	05-02	
	HDD014-02	04/12	06-03	05-03	05-03
	HDD014-03	04/13	06-04	05-04	
	HDD014-04	04/14	06-05	05-05	05-05
	HDD014-05	04/15	06-06	05-06	
	HDD014-06	04/16	06-07	05-07	05-07
	HDD014-07	04/17	06-08	05-08	
	HDD014-08	04/18	06-09	05-09	05-09
	HDD014-09	04/19	06-10/Spare	05-10/Spare	05-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (22/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-015	HDD015-00	05/10	06-01	05-01	05-01
	HDD015-01	05/11	06-02	05-02	
	HDD015-02	05/12	06-03	05-03	05-03
	HDD015-03	05/13	06-04	05-04	
	HDD015-04	05/14	06-05	05-05	05-05
	HDD015-05	05/15	06-06	05-06	
	HDD015-06	05/16	06-07	05-07	05-07
	HDD015-07	05/17	06-08	05-08	
	HDD015-08	05/18	06-09	05-09	05-09
	HDD015-09	05/19	06-10/Spare	05-10/Spare	05-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (23/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD016	HDD016-00	06/10	06-01	05-01	05-01
	HDD016-01	06/11	06-02	05-02	
	HDD016-02	06/12	06-03	05-03	05-03
	HDD016-03	06/13	06-04	05-04	
	HDD016-04	06/14	06-05	05-05	05-05
	HDD016-05	06/15	06-06	05-06	
	HDD016-06	06/16	06-07	05-07	05-07
	HDD016-07	06/17	06-08	05-08	
	HDD016-08	06/18	06-09	05-09	05-09
	HDD016-09	06/19	06-10/Spare	05-10/Spare	05-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (24/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD017	HDD017-00	07/10	06-01	05-01	05-01
	HDD017-01	07/11	06-02	05-02	
	HDD017-02	07/12	06-03	05-03	05-03
	HDD017-03	07/13	06-04	05-04	
	HDD017-04	07/14	06-05	05-05	05-05
	HDD017-05	07/15	06-06	05-06	
	HDD017-06	07/16	06-07	05-07	05-07
	HDD017-07	07/17	06-08	05-08	
	HDD017-08	07/18	06-09	05-09	05-09
	HDD017-09	07/19	06-10/Spare	05-10/Spare	05-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (25/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-110	HDD110-00	08/10	07-01	07-01	07-01
	HDD110-01	08/11	07-02	07-02	
	HDD110-02	08/12	07-03	07-03	07-03
	HDD110-03	08/13	07-04	07-04	
	HDD110-04	08/14	07-05	07-05	07-05
	HDD110-05	08/15	07-06	07-06	
	HDD110-06	08/16	07-07	07-07	07-07
	HDD110-07	08/17	07-08	07-08	
	HDD110-08	08/18	07-09	07-09	07-09
	HDD110-09	08/19	07-10/Spare	07-10/Spare	07-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (26/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-111	HDD111-00	09/10	07-01	07-01	07-01
	HDD111-01	09/11	07-02	07-02	
	HDD111-02	09/12	07-03	07-03	07-03
	HDD111-03	09/13	07-04	07-04	
	HDD111-04	09/14	07-05	07-05	07-05
	HDD111-05	09/15	07-06	07-06	
	HDD111-06	09/16	07-07	07-07	07-07
	HDD111-07	09/17	07-08	07-08	
	HDD111-08	09/18	07-09	07-09	07-09
	HDD111-09	09/19	07-10/Spare	07-10/Spare	07-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (27/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-112	HDD112-00	0A/10	07-01	07-01	07-01
	HDD112-01	0A/11	07-02	07-02	
	HDD112-02	0A/12	07-03	07-03	07-03
	HDD112-03	0A/13	07-04	07-04	
	HDD112-04	0A/14	07-05	07-05	07-05
	HDD112-05	0A/15	07-06	07-06	
	HDD112-06	0A/16	07-07	07-07	07-07
	HDD112-07	0A/17	07-08	07-08	
	HDD112-08	0A/18	07-09	07-09	07-09
	HDD112-09	0A/19	07-10/Spare	07-10/Spare	07-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (28/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-113	HDD113-00	0B/10	07-01	07-01	07-01
	HDD113-01	0B/11	07-02	07-02	
	HDD113-02	0B/12	07-03	07-03	07-03
	HDD113-03	0B/13	07-04	07-04	
	HDD113-04	0B/14	07-05	07-05	07-05
	HDD113-05	0B/15	07-06	07-06	
	HDD113-06	0B/16	07-07	07-07	07-07
	HDD113-07	0B/17	07-08	07-08	
	HDD113-08	0B/18	07-09	07-09	07-09
	HDD113-09	0B/19	07-10/Spare	07-10/Spare	07-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (29/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-114	HDD114-00	0C/10	08-01	07-01	07-01
	HDD114-01	0C/11	08-02	07-02	
	HDD114-02	0C/12	08-03	07-03	07-03
	HDD114-03	0C/13	08-04	07-04	
	HDD114-04	0C/14	08-05	07-05	07-05
	HDD114-05	0C/15	08-06	07-06	
	HDD114-06	0C/16	08-07	07-07	07-07
	HDD114-07	0C/17	08-08	07-08	
	HDD114-08	0C/18	08-09	07-09	07-09
	HDD114-09	0C/19	08-10/Spare	07-10/Spare	07-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (30/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-115	HDD115-00	0D/10	08-01	07-01	07-01
	HDD115-01	0D/11	08-02	07-02	
	HDD115-02	0D/12	08-03	07-03	07-03
	HDD115-03	0D/13	08-04	07-04	
	HDD115-04	0D/14	08-05	07-05	07-05
	HDD115-05	0D/15	08-06	07-06	
	HDD115-06	0D/16	08-07	07-07	07-07
	HDD115-07	0D/17	08-08	07-08	
	HDD115-08	0D/18	08-09	07-09	07-09
	HDD115-09	0D/19	08-10/Spare	07-10/Spare	07-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (31/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-116	HDD116-00	0E/10	08-01	07-01	07-01
	HDD116-01	0E/11	08-02	07-02	
	HDD116-02	0E/12	08-03	07-03	07-03
	HDD116-03	0E/13	08-04	07-04	
	HDD116-04	0E/14	08-05	07-05	07-05
	HDD116-05	0E/15	08-06	07-06	
	HDD116-06	0E/16	08-07	07-07	07-07
	HDD116-07	0E/17	08-08	07-08	
	HDD116-08	0E/18	08-09	07-09	07-09
	HDD116-09	0E/19	08-10/Spare	07-10/Spare	07-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (32/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-117	HDD117-00	0F/10	08-01	07-01	07-01
	HDD117-01	0F/11	08-02	07-02	
	HDD117-02	0F/12	08-03	07-03	07-03
	HDD117-03	0F/13	08-04	07-04	
	HDD117-04	0F/14	08-05	07-05	07-05
	HDD117-05	0F/15	08-06	07-06	
	HDD117-06	0F/16	08-07	07-07	07-07
	HDD117-07	0F/17	08-08	07-08	
	HDD117-08	0F/18	08-09	07-09	07-09
	HDD117-09	0F/19	08-10/Spare	07-10/Spare	07-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (33/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD020	HDD020-00	00/20	09-01	09-01	09-01
	HDD020-01	00/21	09-02	09-02	
	HDD020-02	00/22	09-03	09-03	09-03
	HDD020-03	00/23	09-04	09-04	
	HDD020-04	00/24	09-05	09-05	09-05
	HDD020-05	00/25	09-06	09-06	
	HDD020-06	00/26	09-07	09-07	09-07
	HDD020-07	00/27	09-08	09-08	
	HDD020-08	00/28	09-09	09-09	09-09
	HDD020-09	00/29	09-10/Spare	09-10/Spare	09-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (34/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD021	HDD021-00	01/20	09-01	09-01	09-01
	HDD021-01	01/21	09-02	09-02	
	HDD021-02	01/22	09-03	09-03	09-03
	HDD021-03	01/23	09-04	09-04	
	HDD021-04	01/24	09-05	09-05	09-05
	HDD021-05	01/25	09-06	09-06	
	HDD021-06	01/26	09-07	09-07	09-07
	HDD021-07	01/27	09-08	09-08	
	HDD021-08	01/28	09-09	09-09	09-09
	HDD021-09	01/29	09-10/Spare	09-10/Spare	09-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (35/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD022	HDD022-00	02/20	09-01	09-01	09-01
	HDD022-01	02/21	09-02	09-02	
	HDD022-02	02/22	09-03	09-03	09-03
	HDD022-03	02/23	09-04	09-04	
	HDD022-04	02/24	09-05	09-05	09-05
	HDD022-05	02/25	09-06	09-06	
	HDD022-06	02/26	09-07	09-07	09-07
	HDD022-07	02/27	09-08	09-08	
	HDD022-08	02/28	09-09	09-09	09-09
	HDD022-09	02/29	09-10/Spare	09-10/Spare	09-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (36/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD023	HDD023-00	03/20	09-01	09-01	09-01
	HDD023-01	03/21	09-02	09-02	
	HDD023-02	03/22	09-03	09-03	09-03
	HDD023-03	03/23	09-04	09-04	
	HDD023-04	03/24	09-05	09-05	09-05
	HDD023-05	03/25	09-06	09-06	
	HDD023-06	03/26	09-07	09-07	09-07
	HDD023-07	03/27	09-08	09-08	
	HDD023-08	03/28	09-09	09-09	09-09
	HDD023-09	03/29	09-10/Spare	09-10/Spare	09-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (37/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD024	HDD024-00	04/20	10-01	09-01	09-01
	HDD024-01	04/21	10-02	09-02	
	HDD024-02	04/22	10-03	09-03	09-03
	HDD024-03	04/23	10-04	09-04	
	HDD024-04	04/24	10-05	09-05	09-05
	HDD024-05	04/25	10-06	09-06	
	HDD024-06	04/26	10-07	09-07	09-07
	HDD024-07	04/27	10-08	09-08	
	HDD024-08	04/28	10-09	09-09	09-09
	HDD024-09	04/29	10-10/Spare	09-10/Spare	09-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (38/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD025	HDD025-00	05/20	10-01	09-01	09-01
	HDD025-01	05/21	10-02	09-02	
	HDD025-02	05/22	10-03	09-03	09-03
	HDD025-03	05/23	10-04	09-04	
	HDD025-04	05/24	10-05	09-05	09-05
	HDD025-05	05/25	10-06	09-06	
	HDD025-06	05/26	10-07	09-07	09-07
	HDD025-07	05/27	10-08	09-08	
	HDD025-08	05/28	10-09	09-09	09-09
	HDD025-09	05/29	10-10/Spare	09-10/Spare	09-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (39/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-026	HDD026-00	06/20	10-01	09-01	09-01
	HDD026-01	06/21	10-02	09-02	
	HDD026-02	06/22	10-03	09-03	09-03
	HDD026-03	06/23	10-04	09-04	
	HDD026-04	06/24	10-05	09-05	09-05
	HDD026-05	06/25	10-06	09-06	
	HDD026-06	06/26	10-07	09-07	09-07
	HDD026-07	06/27	10-08	09-08	
	HDD026-08	06/28	10-09	09-09	09-09
	HDD026-09	06/29	10-10/Spare	09-10/Spare	09-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (40/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-027	HDD027-00	07/20	10-01	09-01	09-01
	HDD027-01	07/21	10-02	09-02	
	HDD027-02	07/22	10-03	09-03	09-03
	HDD027-03	07/23	10-04	09-04	
	HDD027-04	07/24	10-05	09-05	09-05
	HDD027-05	07/25	10-06	09-06	
	HDD027-06	07/26	10-07	09-07	09-07
	HDD027-07	07/27	10-08	09-08	
	HDD027-08	07/28	10-09	09-09	09-09
	HDD027-09	07/29	10-10/Spare	09-10/Spare	09-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (41/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-120	HDD120-00	08/20	11-01	11-01	11-01
	HDD120-01	08/21	11-02	11-02	
	HDD120-02	08/22	11-03	11-03	11-03
	HDD120-03	08/23	11-04	11-04	
	HDD120-04	08/24	11-05	11-05	11-05
	HDD120-05	08/25	11-06	11-06	
	HDD120-06	08/26	11-07	11-07	11-07
	HDD120-07	08/27	11-08	11-08	
	HDD120-08	08/28	11-09	11-09	11-09
	HDD120-09	08/29	11-10/Spare	11-10/Spare	11-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (42/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-121	HDD121-00	09/20	11-01	11-01	11-01
	HDD121-01	09/21	11-02	11-02	
	HDD121-02	09/22	11-03	11-03	11-03
	HDD121-03	09/23	11-04	11-04	
	HDD121-04	09/24	11-05	11-05	11-05
	HDD121-05	09/25	11-06	11-06	
	HDD121-06	09/26	11-07	11-07	11-07
	HDD121-07	09/27	11-08	11-08	
	HDD121-08	09/28	11-09	11-09	11-09
	HDD121-09	09/29	11-10/Spare	11-10/Spare	11-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (43/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-122	HDD122-00	0A/20	11-01	11-01	11-01
	HDD122-01	0A/21	11-02	11-02	
	HDD122-02	0A/22	11-03	11-03	11-03
	HDD122-03	0A/23	11-04	11-04	
	HDD122-04	0A/24	11-05	11-05	11-05
	HDD122-05	0A/25	11-06	11-06	
	HDD122-06	0A/26	11-07	11-07	11-07
	HDD122-07	0A/27	11-08	11-08	
	HDD122-08	0A/28	11-09	11-09	11-09
	HDD122-09	0A/29	11-10/Spare	11-10/Spare	11-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (44/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-123	HDD123-00	0B/20	11-01	11-01	11-01
	HDD123-01	0B/21	11-02	11-02	
	HDD123-02	0B/22	11-03	11-03	11-03
	HDD123-03	0B/23	11-04	11-04	
	HDD123-04	0B/24	11-05	11-05	11-05
	HDD123-05	0B/25	11-06	11-06	
	HDD123-06	0B/26	11-07	11-07	11-07
	HDD123-07	0B/27	11-08	11-08	
	HDD123-08	0B/28	11-09	11-09	11-09
	HDD123-09	0B/29	11-10/Spare	11-10/Spare	11-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (45/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-124	HDD124-00	0C/20	12-01	11-01	11-01
	HDD124-01	0C/21	12-02	11-02	
	HDD124-02	0C/22	12-03	11-03	11-03
	HDD124-03	0C/23	12-04	11-04	
	HDD124-04	0C/24	12-05	11-05	11-05
	HDD124-05	0C/25	12-06	11-06	
	HDD124-06	0C/26	12-07	11-07	11-07
	HDD124-07	0C/27	12-08	11-08	
	HDD124-08	0C/28	12-09	11-09	11-09
	HDD124-09	0C/29	12-10/Spare	11-10/Spare	11-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (46/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-125	HDD125-00	0D/20	12-01	11-01	11-01
	HDD125-01	0D/21	12-02	11-02	
	HDD125-02	0D/22	12-03	11-03	11-03
	HDD125-03	0D/23	12-04	11-04	
	HDD125-04	0D/24	12-05	11-05	11-05
	HDD125-05	0D/25	12-06	11-06	
	HDD125-06	0D/26	12-07	11-07	11-07
	HDD125-07	0D/27	12-08	11-08	
	HDD125-08	0D/28	12-09	11-09	11-09
	HDD125-09	0D/29	12-10/Spare	11-10/Spare	11-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (47/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-126	HDD126-00	0E/20	12-01	11-01	11-01
	HDD126-01	0E/21	12-02	11-02	
	HDD126-02	0E/22	12-03	11-03	11-03
	HDD126-03	0E/23	12-04	11-04	
	HDD126-04	0E/24	12-05	11-05	11-05
	HDD126-05	0E/25	12-06	11-06	
	HDD126-06	0E/26	12-07	11-07	11-07
	HDD126-07	0E/27	12-08	11-08	
	HDD126-08	0E/28	12-09	11-09	11-09
	HDD126-09	0E/29	12-10/Spare	11-10/Spare	11-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (48/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-127	HDD127-00	0F/20	12-01	11-01	11-01
	HDD127-01	0F/21	12-02	11-02	
	HDD127-02	0F/22	12-03	11-03	11-03
	HDD127-03	0F/23	12-04	11-04	
	HDD127-04	0F/24	12-05	11-05	11-05
	HDD127-05	0F/25	12-06	11-06	
	HDD127-06	0F/26	12-07	11-07	11-07
	HDD127-07	0F/27	12-08	11-08	
	HDD127-08	0F/28	12-09	11-09	11-09
	HDD127-09	0F/29	12-10/Spare	11-10/Spare	11-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (49/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD030	HDD030-00	00/30	13-01	13-01	13-01
	HDD030-01	00/31	13-02	13-02	13-03
	HDD030-02	00/32	13-03	13-03	
	HDD030-03	00/33	13-04	13-04	
	HDD030-04	00/34	13-05	13-05	13-05
	HDD030-05	00/35	13-06	13-06	13-07
	HDD030-06	00/36	13-07	13-07	
	HDD030-07	00/37	13-08	13-08	
	HDD030-08	00/38	13-09	13-09	13-09
	HDD030-09	00/39	13-10/Spare	13-10/Spare	13-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (50/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD031	HDD031-00	01/30	13-01	13-01	13-01
	HDD031-01	01/31	13-02	13-02	13-03
	HDD031-02	01/32	13-03	13-03	
	HDD031-03	01/33	13-04	13-04	
	HDD031-04	01/34	13-05	13-05	13-05
	HDD031-05	01/35	13-06	13-06	13-07
	HDD031-06	01/36	13-07	13-07	
	HDD031-07	01/37	13-08	13-08	
	HDD031-08	01/38	13-09	13-09	13-09
	HDD031-09	01/39	13-10/Spare	13-10/Spare	13-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (51/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD032	HDD032-00	02/30	13-01	13-01	13-01
	HDD032-01	02/31	13-02	13-02	
	HDD032-02	02/32	13-03	13-03	13-03
	HDD032-03	02/33	13-04	13-04	
	HDD032-04	02/34	13-05	13-05	13-05
	HDD032-05	02/35	13-06	13-06	
	HDD032-06	02/36	13-07	13-07	13-07
	HDD032-07	02/37	13-08	13-08	
	HDD032-08	02/38	13-09	13-09	13-09
	HDD032-09	02/39	13-10/Spare	13-10/Spare	13-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (52/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD033	HDD033-00	03/30	13-01	13-01	13-01
	HDD033-01	03/31	13-02	13-02	
	HDD033-02	03/32	13-03	13-03	13-03
	HDD033-03	03/33	13-04	13-04	
	HDD033-04	03/34	13-05	13-05	13-05
	HDD033-05	03/35	13-06	13-06	
	HDD033-06	03/36	13-07	13-07	13-07
	HDD033-07	03/37	13-08	13-08	
	HDD033-08	03/38	13-09	13-09	13-09
	HDD033-09	03/39	13-10/Spare	13-10/Spare	13-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (53/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD034	HDD034-00	04/30	14-01	13-01	13-01
	HDD034-01	04/31	14-02	13-02	
	HDD034-02	04/32	14-03	13-03	13-03
	HDD034-03	04/33	14-04	13-04	
	HDD034-04	04/34	14-05	13-05	13-05
	HDD034-05	04/35	14-06	13-06	
	HDD034-06	04/36	14-07	13-07	13-07
	HDD034-07	04/37	14-08	13-08	
	HDD034-08	04/38	14-09	13-09	13-09
	HDD034-09	04/39	14-10/Spare	13-10/Spare	13-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (54/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD035	HDD035-00	05/30	14-01	13-01	13-01
	HDD035-01	05/31	14-02	13-02	
	HDD035-02	05/32	14-03	13-03	13-03
	HDD035-03	05/33	14-04	13-04	
	HDD035-04	05/34	14-05	13-05	13-05
	HDD035-05	05/35	14-06	13-06	
	HDD035-06	05/36	14-07	13-07	13-07
	HDD035-07	05/37	14-08	13-08	
	HDD035-08	05/38	14-09	13-09	13-09
	HDD035-09	05/39	14-10/Spare	13-10/Spare	13-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (55/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-036	HDD036-00	06/30	14-01	13-01	13-01
	HDD036-01	06/31	14-02	13-02	
	HDD036-02	06/32	14-03	13-03	13-03
	HDD036-03	06/33	14-04	13-04	
	HDD036-04	06/34	14-05	13-05	13-05
	HDD036-05	06/35	14-06	13-06	
	HDD036-06	06/36	14-07	13-07	13-07
	HDD036-07	06/37	14-08	13-08	
	HDD036-08	06/38	14-09	13-09	13-09
	HDD036-09	06/39	14-10/Spare	13-10/Spare	13-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (56/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-037	HDD037-00	07/30	14-01	13-01	13-01
	HDD037-01	07/31	14-02	13-02	
	HDD037-02	07/32	14-03	13-03	13-03
	HDD037-03	07/33	14-04	13-04	
	HDD037-04	07/34	14-05	13-05	13-05
	HDD037-05	07/35	14-06	13-06	
	HDD037-06	07/36	14-07	13-07	13-07
	HDD037-07	07/37	14-08	13-08	
	HDD037-08	07/38	14-09	13-09	13-09
	HDD037-09	07/39	14-10/Spare	13-10/Spare	13-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (57/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-130	HDD130-00	08/30	15-01	15-01	15-01
	HDD130-01	08/31	15-02	15-02	
	HDD130-02	08/32	15-03	15-03	15-03
	HDD130-03	08/33	15-04	15-04	
	HDD130-04	08/34	15-05	15-05	15-05
	HDD130-05	08/35	15-06	15-06	
	HDD130-06	08/36	15-07	15-07	15-07
	HDD130-07	08/37	15-08	15-08	
	HDD130-08	08/38	15-09	15-09	15-09
	HDD130-09	08/39	15-10/Spare	15-10/Spare	15-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (58/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-131	HDD131-00	09/30	15-01	15-01	15-01
	HDD131-01	09/31	15-02	15-02	
	HDD131-02	09/32	15-03	15-03	15-03
	HDD131-03	09/33	15-04	15-04	
	HDD131-04	09/34	15-05	15-05	15-05
	HDD131-05	09/35	15-06	15-06	
	HDD131-06	09/36	15-07	15-07	15-07
	HDD131-07	09/37	15-08	15-08	
	HDD131-08	09/38	15-09	15-09	15-09
	HDD131-09	09/39	15-10/Spare	15-10/Spare	15-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (59/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-132	HDD132-00	0A/30	15-01	15-01	15-01
	HDD132-01	0A/31	15-02	15-02	
	HDD132-02	0A/32	15-03	15-03	15-03
	HDD132-03	0A/33	15-04	15-04	
	HDD132-04	0A/34	15-05	15-05	15-05
	HDD132-05	0A/35	15-06	15-06	
	HDD132-06	0A/36	15-07	15-07	15-07
	HDD132-07	0A/37	15-08	15-08	
	HDD132-08	0A/38	15-09	15-09	15-09
	HDD132-09	0A/39	15-10/Spare	15-10/Spare	15-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (60/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-133	HDD133-00	0B/30	15-01	15-01	15-01
	HDD133-01	0B/31	15-02	15-02	
	HDD133-02	0B/32	15-03	15-03	15-03
	HDD133-03	0B/33	15-04	15-04	
	HDD133-04	0B/34	15-05	15-05	15-05
	HDD133-05	0B/35	15-06	15-06	
	HDD133-06	0B/36	15-07	15-07	15-07
	HDD133-07	0B/37	15-08	15-08	
	HDD133-08	0B/38	15-09	15-09	15-09
	HDD133-09	0B/39	15-10/Spare	15-10/Spare	15-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (61/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-134	HDD134-00	0C/30	16-01	15-01	15-01
	HDD134-01	0C/31	16-02	15-02	
	HDD134-02	0C/32	16-03	15-03	15-03
	HDD134-03	0C/33	16-04	15-04	
	HDD134-04	0C/34	16-05	15-05	15-05
	HDD134-05	0C/35	16-06	15-06	
	HDD134-06	0C/36	16-07	15-07	15-07
	HDD134-07	0C/37	16-08	15-08	
	HDD134-08	0C/38	16-09	15-09	15-09
	HDD134-09	0C/39	16-10/Spare	15-10/Spare	15-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (62/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-135	HDD135-00	0D/30	16-01	15-01	15-01
	HDD135-01	0D/31	16-02	15-02	
	HDD135-02	0D/32	16-03	15-03	15-03
	HDD135-03	0D/33	16-04	15-04	
	HDD135-04	0D/34	16-05	15-05	15-05
	HDD135-05	0D/35	16-06	15-06	
	HDD135-06	0D/36	16-07	15-07	15-07
	HDD135-07	0D/37	16-08	15-08	
	HDD135-08	0D/38	16-09	15-09	15-09
	HDD135-09	0D/39	16-10/Spare	15-10/Spare	15-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (63/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-136	HDD136-00	0E/30	16-01	15-01	15-01
	HDD136-01	0E/31	16-02	15-02	
	HDD136-02	0E/32	16-03	15-03	15-03
	HDD136-03	0E/33	16-04	15-04	
	HDD136-04	0E/34	16-05	15-05	15-05
	HDD136-05	0E/35	16-06	15-06	
	HDD136-06	0E/36	16-07	15-07	15-07
	HDD136-07	0E/37	16-08	15-08	
	HDD136-08	0E/38	16-09	15-09	15-09
	HDD136-09	0E/39	16-10/Spare	15-10/Spare	15-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (64/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-137	HDD137-00	0F/30	16-01	15-01	15-01
	HDD137-01	0F/31	16-02	15-02	
	HDD137-02	0F/32	16-03	15-03	15-03
	HDD137-03	0F/33	16-04	15-04	
	HDD137-04	0F/34	16-05	15-05	15-05
	HDD137-05	0F/35	16-06	15-06	
	HDD137-06	0F/36	16-07	15-07	15-07
	HDD137-07	0F/37	16-08	15-08	
	HDD137-08	0F/38	16-09	15-09	15-09
	HDD137-09	0F/39	16-10/Spare	15-10/Spare	15-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (65/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-040	HDD040-00	00/40	17-01	17-01	17-01
	HDD040-01	00/41	17-02	17-02	
	HDD040-02	00/42	17-03	17-03	17-03
	HDD040-03	00/43	17-04	17-04	
	HDD040-04	00/44	17-05	17-05	17-05
	HDD040-05	00/45	17-06	17-06	
	HDD040-06	00/46	17-07	17-07	17-07
	HDD040-07	00/47	17-08	17-08	
	HDD040-08	00/48	17-09	17-09	17-09
	HDD040-09	00/49	17-10/Spare	17-10/Spare	17-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (66/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-041	HDD041-00	01/40	17-01	17-01	17-01
	HDD041-01	01/41	17-02	17-02	
	HDD041-02	01/42	17-03	17-03	17-03
	HDD041-03	01/43	17-04	17-04	
	HDD041-04	01/44	17-05	17-05	17-05
	HDD041-05	01/45	17-06	17-06	
	HDD041-06	01/46	17-07	17-07	17-07
	HDD041-07	01/47	17-08	17-08	
	HDD041-08	01/48	17-09	17-09	17-09
	HDD041-09	01/49	17-10/Spare	17-10/Spare	17-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (67/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-042	HDD042-00	02/40	17-01	17-01	17-01
	HDD042-01	02/41	17-02	17-02	
	HDD042-02	02/42	17-03	17-03	17-03
	HDD042-03	02/43	17-04	17-04	
	HDD042-04	02/44	17-05	17-05	17-05
	HDD042-05	02/45	17-06	17-06	
	HDD042-06	02/46	17-07	17-07	17-07
	HDD042-07	02/47	17-08	17-08	
	HDD042-08	02/48	17-09	17-09	17-09
	HDD042-09	02/49	17-10/Spare	17-10/Spare	17-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (68/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-043	HDD043-00	03/40	17-01	17-01	17-01
	HDD043-01	03/41	17-02	17-02	
	HDD043-02	03/42	17-03	17-03	17-03
	HDD043-03	03/43	17-04	17-04	
	HDD043-04	03/44	17-05	17-05	17-05
	HDD043-05	03/45	17-06	17-06	
	HDD043-06	03/46	17-07	17-07	17-07
	HDD043-07	03/47	17-08	17-08	
	HDD043-08	03/48	17-09	17-09	17-09
	HDD043-09	03/49	17-10/Spare	17-10/Spare	17-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (69/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD044	HDD044-00	04/40	18-01	17-01	17-01
	HDD044-01	04/41	18-02	17-02	
	HDD044-02	04/42	18-03	17-03	17-03
	HDD044-03	04/43	18-04	17-04	
	HDD044-04	04/44	18-05	17-05	17-05
	HDD044-05	04/45	18-06	17-06	
	HDD044-06	04/46	18-07	17-07	17-07
	HDD044-07	04/47	18-08	17-08	
	HDD044-08	04/48	18-09	17-09	17-09
	HDD044-09	04/49	18-10/Spare	17-10/Spare	17-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (70/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD045	HDD045-00	05/40	18-01	17-01	17-01
	HDD045-01	05/41	18-02	17-02	
	HDD045-02	05/42	18-03	17-03	17-03
	HDD045-03	05/43	18-04	17-04	
	HDD045-04	05/44	18-05	17-05	17-05
	HDD045-05	05/45	18-06	17-06	
	HDD045-06	05/46	18-07	17-07	17-07
	HDD045-07	05/47	18-08	17-08	
	HDD045-08	05/48	18-09	17-09	17-09
	HDD045-09	05/49	18-10/Spare	17-10/Spare	17-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (71/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD046	HDD046-00	06/40	18-01	17-01	17-01
	HDD046-01	06/41	18-02	17-02	
	HDD046-02	06/42	18-03	17-03	17-03
	HDD046-03	06/43	18-04	17-04	
	HDD046-04	06/44	18-05	17-05	17-05
	HDD046-05	06/45	18-06	17-06	
	HDD046-06	06/46	18-07	17-07	17-07
	HDD046-07	06/47	18-08	17-08	
	HDD046-08	06/48	18-09	17-09	17-09
	HDD046-09	06/49	18-10/Spare	17-10/Spare	17-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (72/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD047	HDD047-00	07/40	18-01	17-01	17-01
	HDD047-01	07/41	18-02	17-02	
	HDD047-02	07/42	18-03	17-03	17-03
	HDD047-03	07/43	18-04	17-04	
	HDD047-04	07/44	18-05	17-05	17-05
	HDD047-05	07/45	18-06	17-06	
	HDD047-06	07/46	18-07	17-07	17-07
	HDD047-07	07/47	18-08	17-08	
	HDD047-08	07/48	18-09	17-09	17-09
	HDD047-09	07/49	18-10/Spare	17-10/Spare	17-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (73/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-140	HDD140-00	08/40	19-01	19-01	19-01
	HDD140-01	08/41	19-02	19-02	
	HDD140-02	08/42	19-03	19-03	19-03
	HDD140-03	08/43	19-04	19-04	
	HDD140-04	08/44	19-05	19-05	19-05
	HDD140-05	08/45	19-06	19-06	
	HDD140-06	08/46	19-07	19-07	19-07
	HDD140-07	08/47	19-08	19-08	
	HDD140-08	08/48	19-09	19-09	19-09
	HDD140-09	08/49	19-10/Spare	19-10/Spare	19-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (74/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-141	HDD141-00	09/40	19-01	19-01	19-01
	HDD141-01	09/41	19-02	19-02	
	HDD141-02	09/42	19-03	19-03	19-03
	HDD141-03	09/43	19-04	19-04	
	HDD141-04	09/44	19-05	19-05	19-05
	HDD141-05	09/45	19-06	19-06	
	HDD141-06	09/46	19-07	19-07	19-07
	HDD141-07	09/47	19-08	19-08	
	HDD141-08	09/48	19-09	19-09	19-09
	HDD141-09	09/49	19-10/Spare	19-10/Spare	19-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (75/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-142	HDD142-00	0A/40	19-01	19-01	19-01
	HDD142-01	0A/41	19-02	19-02	
	HDD142-02	0A/42	19-03	19-03	19-03
	HDD142-03	0A/43	19-04	19-04	
	HDD142-04	0A/44	19-05	19-05	19-05
	HDD142-05	0A/45	19-06	19-06	
	HDD142-06	0A/46	19-07	19-07	19-07
	HDD142-07	0A/47	19-08	19-08	
	HDD142-08	0A/48	19-09	19-09	19-09
	HDD142-09	0A/49	19-10/Spare	19-10/Spare	19-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (76/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-143	HDD143-00	0B/40	19-01	19-01	19-01
	HDD143-01	0B/41	19-02	19-02	
	HDD143-02	0B/42	19-03	19-03	19-03
	HDD143-03	0B/43	19-04	19-04	
	HDD143-04	0B/44	19-05	19-05	19-05
	HDD143-05	0B/45	19-06	19-06	
	HDD143-06	0B/46	19-07	19-07	19-07
	HDD143-07	0B/47	19-08	19-08	
	HDD143-08	0B/48	19-09	19-09	19-09
	HDD143-09	0B/49	19-10/Spare	19-10/Spare	19-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (77/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-144	HDD144-00	0C/40	20-01	19-01	19-01
	HDD144-01	0C/41	20-02	19-02	
	HDD144-02	0C/42	20-03	19-03	19-03
	HDD144-03	0C/43	20-04	19-04	
	HDD144-04	0C/44	20-05	19-05	19-05
	HDD144-05	0C/45	20-06	19-06	
	HDD144-06	0C/46	20-07	19-07	19-07
	HDD144-07	0C/47	20-08	19-08	
	HDD144-08	0C/48	20-09	19-09	19-09
	HDD144-09	0C/49	20-10/Spare	19-10/Spare	19-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (78/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-145	HDD145-00	0D/40	20-01	19-01	19-01
	HDD145-01	0D/41	20-02	19-02	
	HDD145-02	0D/42	20-03	19-03	19-03
	HDD145-03	0D/43	20-04	19-04	
	HDD145-04	0D/44	20-05	19-05	19-05
	HDD145-05	0D/45	20-06	19-06	
	HDD145-06	0D/46	20-07	19-07	19-07
	HDD145-07	0D/47	20-08	19-08	
	HDD145-08	0D/48	20-09	19-09	19-09
	HDD145-09	0D/49	20-10/Spare	19-10/Spare	19-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (79/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-146	HDD146-00	0E/40	20-01	19-01	19-01
	HDD146-01	0E/41	20-02	19-02	
	HDD146-02	0E/42	20-03	19-03	19-03
	HDD146-03	0E/43	20-04	19-04	
	HDD146-04	0E/44	20-05	19-05	19-05
	HDD146-05	0E/45	20-06	19-06	
	HDD146-06	0E/46	20-07	19-07	19-07
	HDD146-07	0E/47	20-08	19-08	
	HDD146-08	0E/48	20-09	19-09	19-09
	HDD146-09	0E/49	20-10/Spare	19-10/Spare	19-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (80/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-147	HDD147-00	0F/40	20-01	19-01	19-01
	HDD147-01	0F/41	20-02	19-02	
	HDD147-02	0F/42	20-03	19-03	19-03
	HDD147-03	0F/43	20-04	19-04	
	HDD147-04	0F/44	20-05	19-05	19-05
	HDD147-05	0F/45	20-06	19-06	
	HDD147-06	0F/46	20-07	19-07	19-07
	HDD147-07	0F/47	20-08	19-08	
	HDD147-08	0F/48	20-09	19-09	19-09
	HDD147-09	0F/49	20-10/Spare	19-10/Spare	19-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (81/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD050	HDD050-00	00/50	21-01	21-01	21-01
	HDD050-01	00/51	21-02	21-02	
	HDD050-02	00/52	21-03	21-03	21-03
	HDD050-03	00/53	21-04	21-04	
	HDD050-04	00/54	21-05	21-05	21-05
	HDD050-05	00/55	21-06	21-06	
	HDD050-06	00/56	21-07	21-07	21-07
	HDD050-07	00/57	21-08	21-08	
	HDD050-08	00/58	21-09	21-09	21-09
	HDD050-09	00/59	21-10/Spare	21-10/Spare	21-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (82/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD051	HDD051-00	01/50	21-01	21-01	21-01
	HDD051-01	01/51	21-02	21-02	
	HDD051-02	01/52	21-03	21-03	21-03
	HDD051-03	01/53	21-04	21-04	
	HDD051-04	01/54	21-05	21-05	21-05
	HDD051-05	01/55	21-06	21-06	
	HDD051-06	01/56	21-07	21-07	21-07
	HDD051-07	01/57	21-08	21-08	
	HDD051-08	01/58	21-09	21-09	21-09
	HDD051-09	01/59	21-10/Spare	21-10/Spare	21-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (83/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD052	HDD052-00	02/50	21-01	21-01	21-01
	HDD052-01	02/51	21-02	21-02	
	HDD052-02	02/52	21-03	21-03	21-03
	HDD052-03	02/53	21-04	21-04	
	HDD052-04	02/54	21-05	21-05	21-05
	HDD052-05	02/55	21-06	21-06	
	HDD052-06	02/56	21-07	21-07	21-07
	HDD052-07	02/57	21-08	21-08	
	HDD052-08	02/58	21-09	21-09	21-09
	HDD052-09	02/59	21-10/Spare	21-10/Spare	21-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (84/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD053	HDD053-00	03/50	21-01	21-01	21-01
	HDD053-01	03/51	21-02	21-02	
	HDD053-02	03/52	21-03	21-03	21-03
	HDD053-03	03/53	21-04	21-04	
	HDD053-04	03/54	21-05	21-05	21-05
	HDD053-05	03/55	21-06	21-06	
	HDD053-06	03/56	21-07	21-07	21-07
	HDD053-07	03/57	21-08	21-08	
	HDD053-08	03/58	21-09	21-09	21-09
	HDD053-09	03/59	21-10/Spare	21-10/Spare	21-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (85/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD054	HDD054-00	04/50	22-01	21-01	21-01
	HDD054-01	04/51	22-02	21-02	
	HDD054-02	04/52	22-03	21-03	21-03
	HDD054-03	04/53	22-04	21-04	
	HDD054-04	04/54	22-05	21-05	21-05
	HDD054-05	04/55	22-06	21-06	
	HDD054-06	04/56	22-07	21-07	21-07
	HDD054-07	04/57	22-08	21-08	
	HDD054-08	04/58	22-09	21-09	21-09
	HDD054-09	04/59	22-10/Spare	21-10/Spare	21-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (86/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD055	HDD055-00	05/50	22-01	21-01	21-01
	HDD055-01	05/51	22-02	21-02	
	HDD055-02	05/52	22-03	21-03	21-03
	HDD055-03	05/53	22-04	21-04	
	HDD055-04	05/54	22-05	21-05	21-05
	HDD055-05	05/55	22-06	21-06	
	HDD055-06	05/56	22-07	21-07	21-07
	HDD055-07	05/57	22-08	21-08	
	HDD055-08	05/58	22-09	21-09	21-09
	HDD055-09	05/59	22-10/Spare	21-10/Spare	21-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (87/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD056	HDD056-00	06/50	22-01	21-01	21-01
	HDD056-01	06/51	22-02	21-02	
	HDD056-02	06/52	22-03	21-03	21-03
	HDD056-03	06/53	22-04	21-04	
	HDD056-04	06/54	22-05	21-05	21-05
	HDD056-05	06/55	22-06	21-06	
	HDD056-06	06/56	22-07	21-07	21-07
	HDD056-07	06/57	22-08	21-08	
	HDD056-08	06/58	22-09	21-09	21-09
	HDD056-09	06/59	22-10/Spare	21-10/Spare	21-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (88/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD057	HDD057-00	07/50	22-01	21-01	21-01
	HDD057-01	07/51	22-02	21-02	
	HDD057-02	07/52	22-03	21-03	21-03
	HDD057-03	07/53	22-04	21-04	
	HDD057-04	07/54	22-05	21-05	21-05
	HDD057-05	07/55	22-06	21-06	
	HDD057-06	07/56	22-07	21-07	21-07
	HDD057-07	07/57	22-08	21-08	
	HDD057-08	07/58	22-09	21-09	21-09
	HDD057-09	07/59	22-10/Spare	21-10/Spare	21-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (89/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-150	HDD150-00	08/50	23-01	23-01	23-01
	HDD150-01	08/51	23-02	23-02	
	HDD150-02	08/52	23-03	23-03	23-03
	HDD150-03	08/53	23-04	23-04	
	HDD150-04	08/54	23-05	23-05	23-05
	HDD150-05	08/55	23-06	23-06	
	HDD150-06	08/56	23-07	23-07	23-07
	HDD150-07	08/57	23-08	23-08	
	HDD150-08	08/58	23-09	23-09	23-09
	HDD150-09	08/59	23-10/Spare	23-10/Spare	23-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (90/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-151	HDD151-00	09/50	23-01	23-01	23-01
	HDD151-01	09/51	23-02	23-02	
	HDD151-02	09/52	23-03	23-03	23-03
	HDD151-03	09/53	23-04	23-04	
	HDD151-04	09/54	23-05	23-05	23-05
	HDD151-05	09/55	23-06	23-06	
	HDD151-06	09/56	23-07	23-07	23-07
	HDD151-07	09/57	23-08	23-08	
	HDD151-08	09/58	23-09	23-09	23-09
	HDD151-09	09/59	23-10/Spare	23-10/Spare	23-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (91/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-152	HDD152-00	0A/50	23-01	23-01	23-01
	HDD152-01	0A/51	23-02	23-02	
	HDD152-02	0A/52	23-03	23-03	23-03
	HDD152-03	0A/53	23-04	23-04	
	HDD152-04	0A/54	23-05	23-05	23-05
	HDD152-05	0A/55	23-06	23-06	
	HDD152-06	0A/56	23-07	23-07	23-07
	HDD152-07	0A/57	23-08	23-08	
	HDD152-08	0A/58	23-09	23-09	23-09
	HDD152-09	0A/59	23-10/Spare	23-10/Spare	23-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (92/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-153	HDD153-00	0B/50	23-01	23-01	23-01
	HDD153-01	0B/51	23-02	23-02	
	HDD153-02	0B/52	23-03	23-03	23-03
	HDD153-03	0B/53	23-04	23-04	
	HDD153-04	0B/54	23-05	23-05	23-05
	HDD153-05	0B/55	23-06	23-06	
	HDD153-06	0B/56	23-07	23-07	23-07
	HDD153-07	0B/57	23-08	23-08	
	HDD153-08	0B/58	23-09	23-09	23-09
	HDD153-09	0B/59	23-10/Spare	23-10/Spare	23-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (93/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-154	HDD154-00	0C/50	24-01	23-01	23-01
	HDD154-01	0C/51	24-02	23-02	
	HDD154-02	0C/52	24-03	23-03	23-03
	HDD154-03	0C/53	24-04	23-04	
	HDD154-04	0C/54	24-05	23-05	23-05
	HDD154-05	0C/55	24-06	23-06	
	HDD154-06	0C/56	24-07	23-07	23-07
	HDD154-07	0C/57	24-08	23-08	
	HDD154-08	0C/58	24-09	23-09	23-09
	HDD154-09	0C/59	24-10/Spare	23-10/Spare	23-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (94/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-155	HDD155-00	0D/50	24-01	23-01	23-01
	HDD155-01	0D/51	24-02	23-02	
	HDD155-02	0D/52	24-03	23-03	23-03
	HDD155-03	0D/53	24-04	23-04	
	HDD155-04	0D/54	24-05	23-05	23-05
	HDD155-05	0D/55	24-06	23-06	
	HDD155-06	0D/56	24-07	23-07	23-07
	HDD155-07	0D/57	24-08	23-08	
	HDD155-08	0D/58	24-09	23-09	23-09
	HDD155-09	0D/59	24-10/Spare	23-10/Spare	23-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (95/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-156	HDD156-00	0E/50	24-01	23-01	23-01
	HDD156-01	0E/51	24-02	23-02	
	HDD156-02	0E/52	24-03	23-03	23-03
	HDD156-03	0E/53	24-04	23-04	
	HDD156-04	0E/54	24-05	23-05	23-05
	HDD156-05	0E/55	24-06	23-06	
	HDD156-06	0E/56	24-07	23-07	23-07
	HDD156-07	0E/57	24-08	23-08	
	HDD156-08	0E/58	24-09	23-09	23-09
	HDD156-09	0E/59	24-10/Spare	23-10/Spare	23-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (96/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-157	HDD157-00	0F/50	24-01	23-01	23-01
	HDD157-01	0F/51	24-02	23-02	
	HDD157-02	0F/52	24-03	23-03	23-03
	HDD157-03	0F/53	24-04	23-04	
	HDD157-04	0F/54	24-05	23-05	23-05
	HDD157-05	0F/55	24-06	23-06	
	HDD157-06	0F/56	24-07	23-07	23-07
	HDD157-07	0F/57	24-08	23-08	
	HDD157-08	0F/58	24-09	23-09	23-09
	HDD157-09	0F/59	24-10/Spare	23-10/Spare	23-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (97/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-060	HDD060-00	00/60	25-01	25-01	25-01
	HDD060-01	00/61	25-02	25-02	
	HDD060-02	00/62	25-03	25-03	25-03
	HDD060-03	00/63	25-04	25-04	
	HDD060-04	00/64	25-05	25-05	25-05
	HDD060-05	00/65	25-06	25-06	
	HDD060-06	00/66	25-07	25-07	25-07
	HDD060-07	00/67	25-08	25-08	
	HDD060-08	00/68	25-09	25-09	25-09
	HDD060-09	00/69	25-10/Spare	25-10/Spare	25-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (98/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-061	HDD061-00	01/60	25-01	25-01	25-01
	HDD061-01	01/61	25-02	25-02	
	HDD061-02	01/62	25-03	25-03	25-03
	HDD061-03	01/63	25-04	25-04	
	HDD061-04	01/64	25-05	25-05	25-05
	HDD061-05	01/65	25-06	25-06	
	HDD061-06	01/66	25-07	25-07	25-07
	HDD061-07	01/67	25-08	25-08	
	HDD061-08	01/68	25-09	25-09	25-09
	HDD061-09	01/69	25-10/Spare	25-10/Spare	25-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (99/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD062	HDD062-00	02/60	25-01	25-01	25-01
	HDD062-01	02/61	25-02	25-02	
	HDD062-02	02/62	25-03	25-03	25-03
	HDD062-03	02/63	25-04	25-04	
	HDD062-04	02/64	25-05	25-05	25-05
	HDD062-05	02/65	25-06	25-06	
	HDD062-06	02/66	25-07	25-07	25-07
	HDD062-07	02/67	25-08	25-08	
	HDD062-08	02/68	25-09	25-09	25-09
	HDD062-09	02/69	25-10/Spare	25-10/Spare	25-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (100/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD063	HDD063-00	03/60	25-01	25-01	25-01
	HDD063-01	03/61	25-02	25-02	
	HDD063-02	03/62	25-03	25-03	25-03
	HDD063-03	03/63	25-04	25-04	
	HDD063-04	03/64	25-05	25-05	25-05
	HDD063-05	03/65	25-06	25-06	
	HDD063-06	03/66	25-07	25-07	25-07
	HDD063-07	03/67	25-08	25-08	
	HDD063-08	03/68	25-09	25-09	25-09
	HDD063-09	03/69	25-10/Spare	25-10/Spare	25-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (101/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-064	HDD064-00	04/60	26-01	25-01	25-01
	HDD064-01	04/61	26-02	25-02	
	HDD064-02	04/62	26-03	25-03	25-03
	HDD064-03	04/63	26-04	25-04	
	HDD064-04	04/64	26-05	25-05	25-05
	HDD064-05	04/65	26-06	25-06	
	HDD064-06	04/66	26-07	25-07	25-07
	HDD064-07	04/67	26-08	25-08	
	HDD064-08	04/68	26-09	25-09	25-09
	HDD064-09	04/69	26-10/Spare	25-10/Spare	25-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (102/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-065	HDD065-00	05/60	26-01	25-01	25-01
	HDD065-01	05/61	26-02	25-02	
	HDD065-02	05/62	26-03	25-03	25-03
	HDD065-03	05/63	26-04	25-04	
	HDD065-04	05/64	26-05	25-05	25-05
	HDD065-05	05/65	26-06	25-06	
	HDD065-06	05/66	26-07	25-07	25-07
	HDD065-07	05/67	26-08	25-08	
	HDD065-08	05/68	26-09	25-09	25-09
	HDD065-09	05/69	26-10/Spare	25-10/Spare	25-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (103/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD066	HDD066-00	06/60	26-01	25-01	25-01
	HDD066-01	06/61	26-02	25-02	
	HDD066-02	06/62	26-03	25-03	25-03
	HDD066-03	06/63	26-04	25-04	
	HDD066-04	06/64	26-05	25-05	25-05
	HDD066-05	06/65	26-06	25-06	
	HDD066-06	06/66	26-07	25-07	25-07
	HDD066-07	06/67	26-08	25-08	
	HDD066-08	06/68	26-09	25-09	25-09
	HDD066-09	06/69	26-10/Spare	25-10/Spare	25-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (104/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD067	HDD067-00	07/60	26-01	25-01	25-01
	HDD067-01	07/61	26-02	25-02	
	HDD067-02	07/62	26-03	25-03	25-03
	HDD067-03	07/63	26-04	25-04	
	HDD067-04	07/64	26-05	25-05	25-05
	HDD067-05	07/65	26-06	25-06	
	HDD067-06	07/66	26-07	25-07	25-07
	HDD067-07	07/67	26-08	25-08	
	HDD067-08	07/68	26-09	25-09	25-09
	HDD067-09	07/69	26-10/Spare	25-10/Spare	25-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (105/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-160	HDD160-00	08/60	27-01	27-01	27-01
	HDD160-01	08/61	27-02	27-02	
	HDD160-02	08/62	27-03	27-03	27-03
	HDD160-03	08/63	27-04	27-04	
	HDD160-04	08/64	27-05	27-05	27-05
	HDD160-05	08/65	27-06	27-06	
	HDD160-06	08/66	27-07	27-07	27-07
	HDD160-07	08/67	27-08	27-08	
	HDD160-08	08/68	27-09	27-09	27-09
	HDD160-09	08/69	27-10/Spare	27-10/Spare	27-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (106/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-161	HDD161-00	09/60	27-01	27-01	27-01
	HDD161-01	09/61	27-02	27-02	
	HDD161-02	09/62	27-03	27-03	27-03
	HDD161-03	09/63	27-04	27-04	
	HDD161-04	09/64	27-05	27-05	27-05
	HDD161-05	09/65	27-06	27-06	
	HDD161-06	09/66	27-07	27-07	27-07
	HDD161-07	09/67	27-08	27-08	
	HDD161-08	09/68	27-09	27-09	27-09
	HDD161-09	09/69	27-10/Spare	27-10/Spare	27-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (107/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-162	HDD162-00	0A/60	27-01	27-01	27-01
	HDD162-01	0A/61	27-02	27-02	
	HDD162-02	0A/62	27-03	27-03	27-03
	HDD162-03	0A/63	27-04	27-04	
	HDD162-04	0A/64	27-05	27-05	27-05
	HDD162-05	0A/65	27-06	27-06	
	HDD162-06	0A/66	27-07	27-07	27-07
	HDD162-07	0A/67	27-08	27-08	
	HDD162-08	0A/68	27-09	27-09	27-09
	HDD162-09	0A/69	27-10/Spare	27-10/Spare	27-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (108/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-163	HDD163-00	0B/60	27-01	27-01	27-01
	HDD163-01	0B/61	27-02	27-02	
	HDD163-02	0B/62	27-03	27-03	27-03
	HDD163-03	0B/63	27-04	27-04	
	HDD163-04	0B/64	27-05	27-05	27-05
	HDD163-05	0B/65	27-06	27-06	
	HDD163-06	0B/66	27-07	27-07	27-07
	HDD163-07	0B/67	27-08	27-08	
	HDD163-08	0B/68	27-09	27-09	27-09
	HDD163-09	0B/69	27-10/Spare	27-10/Spare	27-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (109/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-164	HDD164-00	0C/60	28-01	27-01	27-01
	HDD164-01	0C/61	28-02	27-02	
	HDD164-02	0C/62	28-03	27-03	27-03
	HDD164-03	0C/63	28-04	27-04	
	HDD164-04	0C/64	28-05	27-05	27-05
	HDD164-05	0C/65	28-06	27-06	
	HDD164-06	0C/66	28-07	27-07	27-07
	HDD164-07	0C/67	28-08	27-08	
	HDD164-08	0C/68	28-09	27-09	27-09
	HDD164-09	0C/69	28-10/Spare	27-10/Spare	27-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (110/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-165	HDD165-00	0D/60	28-01	27-01	27-01
	HDD165-01	0D/61	28-02	27-02	
	HDD165-02	0D/62	28-03	27-03	27-03
	HDD165-03	0D/63	28-04	27-04	
	HDD165-04	0D/64	28-05	27-05	27-05
	HDD165-05	0D/65	28-06	27-06	
	HDD165-06	0D/66	28-07	27-07	27-07
	HDD165-07	0D/67	28-08	27-08	
	HDD165-08	0D/68	28-09	27-09	27-09
	HDD165-09	0D/69	28-10/Spare	27-10/Spare	27-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (111/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-166	HDD166-00	0E/60	28-01	27-01	27-01
	HDD166-01	0E/61	28-02	27-02	
	HDD166-02	0E/62	28-03	27-03	27-03
	HDD166-03	0E/63	28-04	27-04	
	HDD166-04	0E/64	28-05	27-05	27-05
	HDD166-05	0E/65	28-06	27-06	
	HDD166-06	0E/66	28-07	27-07	27-07
	HDD166-07	0E/67	28-08	27-08	
	HDD166-08	0E/68	28-09	27-09	27-09
	HDD166-09	0E/69	28-10/Spare	27-10/Spare	27-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (112/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-167	HDD167-00	0F/60	28-01	27-01	27-01
	HDD167-01	0F/61	28-02	27-02	
	HDD167-02	0F/62	28-03	27-03	27-03
	HDD167-03	0F/63	28-04	27-04	
	HDD167-04	0F/64	28-05	27-05	27-05
	HDD167-05	0F/65	28-06	27-06	
	HDD167-06	0F/66	28-07	27-07	27-07
	HDD167-07	0F/67	28-08	27-08	
	HDD167-08	0F/68	28-09	27-09	27-09
	HDD167-09	0F/69	28-10/Spare	27-10/Spare	27-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (113/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD070	HDD070-00	00/70	29-01	29-01	29-01
	HDD070-01	00/71	29-02	29-02	
	HDD070-02	00/72	29-03	29-03	29-03
	HDD070-03	00/73	29-04	29-04	
	HDD070-04	00/74	29-05	29-05	29-05
	HDD070-05	00/75	29-06	29-06	
	HDD070-06	00/76	29-07	29-07	29-07
	HDD070-07	00/77	29-08	29-08	
	HDD070-08	00/78	29-09	29-09	29-09
	HDD070-09	00/79	29-10/Spare	29-10/Spare	29-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (114/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD071	HDD071-00	01/70	29-01	29-01	29-01
	HDD071-01	01/71	29-02	29-02	
	HDD071-02	01/72	29-03	29-03	29-03
	HDD071-03	01/73	29-04	29-04	
	HDD071-04	01/74	29-05	29-05	29-05
	HDD071-05	01/75	29-06	29-06	
	HDD071-06	01/76	29-07	29-07	29-07
	HDD071-07	01/77	29-08	29-08	
	HDD071-08	01/78	29-09	29-09	29-09
	HDD071-09	01/79	29-10/Spare	29-10/Spare	29-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (115/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-072	HDD072-00	02/70	29-01	29-01	29-01
	HDD072-01	02/71	29-02	29-02	
	HDD072-02	02/72	29-03	29-03	29-03
	HDD072-03	02/73	29-04	29-04	
	HDD072-04	02/74	29-05	29-05	29-05
	HDD072-05	02/75	29-06	29-06	
	HDD072-06	02/76	29-07	29-07	29-07
	HDD072-07	02/77	29-08	29-08	
	HDD072-08	02/78	29-09	29-09	29-09
	HDD072-09	02/79	29-10/Spare	29-10/Spare	29-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (116/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-073	HDD073-00	03/70	29-01	29-01	29-01
	HDD073-01	03/71	29-02	29-02	
	HDD073-02	03/72	29-03	29-03	29-03
	HDD073-03	03/73	29-04	29-04	
	HDD073-04	03/74	29-05	29-05	29-05
	HDD073-05	03/75	29-06	29-06	
	HDD073-06	03/76	29-07	29-07	29-07
	HDD073-07	03/77	29-08	29-08	
	HDD073-08	03/78	29-09	29-09	29-09
	HDD073-09	03/79	29-10/Spare	29-10/Spare	29-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (117/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-074	HDD074-00	04/70	30-01	29-01	29-01
	HDD074-01	04/71	30-02	29-02	
	HDD074-02	04/72	30-03	29-03	29-03
	HDD074-03	04/73	30-04	29-04	
	HDD074-04	04/74	30-05	29-05	29-05
	HDD074-05	04/75	30-06	29-06	
	HDD074-06	04/76	30-07	29-07	29-07
	HDD074-07	04/77	30-08	29-08	
	HDD074-08	04/78	30-09	29-09	29-09
	HDD074-09	04/79	30-10/Spare	29-10/Spare	29-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (118/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-075	HDD075-00	05/70	30-01	29-01	29-01
	HDD075-01	05/71	30-02	29-02	
	HDD075-02	05/72	30-03	29-03	29-03
	HDD075-03	05/73	30-04	29-04	
	HDD075-04	05/74	30-05	29-05	29-05
	HDD075-05	05/75	30-06	29-06	
	HDD075-06	05/76	30-07	29-07	29-07
	HDD075-07	05/77	30-08	29-08	
	HDD075-08	05/78	30-09	29-09	29-09
	HDD075-09	05/79	30-10/Spare	29-10/Spare	29-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (119/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-076	HDD076-00	06/70	30-01	29-01	29-01
	HDD076-01	06/71	30-02	29-02	
	HDD076-02	06/72	30-03	29-03	29-03
	HDD076-03	06/73	30-04	29-04	
	HDD076-04	06/74	30-05	29-05	29-05
	HDD076-05	06/75	30-06	29-06	
	HDD076-06	06/76	30-07	29-07	29-07
	HDD076-07	06/77	30-08	29-08	
	HDD076-08	06/78	30-09	29-09	29-09
	HDD076-09	06/79	30-10/Spare	29-10/Spare	29-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (120/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-077	HDD077-00	07/70	30-01	29-01	29-01
	HDD077-01	07/71	30-02	29-02	
	HDD077-02	07/72	30-03	29-03	29-03
	HDD077-03	07/73	30-04	29-04	
	HDD077-04	07/74	30-05	29-05	29-05
	HDD077-05	07/75	30-06	29-06	
	HDD077-06	07/76	30-07	29-07	29-07
	HDD077-07	07/77	30-08	29-08	
	HDD077-08	07/78	30-09	29-09	29-09
	HDD077-09	07/79	30-10/Spare	29-10/Spare	29-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (121/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-170	HDD170-00	08/70	31-01	31-01	31-01
	HDD170-01	08/71	31-02	31-02	
	HDD170-02	08/72	31-03	31-03	31-03
	HDD170-03	08/73	31-04	31-04	
	HDD170-04	08/74	31-05	31-05	31-05
	HDD170-05	08/75	31-06	31-06	
	HDD170-06	08/76	31-07	31-07	31-07
	HDD170-07	08/77	31-08	31-08	
	HDD170-08	08/78	31-09	31-09	31-09
	HDD170-09	08/79	31-10/Spare	31-10/Spare	31-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (122/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-171	HDD171-00	09/70	31-01	31-01	31-01
	HDD171-01	09/71	31-02	31-02	
	HDD171-02	09/72	31-03	31-03	31-03
	HDD171-03	09/73	31-04	31-04	
	HDD171-04	09/74	31-05	31-05	31-05
	HDD171-05	09/75	31-06	31-06	
	HDD171-06	09/76	31-07	31-07	31-07
	HDD171-07	09/77	31-08	31-08	
	HDD171-08	09/78	31-09	31-09	31-09
	HDD171-09	09/79	31-10/Spare	31-10/Spare	31-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (123/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-172	HDD172-00	0A/70	31-01	31-01	31-01
	HDD172-01	0A/71	31-02	31-02	
	HDD172-02	0A/72	31-03	31-03	31-03
	HDD172-03	0A/73	31-04	31-04	
	HDD172-04	0A/74	31-05	31-05	31-05
	HDD172-05	0A/75	31-06	31-06	
	HDD172-06	0A/76	31-07	31-07	31-07
	HDD172-07	0A/77	31-08	31-08	
	HDD172-08	0A/78	31-09	31-09	31-09
	HDD172-09	0A/79	31-10/Spare	31-10/Spare	31-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (124/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-173	HDD173-00	0B/70	31-01	31-01	31-01
	HDD173-01	0B/71	31-02	31-02	
	HDD173-02	0B/72	31-03	31-03	31-03
	HDD173-03	0B/73	31-04	31-04	
	HDD173-04	0B/74	31-05	31-05	31-05
	HDD173-05	0B/75	31-06	31-06	
	HDD173-06	0B/76	31-07	31-07	31-07
	HDD173-07	0B/77	31-08	31-08	
	HDD173-08	0B/78	31-09	31-09	31-09
	HDD173-09	0B/79	31-10/Spare	31-10/Spare	31-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (125/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-174	HDD174-00	0C/70	32-01	31-01	31-01
	HDD174-01	0C/71	32-02	31-02	
	HDD174-02	0C/72	32-03	31-03	31-03
	HDD174-03	0C/73	32-04	31-04	
	HDD174-04	0C/74	32-05	31-05	31-05
	HDD174-05	0C/75	32-06	31-06	
	HDD174-06	0C/76	32-07	31-07	31-07
	HDD174-07	0C/77	32-08	31-08	
	HDD174-08	0C/78	32-09	31-09	31-09
	HDD174-09	0C/79	32-10/Spare	31-10/Spare	31-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (126/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-175	HDD175-00	0D/70	32-01	31-01	31-01
	HDD175-01	0D/71	32-02	31-02	
	HDD175-02	0D/72	32-03	31-03	31-03
	HDD175-03	0D/73	32-04	31-04	
	HDD175-04	0D/74	32-05	31-05	31-05
	HDD175-05	0D/75	32-06	31-06	
	HDD175-06	0D/76	32-07	31-07	31-07
	HDD175-07	0D/77	32-08	31-08	
	HDD175-08	0D/78	32-09	31-09	31-09
	HDD175-09	0D/79	32-10/Spare	31-10/Spare	31-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (127/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-176	HDD176-00	0E/70	32-01	31-01	31-01
	HDD176-01	0E/71	32-02	31-02	
	HDD176-02	0E/72	32-03	31-03	31-03
	HDD176-03	0E/73	32-04	31-04	
	HDD176-04	0E/74	32-05	31-05	31-05
	HDD176-05	0E/75	32-06	31-06	
	HDD176-06	0E/76	32-07	31-07	31-07
	HDD176-07	0E/77	32-08	31-08	
	HDD176-08	0E/78	32-09	31-09	31-09
	HDD176-09	0E/79	32-10/Spare	31-10/Spare	31-09/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (3.5 INCH BOX) (128/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-177	HDD177-00	0F/70	32-01	31-01	31-01
	HDD177-01	0F/71	32-02	31-02	
	HDD177-02	0F/72	32-03	31-03	31-03
	HDD177-03	0F/73	32-04	31-04	
	HDD177-04	0F/74	32-05	31-05	31-05
	HDD177-05	0F/75	32-06	31-06	
	HDD177-06	0F/76	32-07	31-07	31-07
	HDD177-07	0F/77	32-08	31-08	
	HDD177-08	0F/78	32-09	31-09	31-09
	HDD177-09	0F/79	32-10/Spare	31-10/Spare	31-09/Spare

5.3 Physical-Logical Device Matrixes (FBX DKU)

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (1/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-000	HDD000-00	00/00	01-01	01-01	01-01
	HDD000-01	00/01	01-02	01-02	
	HDD000-02	00/02	01-03	01-03	01-03
	HDD000-03	00/03	01-04	01-04	
	HDD000-04	00/04	01-05	01-05	01-05
	HDD000-05	00/05	01-06/Spare	01-06/Spare	01-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (2/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-001	HDD001-00	01/00	01-01	01-01	01-01
	HDD001-01	01/01	01-02	01-02	
	HDD001-02	01/02	01-03	01-03	01-03
	HDD001-03	01/03	01-04	01-04	
	HDD001-04	01/04	01-05	01-05	01-05
	HDD001-05	01/05	01-06/Spare	01-06/Spare	01-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (3/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-002	HDD002-00	02/00	01-01	01-01	01-01
	HDD002-01	02/01	01-02	01-02	
	HDD002-02	02/02	01-03	01-03	01-03
	HDD002-03	02/03	01-04	01-04	
	HDD002-04	02/04	01-05	01-05	01-05
	HDD002-05	02/05	01-06/Spare	01-06/Spare	01-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (4/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-003	HDD003-00	03/00	01-01	01-01	01-01
	HDD003-01	03/01	01-02	01-02	
	HDD003-02	03/02	01-03	01-03	01-03
	HDD003-03	03/03	01-04	01-04	
	HDD003-04	03/04	01-05	01-05	01-05
	HDD003-05	03/05	01-06/Spare	01-06/Spare	01-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (5/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-004	HDD004-00	04/00	02-01	01-01	01-01
	HDD004-01	04/01	02-02	01-02	
	HDD004-02	04/02	02-03	01-03	01-03
	HDD004-03	04/03	02-04	01-04	
	HDD004-04	04/04	02-05	01-05	01-05
	HDD004-05	04/05	02-06/Spare	01-06/Spare	01-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (6/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-005	HDD005-00	05/00	02-01	01-01	01-01
	HDD005-01	05/01	02-02	01-02	
	HDD005-02	05/02	02-03	01-03	01-03
	HDD005-03	05/03	02-04	01-04	
	HDD005-04	05/04	02-05	01-05	01-05
	HDD005-05	05/05	02-06/Spare	01-06/Spare	01-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(7/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-006	HDD006-00	06/00	02-01	01-01	01-01
	HDD006-01	06/01	02-02	01-02	
	HDD006-02	06/02	02-03	01-03	01-03
	HDD006-03	06/03	02-04	01-04	
	HDD006-04	06/04	02-05	01-05	01-05
	HDD006-05	06/05	02-06/Spare	01-06/Spare	01-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(8/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-007	HDD007-00	07/00	02-01	01-01	01-01
	HDD007-01	07/01	02-02	01-02	
	HDD007-02	07/02	02-03	01-03	01-03
	HDD007-03	07/03	02-04	01-04	
	HDD007-04	07/04	02-05	01-05	01-05
	HDD007-05	07/05	02-06/Spare	01-06/Spare	01-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (9/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-100	HDD100-00	08/00	03-01	03-01	03-01
	HDD100-01	08/01	03-02	03-02	
	HDD100-02	08/02	03-03	03-03	03-03
	HDD100-03	08/03	03-04	03-04	
	HDD100-04	08/04	03-05	03-05	03-05
	HDD100-05	08/05	03-06/Spare	03-06/Spare	03-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (10/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-101	HDD101-00	09/00	03-01	03-01	03-01
	HDD101-01	09/01	03-02	03-02	
	HDD101-02	09/02	03-03	03-03	03-03
	HDD101-03	09/03	03-04	03-04	
	HDD101-04	09/04	03-05	03-05	03-05
	HDD101-05	09/05	03-06/Spare	03-06/Spare	03-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(11/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-102	HDD102-00	0A/00	03-01	03-01	03-01
	HDD102-01	0A/01	03-02	03-02	
	HDD102-02	0A/02	03-03	03-03	03-03
	HDD102-03	0A/03	03-04	03-04	
	HDD102-04	0A/04	03-05	03-05	03-05
	HDD102-05	0A/05	03-06/Spare	03-06/Spare	03-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(12/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-103	HDD103-00	0B/00	03-01	03-01	03-01
	HDD103-01	0B/01	03-02	03-02	
	HDD103-02	0B/02	03-03	03-03	03-03
	HDD103-03	0B/03	03-04	03-04	
	HDD103-04	0B/04	03-05	03-05	03-05
	HDD103-05	0B/05	03-06/Spare	03-06/Spare	03-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(13/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-104	HDD104-00	0C/00	04-01	03-01	03-01
	HDD104-01	0C/01	04-02	03-02	
	HDD104-02	0C/02	04-03	03-03	03-03
	HDD104-03	0C/03	04-04	03-04	
	HDD104-04	0C/04	04-05	03-05	03-05
	HDD104-05	0C/05	04-06/Spare	03-06/Spare	03-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(14/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-105	HDD105-00	0D/00	04-01	03-01	03-01
	HDD105-01	0D/01	04-02	03-02	
	HDD105-02	0D/02	04-03	03-03	03-03
	HDD105-03	0D/03	04-04	03-04	
	HDD105-04	0D/04	04-05	03-05	03-05
	HDD105-05	0D/05	04-06/Spare	03-06/Spare	03-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (15/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-106	HDD106-00	0E/00	04-01	03-01	03-01
	HDD106-01	0E/01	04-02	03-02	
	HDD106-02	0E/02	04-03	03-03	03-03
	HDD106-03	0E/03	04-04	03-04	
	HDD106-04	0E/04	04-05	03-05	03-05
	HDD106-05	0E/05	04-06/Spare	03-06/Spare	03-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (16/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-107	HDD107-00	0F/00	04-01	03-01	03-01
	HDD107-01	0F/01	04-02	03-02	
	HDD107-02	0F/02	04-03	03-03	03-03
	HDD107-03	0F/03	04-04	03-04	
	HDD107-04	0F/04	04-05	03-05	03-05
	HDD107-05	0F/05	04-06/Spare	03-06/Spare	03-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(17/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-010	HDD010-00	00/10	05-01	05-01	05-01
	HDD010-01	00/11	05-02	05-02	
	HDD010-02	00/12	05-03	05-03	05-03
	HDD010-03	00/13	05-04	05-04	
	HDD010-04	00/14	05-05	05-05	05-05
	HDD010-05	00/15	05-06/Spare	05-06/Spare	05-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(18/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-011	HDD011-00	01/10	05-01	05-01	05-01
	HDD011-01	01/11	05-02	05-02	
	HDD011-02	01/12	05-03	05-03	05-03
	HDD011-03	01/13	05-04	05-04	
	HDD011-04	01/14	05-05	05-05	05-05
	HDD011-05	01/15	05-06/Spare	05-06/Spare	05-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (19/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD012	HDD012-00	02/10	05-01	05-01	05-01
	HDD012-01	02/11	05-02	05-02	
	HDD012-02	02/12	05-03	05-03	05-03
	HDD012-03	02/13	05-04	05-04	
	HDD012-04	02/14	05-05	05-05	05-05
	HDD012-05	02/15	05-06/Spare	05-06/Spare	05-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (20/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD013	HDD013-00	03/10	05-01	05-01	05-01
	HDD013-01	03/11	05-02	05-02	
	HDD013-02	03/12	05-03	05-03	05-03
	HDD013-03	03/13	05-04	05-04	
	HDD013-04	03/14	05-05	05-05	05-05
	HDD013-05	03/15	05-06/Spare	05-06/Spare	05-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (21/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-014	HDD014-00	04/10	06-01	05-01	05-01
	HDD014-01	04/11	06-02	05-02	
	HDD014-02	04/12	06-03	05-03	05-03
	HDD014-03	04/13	06-04	05-04	
	HDD014-04	04/14	06-05	05-05	05-05
	HDD014-05	04/15	06-06/Spare	05-06/Spare	05-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (22/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-015	HDD015-00	05/10	06-01	05-01	05-01
	HDD015-01	05/11	06-02	05-02	
	HDD015-02	05/12	06-03	05-03	05-03
	HDD015-03	05/13	06-04	05-04	
	HDD015-04	05/14	06-05	05-05	05-05
	HDD015-05	05/15	06-06/Spare	05-06/Spare	05-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (23/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD016	HDD016-00	06/10	06-01	05-01	05-01
	HDD016-01	06/11	06-02	05-02	
	HDD016-02	06/12	06-03	05-03	05-03
	HDD016-03	06/13	06-04	05-04	
	HDD016-04	06/14	06-05	05-05	05-05
	HDD016-05	06/15	06-06/Spare	05-06/Spare	05-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (24/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD017	HDD017-00	07/10	06-01	05-01	05-01
	HDD017-01	07/11	06-02	05-02	
	HDD017-02	07/12	06-03	05-03	05-03
	HDD017-03	07/13	06-04	05-04	
	HDD017-04	07/14	06-05	05-05	05-05
	HDD017-05	07/15	06-06/Spare	05-06/Spare	05-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(25/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-110	HDD110-00	08/10	07-01	07-01	07-01
	HDD110-01	08/11	07-02	07-02	
	HDD110-02	08/12	07-03	07-03	07-03
	HDD110-03	08/13	07-04	07-04	
	HDD110-04	08/14	07-05	07-05	07-05
	HDD110-05	08/15	07-06/Spare	07-06/Spare	07-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(26/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-111	HDD111-00	09/10	07-01	07-01	07-01
	HDD111-01	09/11	07-02	07-02	
	HDD111-02	09/12	07-03	07-03	07-03
	HDD111-03	09/13	07-04	07-04	
	HDD111-04	09/14	07-05	07-05	07-05
	HDD111-05	09/15	07-06/Spare	07-06/Spare	07-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (27/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-112	HDD112-00	0A/10	07-01	07-01	07-01
	HDD112-01	0A/11	07-02	07-02	
	HDD112-02	0A/12	07-03	07-03	07-03
	HDD112-03	0A/13	07-04	07-04	
	HDD112-04	0A/14	07-05	07-05	07-05
	HDD112-05	0A/15	07-06/Spare	07-06/Spare	07-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (28/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-113	HDD113-00	0B/10	07-01	07-01	07-01
	HDD113-01	0B/11	07-02	07-02	
	HDD113-02	0B/12	07-03	07-03	07-03
	HDD113-03	0B/13	07-04	07-04	
	HDD113-04	0B/14	07-05	07-05	07-05
	HDD113-05	0B/15	07-06/Spare	07-06/Spare	07-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (29/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-114	HDD114-00	0C/10	08-01	07-01	07-01
	HDD114-01	0C/11	08-02	07-02	
	HDD114-02	0C/12	08-03	07-03	07-03
	HDD114-03	0C/13	08-04	07-04	
	HDD114-04	0C/14	08-05	07-05	07-05
	HDD114-05	0C/15	08-06/Spare	07-06/Spare	07-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (30/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-115	HDD115-00	0D/10	08-01	07-01	07-01
	HDD115-01	0D/11	08-02	07-02	
	HDD115-02	0D/12	08-03	07-03	07-03
	HDD115-03	0D/13	08-04	07-04	
	HDD115-04	0D/14	08-05	07-05	07-05
	HDD115-05	0D/15	08-06/Spare	07-06/Spare	07-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (31/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-116	HDD116-00	0E/10	08-01	07-01	07-01
	HDD116-01	0E/11	08-02	07-02	
	HDD116-02	0E/12	08-03	07-03	07-03
	HDD116-03	0E/13	08-04	07-04	
	HDD116-04	0E/14	08-05	07-05	07-05
	HDD116-05	0E/15	08-06/Spare	07-06/Spare	07-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (32/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-117	HDD117-00	0F/10	08-01	07-01	07-01
	HDD117-01	0F/11	08-02	07-02	
	HDD117-02	0F/12	08-03	07-03	07-03
	HDD117-03	0F/13	08-04	07-04	
	HDD117-04	0F/14	08-05	07-05	07-05
	HDD117-05	0F/15	08-06/Spare	07-06/Spare	07-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (33/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-020	HDD020-00	00/20	09-01	09-01	09-01
	HDD020-01	00/21	09-02	09-02	
	HDD020-02	00/22	09-03	09-03	09-03
	HDD020-03	00/23	09-04	09-04	
	HDD020-04	00/24	09-05	09-05	09-05
	HDD020-05	00/25	09-06/Spare	09-06/Spare	09-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (34/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-021	HDD021-00	01/20	09-01	09-01	09-01
	HDD021-01	01/21	09-02	09-02	
	HDD021-02	01/22	09-03	09-03	09-03
	HDD021-03	01/23	09-04	09-04	
	HDD021-04	01/24	09-05	09-05	09-05
	HDD021-05	01/25	09-06/Spare	09-06/Spare	09-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (35/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-022	HDD022-00	02/20	09-01	09-01	09-01
	HDD022-01	02/21	09-02	09-02	
	HDD022-02	02/22	09-03	09-03	09-03
	HDD022-03	02/23	09-04	09-04	
	HDD022-04	02/24	09-05	09-05	09-05
	HDD022-05	02/25	09-06/Spare	09-06/Spare	09-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (36/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-023	HDD023-00	03/20	09-01	09-01	09-01
	HDD023-01	03/21	09-02	09-02	
	HDD023-02	03/22	09-03	09-03	09-03
	HDD023-03	03/23	09-04	09-04	
	HDD023-04	03/24	09-05	09-05	09-05
	HDD023-05	03/25	09-06/Spare	09-06/Spare	09-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (37/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-024	HDD024-00	04/20	10-01	09-01	09-01
	HDD024-01	04/21	10-02	09-02	
	HDD024-02	04/22	10-03	09-03	09-03
	HDD024-03	04/23	10-04	09-04	
	HDD024-04	04/24	10-05	09-05	09-05
	HDD024-05	04/25	10-06/Spare	09-06/Spare	09-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (38/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-025	HDD025-00	05/20	10-01	09-01	09-01
	HDD025-01	05/21	10-02	09-02	
	HDD025-02	05/22	10-03	09-03	09-03
	HDD025-03	05/23	10-04	09-04	
	HDD025-04	05/24	10-05	09-05	09-05
	HDD025-05	05/25	10-06/Spare	09-06/Spare	09-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (39/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-026	HDD026-00	06/20	10-01	09-01	09-01
	HDD026-01	06/21	10-02	09-02	
	HDD026-02	06/22	10-03	09-03	09-03
	HDD026-03	06/23	10-04	09-04	
	HDD026-04	06/24	10-05	09-05	09-05
	HDD026-05	06/25	10-06/Spare	09-06/Spare	09-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (40/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-027	HDD027-00	07/20	10-01	09-01	09-01
	HDD027-01	07/21	10-02	09-02	
	HDD027-02	07/22	10-03	09-03	09-03
	HDD027-03	07/23	10-04	09-04	
	HDD027-04	07/24	10-05	09-05	09-05
	HDD027-05	07/25	10-06/Spare	09-06/Spare	09-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (41/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-120	HDD120-00	08/20	11-01	11-01	11-01
	HDD120-01	08/21	11-02	11-02	
	HDD120-02	08/22	11-03	11-03	11-03
	HDD120-03	08/23	11-04	11-04	
	HDD120-04	08/24	11-05	11-05	11-05
	HDD120-05	08/25	11-06/Spare	11-06/Spare	11-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (42/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-121	HDD121-00	09/20	11-01	11-01	11-01
	HDD121-01	09/21	11-02	11-02	
	HDD121-02	09/22	11-03	11-03	11-03
	HDD121-03	09/23	11-04	11-04	
	HDD121-04	09/24	11-05	11-05	11-05
	HDD121-05	09/25	11-06/Spare	11-06/Spare	11-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (43/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-122	HDD122-00	0A/20	11-01	11-01	11-01
	HDD122-01	0A/21	11-02	11-02	
	HDD122-02	0A/22	11-03	11-03	11-03
	HDD122-03	0A/23	11-04	11-04	
	HDD122-04	0A/24	11-05	11-05	11-05
	HDD122-05	0A/25	11-06/Spare	11-06/Spare	11-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (44/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-123	HDD123-00	0B/20	11-01	11-01	11-01
	HDD123-01	0B/21	11-02	11-02	
	HDD123-02	0B/22	11-03	11-03	11-03
	HDD123-03	0B/23	11-04	11-04	
	HDD123-04	0B/24	11-05	11-05	11-05
	HDD123-05	0B/25	11-06/Spare	11-06/Spare	11-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(45/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-124	HDD124-00	0C/20	12-01	11-01	11-01
	HDD124-01	0C/21	12-02	11-02	
	HDD124-02	0C/22	12-03	11-03	11-03
	HDD124-03	0C/23	12-04	11-04	
	HDD124-04	0C/24	12-05	11-05	11-05
	HDD124-05	0C/25	12-06/Spare	11-06/Spare	11-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(46/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-125	HDD125-00	0D/20	12-01	11-01	11-01
	HDD125-01	0D/21	12-02	11-02	
	HDD125-02	0D/22	12-03	11-03	11-03
	HDD125-03	0D/23	12-04	11-04	
	HDD125-04	0D/24	12-05	11-05	11-05
	HDD125-05	0D/25	12-06/Spare	11-06/Spare	11-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (47/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-126	HDD126-00	0E/20	12-01	11-01	11-01
	HDD126-01	0E/21	12-02	11-02	
	HDD126-02	0E/22	12-03	11-03	11-03
	HDD126-03	0E/23	12-04	11-04	
	HDD126-04	0E/24	12-05	11-05	11-05
	HDD126-05	0E/25	12-06/Spare	11-06/Spare	11-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (48/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-127	HDD127-00	0F/20	12-01	11-01	11-01
	HDD127-01	0F/21	12-02	11-02	
	HDD127-02	0F/22	12-03	11-03	11-03
	HDD127-03	0F/23	12-04	11-04	
	HDD127-04	0F/24	12-05	11-05	11-05
	HDD127-05	0F/25	12-06/Spare	11-06/Spare	11-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (49/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD030	HDD030-00	00/30	13-01	13-01	13-01
	HDD030-01	00/31	13-02	13-02	
	HDD030-02	00/32	13-03	13-03	13-03
	HDD030-03	00/33	13-04	13-04	
	HDD030-04	00/34	13-05	13-05	13-05
	HDD030-05	00/35	13-06/Spare	13-06/Spare	13-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (50/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD031	HDD031-00	01/30	13-01	13-01	13-01
	HDD031-01	01/31	13-02	13-02	
	HDD031-02	01/32	13-03	13-03	13-03
	HDD031-03	01/33	13-04	13-04	
	HDD031-04	01/34	13-05	13-05	13-05
	HDD031-05	01/35	13-06/Spare	13-06/Spare	13-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (51/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-032	HDD032-00	02/30	13-01	13-01	13-01
	HDD032-01	02/31	13-02	13-02	
	HDD032-02	02/32	13-03	13-03	13-03
	HDD032-03	02/33	13-04	13-04	
	HDD032-04	02/34	13-05	13-05	13-05
	HDD032-05	02/35	13-06/Spare	13-06/Spare	13-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (52/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-033	HDD033-00	03/30	13-01	13-01	13-01
	HDD033-01	03/31	13-02	13-02	
	HDD033-02	03/32	13-03	13-03	13-03
	HDD033-03	03/33	13-04	13-04	
	HDD033-04	03/34	13-05	13-05	13-05
	HDD033-05	03/35	13-06/Spare	13-06/Spare	13-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (53/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-034	HDD034-00	04/30	14-01	13-01	13-01
	HDD034-01	04/31	14-02	13-02	
	HDD034-02	04/32	14-03	13-03	13-03
	HDD034-03	04/33	14-04	13-04	
	HDD034-04	04/34	14-05	13-05	13-05
	HDD034-05	04/35	14-06/Spare	13-06/Spare	13-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (54/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-035	HDD035-00	05/30	14-01	13-01	13-01
	HDD035-01	05/31	14-02	13-02	
	HDD035-02	05/32	14-03	13-03	13-03
	HDD035-03	05/33	14-04	13-04	
	HDD035-04	05/34	14-05	13-05	13-05
	HDD035-05	05/35	14-06/Spare	13-06/Spare	13-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (55/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-036	HDD036-00	06/30	14-01	13-01	13-01
	HDD036-01	06/31	14-02	13-02	
	HDD036-02	06/32	14-03	13-03	13-03
	HDD036-03	06/33	14-04	13-04	
	HDD036-04	06/34	14-05	13-05	13-05
	HDD036-05	06/35	14-06/Spare	13-06/Spare	13-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (56/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-037	HDD037-00	07/30	14-01	13-01	13-01
	HDD037-01	07/31	14-02	13-02	
	HDD037-02	07/32	14-03	13-03	13-03
	HDD037-03	07/33	14-04	13-04	
	HDD037-04	07/34	14-05	13-05	13-05
	HDD037-05	07/35	14-06/Spare	13-06/Spare	13-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (57/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-130	HDD130-00	08/30	15-01	15-01	15-01
	HDD130-01	08/31	15-02	15-02	
	HDD130-02	08/32	15-03	15-03	15-03
	HDD130-03	08/33	15-04	15-04	
	HDD130-04	08/34	15-05	15-05	15-05
	HDD130-05	08/35	15-06/Spare	15-06/Spare	15-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (58/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-131	HDD131-00	09/30	15-01	15-01	15-01
	HDD131-01	09/31	15-02	15-02	
	HDD131-02	09/32	15-03	15-03	15-03
	HDD131-03	09/33	15-04	15-04	
	HDD131-04	09/34	15-05	15-05	15-05
	HDD131-05	09/35	15-06/Spare	15-06/Spare	15-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (59/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-132	HDD132-00	0A/30	15-01	15-01	15-01
	HDD132-01	0A/31	15-02	15-02	
	HDD132-02	0A/32	15-03	15-03	15-03
	HDD132-03	0A/33	15-04	15-04	
	HDD132-04	0A/34	15-05	15-05	15-05
	HDD132-05	0A/35	15-06/Spare	15-06/Spare	15-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (60/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-133	HDD133-00	0B/30	15-01	15-01	15-01
	HDD133-01	0B/31	15-02	15-02	
	HDD133-02	0B/32	15-03	15-03	15-03
	HDD133-03	0B/33	15-04	15-04	
	HDD133-04	0B/34	15-05	15-05	15-05
	HDD133-05	0B/35	15-06/Spare	15-06/Spare	15-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (61/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-134	HDD134-00	0C/30	16-01	15-01	15-01
	HDD134-01	0C/31	16-02	15-02	
	HDD134-02	0C/32	16-03	15-03	15-03
	HDD134-03	0C/33	16-04	15-04	
	HDD134-04	0C/34	16-05	15-05	15-05
	HDD134-05	0C/35	16-06/Spare	15-06/Spare	15-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (62/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-135	HDD135-00	0D/30	16-01	15-01	15-01
	HDD135-01	0D/31	16-02	15-02	
	HDD135-02	0D/32	16-03	15-03	15-03
	HDD135-03	0D/33	16-04	15-04	
	HDD135-04	0D/34	16-05	15-05	15-05
	HDD135-05	0D/35	16-06/Spare	15-06/Spare	15-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (63/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-136	HDD136-00	0E/30	16-01	15-01	15-01
	HDD136-01	0E/31	16-02	15-02	
	HDD136-02	0E/32	16-03	15-03	15-03
	HDD136-03	0E/33	16-04	15-04	
	HDD136-04	0E/34	16-05	15-05	15-05
	HDD136-05	0E/35	16-06/Spare	15-06/Spare	15-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (64/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-137	HDD137-00	0F/30	16-01	15-01	15-01
	HDD137-01	0F/31	16-02	15-02	
	HDD137-02	0F/32	16-03	15-03	15-03
	HDD137-03	0F/33	16-04	15-04	
	HDD137-04	0F/34	16-05	15-05	15-05
	HDD137-05	0F/35	16-06/Spare	15-06/Spare	15-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(65/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-040	HDD040-00	00/40	17-01	17-01	17-01
	HDD040-01	00/41	17-02	17-02	
	HDD040-02	00/42	17-03	17-03	17-03
	HDD040-03	00/43	17-04	17-04	
	HDD040-04	00/44	17-05	17-05	17-05
	HDD040-05	00/45	17-06/Spare	17-06/Spare	17-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(66/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-041	HDD041-00	01/40	17-01	17-01	17-01
	HDD041-01	01/41	17-02	17-02	
	HDD041-02	01/42	17-03	17-03	17-03
	HDD041-03	01/43	17-04	17-04	
	HDD041-04	01/44	17-05	17-05	17-05
	HDD041-05	01/45	17-06/Spare	17-06/Spare	17-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (67/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-042	HDD042-00	02/40	17-01	17-01	17-01
	HDD042-01	02/41	17-02	17-02	
	HDD042-02	02/42	17-03	17-03	17-03
	HDD042-03	02/43	17-04	17-04	
	HDD042-04	02/44	17-05	17-05	17-05
	HDD042-05	02/45	17-06/Spare	17-06/Spare	17-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (68/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-043	HDD043-00	03/40	17-01	17-01	17-01
	HDD043-01	03/41	17-02	17-02	
	HDD043-02	03/42	17-03	17-03	17-03
	HDD043-03	03/43	17-04	17-04	
	HDD043-04	03/44	17-05	17-05	17-05
	HDD043-05	03/45	17-06/Spare	17-06/Spare	17-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (69/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-044	HDD044-00	04/40	18-01	17-01	17-01
	HDD044-01	04/41	18-02	17-02	
	HDD044-02	04/42	18-03	17-03	17-03
	HDD044-03	04/43	18-04	17-04	
	HDD044-04	04/44	18-05	17-05	17-05
	HDD044-05	04/45	18-06/Spare	17-06/Spare	17-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (70/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-045	HDD045-00	05/40	18-01	17-01	17-01
	HDD045-01	05/41	18-02	17-02	
	HDD045-02	05/42	18-03	17-03	17-03
	HDD045-03	05/43	18-04	17-04	
	HDD045-04	05/44	18-05	17-05	17-05
	HDD045-05	05/45	18-06/Spare	17-06/Spare	17-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (71/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-046	HDD046-00	06/40	18-01	17-01	17-01
	HDD046-01	06/41	18-02	17-02	
	HDD046-02	06/42	18-03	17-03	17-03
	HDD046-03	06/43	18-04	17-04	
	HDD046-04	06/44	18-05	17-05	17-05
	HDD046-05	06/45	18-06/Spare	17-06/Spare	17-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (72/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-047	HDD047-00	07/40	18-01	17-01	17-01
	HDD047-01	07/41	18-02	17-02	
	HDD047-02	07/42	18-03	17-03	17-03
	HDD047-03	07/43	18-04	17-04	
	HDD047-04	07/44	18-05	17-05	17-05
	HDD047-05	07/45	18-06/Spare	17-06/Spare	17-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (73/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-140	HDD140-00	08/40	19-01	19-01	19-01
	HDD140-01	08/41	19-02	19-02	
	HDD140-02	08/42	19-03	19-03	19-03
	HDD140-03	08/43	19-04	19-04	
	HDD140-04	08/44	19-05	19-05	19-05
	HDD140-05	08/45	19-06/Spare	19-06/Spare	19-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (74/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-141	HDD141-00	09/40	19-01	19-01	19-01
	HDD141-01	09/41	19-02	19-02	
	HDD141-02	09/42	19-03	19-03	19-03
	HDD141-03	09/43	19-04	19-04	
	HDD141-04	09/44	19-05	19-05	19-05
	HDD141-05	09/45	19-06/Spare	19-06/Spare	19-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (75/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-142	HDD142-00	0A/40	19-01	19-01	19-01
	HDD142-01	0A/41	19-02	19-02	
	HDD142-02	0A/42	19-03	19-03	19-03
	HDD142-03	0A/43	19-04	19-04	
	HDD142-04	0A/44	19-05	19-05	19-05
	HDD142-05	0A/45	19-06/Spare	19-06/Spare	19-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (76/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-143	HDD143-00	0B/40	19-01	19-01	19-01
	HDD143-01	0B/41	19-02	19-02	
	HDD143-02	0B/42	19-03	19-03	19-03
	HDD143-03	0B/43	19-04	19-04	
	HDD143-04	0B/44	19-05	19-05	19-05
	HDD143-05	0B/45	19-06/Spare	19-06/Spare	19-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (77/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-144	HDD144-00	0C/40	20-01	19-01	19-01
	HDD144-01	0C/41	20-02	19-02	
	HDD144-02	0C/42	20-03	19-03	19-03
	HDD144-03	0C/43	20-04	19-04	
	HDD144-04	0C/44	20-05	19-05	19-05
	HDD144-05	0C/45	20-06/Spare	19-06/Spare	19-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (78/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-145	HDD145-00	0D/40	20-01	19-01	19-01
	HDD145-01	0D/41	20-02	19-02	
	HDD145-02	0D/42	20-03	19-03	19-03
	HDD145-03	0D/43	20-04	19-04	
	HDD145-04	0D/44	20-05	19-05	19-05
	HDD145-05	0D/45	20-06/Spare	19-06/Spare	19-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (79/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-146	HDD146-00	0E/40	20-01	19-01	19-01
	HDD146-01	0E/41	20-02	19-02	
	HDD146-02	0E/42	20-03	19-03	19-03
	HDD146-03	0E/43	20-04	19-04	
	HDD146-04	0E/44	20-05	19-05	19-05
	HDD146-05	0E/45	20-06/Spare	19-06/Spare	19-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (80/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-147	HDD147-00	0F/40	20-01	19-01	19-01
	HDD147-01	0F/41	20-02	19-02	
	HDD147-02	0F/42	20-03	19-03	19-03
	HDD147-03	0F/43	20-04	19-04	
	HDD147-04	0F/44	20-05	19-05	19-05
	HDD147-05	0F/45	20-06/Spare	19-06/Spare	19-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (81/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-050	HDD050-00	00/50	21-01	21-01	21-01
	HDD050-01	00/51	21-02	21-02	
	HDD050-02	00/52	21-03	21-03	21-03
	HDD050-03	00/53	21-04	21-04	
	HDD050-04	00/54	21-05	21-05	21-05
	HDD050-05	00/55	21-06/Spare	21-06/Spare	21-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (82/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-051	HDD051-00	01/50	21-01	21-01	21-01
	HDD051-01	01/51	21-02	21-02	
	HDD051-02	01/52	21-03	21-03	21-03
	HDD051-03	01/53	21-04	21-04	
	HDD051-04	01/54	21-05	21-05	21-05
	HDD051-05	01/55	21-06/Spare	21-06/Spare	21-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (83/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-052	HDD052-00	02/50	21-01	21-01	21-01
	HDD052-01	02/51	21-02	21-02	
	HDD052-02	02/52	21-03	21-03	21-03
	HDD052-03	02/53	21-04	21-04	
	HDD052-04	02/54	21-05	21-05	21-05
	HDD052-05	02/55	21-06/Spare	21-06/Spare	21-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (84/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-053	HDD053-00	03/50	21-01	21-01	21-01
	HDD053-01	03/51	21-02	21-02	
	HDD053-02	03/52	21-03	21-03	21-03
	HDD053-03	03/53	21-04	21-04	
	HDD053-04	03/54	21-05	21-05	21-05
	HDD053-05	03/55	21-06/Spare	21-06/Spare	21-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(85/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-054	HDD054-00	04/50	22-01	21-01	21-01
	HDD054-01	04/51	22-02	21-02	
	HDD054-02	04/52	22-03	21-03	21-03
	HDD054-03	04/53	22-04	21-04	
	HDD054-04	04/54	22-05	21-05	21-05
	HDD054-05	04/55	22-06/Spare	21-06/Spare	21-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(86/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-055	HDD055-00	05/50	22-01	21-01	21-01
	HDD055-01	05/51	22-02	21-02	
	HDD055-02	05/52	22-03	21-03	21-03
	HDD055-03	05/53	22-04	21-04	
	HDD055-04	05/54	22-05	21-05	21-05
	HDD055-05	05/55	22-06/Spare	21-06/Spare	21-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (87/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-056	HDD056-00	06/50	22-01	21-01	21-01
	HDD056-01	06/51	22-02	21-02	
	HDD056-02	06/52	22-03	21-03	21-03
	HDD056-03	06/53	22-04	21-04	
	HDD056-04	06/54	22-05	21-05	21-05
	HDD056-05	06/55	22-06/Spare	21-06/Spare	21-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (88/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-057	HDD057-00	07/50	22-01	21-01	21-01
	HDD057-01	07/51	22-02	21-02	
	HDD057-02	07/52	22-03	21-03	21-03
	HDD057-03	07/53	22-04	21-04	
	HDD057-04	07/54	22-05	21-05	21-05
	HDD057-05	07/55	22-06/Spare	21-06/Spare	21-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (89/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-150	HDD150-00	08/50	23-01	23-01	23-01
	HDD150-01	08/51	23-02	23-02	
	HDD150-02	08/52	23-03	23-03	23-03
	HDD150-03	08/53	23-04	23-04	
	HDD150-04	08/54	23-05	23-05	23-05
	HDD150-05	08/55	23-06/Spare	23-06/Spare	23-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (90/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-151	HDD151-00	09/50	23-01	23-01	23-01
	HDD151-01	09/51	23-02	23-02	
	HDD151-02	09/52	23-03	23-03	23-03
	HDD151-03	09/53	23-04	23-04	
	HDD151-04	09/54	23-05	23-05	23-05
	HDD151-05	09/55	23-06/Spare	23-06/Spare	23-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (91/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-152	HDD152-00	0A/50	23-01	23-01	23-01
	HDD152-01	0A/51	23-02	23-02	
	HDD152-02	0A/52	23-03	23-03	23-03
	HDD152-03	0A/53	23-04	23-04	
	HDD152-04	0A/54	23-05	23-05	23-05
	HDD152-05	0A/55	23-06/Spare	23-06/Spare	23-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (92/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-153	HDD153-00	0B/50	23-01	23-01	23-01
	HDD153-01	0B/51	23-02	23-02	
	HDD153-02	0B/52	23-03	23-03	23-03
	HDD153-03	0B/53	23-04	23-04	
	HDD153-04	0B/54	23-05	23-05	23-05
	HDD153-05	0B/55	23-06/Spare	23-06/Spare	23-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (93/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-154	HDD154-00	0C/50	24-01	23-01	23-01
	HDD154-01	0C/51	24-02	23-02	
	HDD154-02	0C/52	24-03	23-03	23-03
	HDD154-03	0C/53	24-04	23-04	
	HDD154-04	0C/54	24-05	23-05	23-05
	HDD154-05	0C/55	24-06/Spare	23-06/Spare	23-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (94/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-155	HDD155-00	0D/50	24-01	23-01	23-01
	HDD155-01	0D/51	24-02	23-02	
	HDD155-02	0D/52	24-03	23-03	23-03
	HDD155-03	0D/53	24-04	23-04	
	HDD155-04	0D/54	24-05	23-05	23-05
	HDD155-05	0D/55	24-06/Spare	23-06/Spare	23-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (95/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-156	HDD156-00	0E/50	24-01	23-01	23-01
	HDD156-01	0E/51	24-02	23-02	
	HDD156-02	0E/52	24-03	23-03	23-03
	HDD156-03	0E/53	24-04	23-04	
	HDD156-04	0E/54	24-05	23-05	23-05
	HDD156-05	0E/55	24-06/Spare	23-06/Spare	23-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (96/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-157	HDD157-00	0F/50	24-01	23-01	23-01
	HDD157-01	0F/51	24-02	23-02	
	HDD157-02	0F/52	24-03	23-03	23-03
	HDD157-03	0F/53	24-04	23-04	
	HDD157-04	0F/54	24-05	23-05	23-05
	HDD157-05	0F/55	24-06/Spare	23-06/Spare	23-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (97/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-060	HDD060-00	00/60	25-01	25-01	25-01
	HDD060-01	00/61	25-02	25-02	
	HDD060-02	00/62	25-03	25-03	25-03
	HDD060-03	00/63	25-04	25-04	
	HDD060-04	00/64	25-05	25-05	25-05
	HDD060-05	00/65	25-06/Spare	25-06/Spare	25-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (98/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-061	HDD061-00	01/60	25-01	25-01	25-01
	HDD061-01	01/61	25-02	25-02	
	HDD061-02	01/62	25-03	25-03	25-03
	HDD061-03	01/63	25-04	25-04	
	HDD061-04	01/64	25-05	25-05	25-05
	HDD061-05	01/65	25-06/Spare	25-06/Spare	25-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (99/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-062	HDD062-00	02/60	25-01	25-01	25-01
	HDD062-01	02/61	25-02	25-02	
	HDD062-02	02/62	25-03	25-03	25-03
	HDD062-03	02/63	25-04	25-04	
	HDD062-04	02/64	25-05	25-05	25-05
	HDD062-05	02/65	25-06/Spare	25-06/Spare	25-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (100/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-063	HDD063-00	03/60	25-01	25-01	25-01
	HDD063-01	03/61	25-02	25-02	
	HDD063-02	03/62	25-03	25-03	25-03
	HDD063-03	03/63	25-04	25-04	
	HDD063-04	03/64	25-05	25-05	25-05
	HDD063-05	03/65	25-06/Spare	25-06/Spare	25-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (101/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-064	HDD064-00	04/60	26-01	25-01	25-01
	HDD064-01	04/61	26-02	25-02	
	HDD064-02	04/62	26-03	25-03	25-03
	HDD064-03	04/63	26-04	25-04	
	HDD064-04	04/64	26-05	25-05	25-05
	HDD064-05	04/65	26-06/Spare	25-06/Spare	25-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (102/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-065	HDD065-00	05/60	26-01	25-01	25-01
	HDD065-01	05/61	26-02	25-02	
	HDD065-02	05/62	26-03	25-03	25-03
	HDD065-03	05/63	26-04	25-04	
	HDD065-04	05/64	26-05	25-05	25-05
	HDD065-05	05/65	26-06/Spare	25-06/Spare	25-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (103/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-066	HDD066-00	06/60	26-01	25-01	25-01
	HDD066-01	06/61	26-02	25-02	
	HDD066-02	06/62	26-03	25-03	25-03
	HDD066-03	06/63	26-04	25-04	
	HDD066-04	06/64	26-05	25-05	25-05
	HDD066-05	06/65	26-06/Spare	25-06/Spare	25-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (104/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-067	HDD067-00	07/60	26-01	25-01	25-01
	HDD067-01	07/61	26-02	25-02	
	HDD067-02	07/62	26-03	25-03	25-03
	HDD067-03	07/63	26-04	25-04	
	HDD067-04	07/64	26-05	25-05	25-05
	HDD067-05	07/65	26-06/Spare	25-06/Spare	25-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (105/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-160	HDD160-00	08/60	27-01	27-01	27-01
	HDD160-01	08/61	27-02	27-02	
	HDD160-02	08/62	27-03	27-03	27-03
	HDD160-03	08/63	27-04	27-04	
	HDD160-04	08/64	27-05	27-05	27-05
	HDD160-05	08/65	27-06/Spare	27-06/Spare	27-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (106/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-161	HDD161-00	09/60	27-01	27-01	27-01
	HDD161-01	09/61	27-02	27-02	
	HDD161-02	09/62	27-03	27-03	27-03
	HDD161-03	09/63	27-04	27-04	
	HDD161-04	09/64	27-05	27-05	27-05
	HDD161-05	09/65	27-06/Spare	27-06/Spare	27-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (107/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-162	HDD162-00	0A/60	27-01	27-01	27-01
	HDD162-01	0A/61	27-02	27-02	
	HDD162-02	0A/62	27-03	27-03	27-03
	HDD162-03	0A/63	27-04	27-04	
	HDD162-04	0A/64	27-05	27-05	27-05
	HDD162-05	0A/65	27-06/Spare	27-06/Spare	27-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (108/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-163	HDD163-00	0B/60	27-01	27-01	27-01
	HDD163-01	0B/61	27-02	27-02	
	HDD163-02	0B/62	27-03	27-03	27-03
	HDD163-03	0B/63	27-04	27-04	
	HDD163-04	0B/64	27-05	27-05	27-05
	HDD163-05	0B/65	27-06/Spare	27-06/Spare	27-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(109/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-164	HDD164-00	0C/60	28-01	27-01	27-01
	HDD164-01	0C/61	28-02	27-02	
	HDD164-02	0C/62	28-03	27-03	27-03
	HDD164-03	0C/63	28-04	27-04	
	HDD164-04	0C/64	28-05	27-05	27-05
	HDD164-05	0C/65	28-06/Spare	27-06/Spare	27-05/Spare

**RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU)
(110/128)**

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-165	HDD165-00	0D/60	28-01	27-01	27-01
	HDD165-01	0D/61	28-02	27-02	
	HDD165-02	0D/62	28-03	27-03	27-03
	HDD165-03	0D/63	28-04	27-04	
	HDD165-04	0D/64	28-05	27-05	27-05
	HDD165-05	0D/65	28-06/Spare	27-06/Spare	27-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (111/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-166	HDD166-00	0E/60	28-01	27-01	27-01
	HDD166-01	0E/61	28-02	27-02	
	HDD166-02	0E/62	28-03	27-03	27-03
	HDD166-03	0E/63	28-04	27-04	
	HDD166-04	0E/64	28-05	27-05	27-05
	HDD166-05	0E/65	28-06/Spare	27-06/Spare	27-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (112/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-167	HDD167-00	0F/60	28-01	27-01	27-01
	HDD167-01	0F/61	28-02	27-02	
	HDD167-02	0F/62	28-03	27-03	27-03
	HDD167-03	0F/63	28-04	27-04	
	HDD167-04	0F/64	28-05	27-05	27-05
	HDD167-05	0F/65	28-06/Spare	27-06/Spare	27-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (113/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-070	HDD070-00	00/70	29-01	29-01	29-01
	HDD070-01	00/71	29-02	29-02	
	HDD070-02	00/72	29-03	29-03	29-03
	HDD070-03	00/73	29-04	29-04	
	HDD070-04	00/74	29-05	29-05	29-05
	HDD070-05	00/75	29-06/Spare	29-06/Spare	29-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (114/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-071	HDD071-00	01/70	29-01	29-01	29-01
	HDD071-01	01/71	29-02	29-02	
	HDD071-02	01/72	29-03	29-03	29-03
	HDD071-03	01/73	29-04	29-04	
	HDD071-04	01/74	29-05	29-05	29-05
	HDD071-05	01/75	29-06/Spare	29-06/Spare	29-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (115/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-072	HDD072-00	02/70	29-01	29-01	29-01
	HDD072-01	02/71	29-02	29-02	
	HDD072-02	02/72	29-03	29-03	29-03
	HDD072-03	02/73	29-04	29-04	
	HDD072-04	02/74	29-05	29-05	29-05
	HDD072-05	02/75	29-06/Spare	29-06/Spare	29-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (116/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-073	HDD073-00	03/70	29-01	29-01	29-01
	HDD073-01	03/71	29-02	29-02	
	HDD073-02	03/72	29-03	29-03	29-03
	HDD073-03	03/73	29-04	29-04	
	HDD073-04	03/74	29-05	29-05	29-05
	HDD073-05	03/75	29-06/Spare	29-06/Spare	29-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (117/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-074	HDD074-00	04/70	30-01	29-01	29-01
	HDD074-01	04/71	30-02	29-02	
	HDD074-02	04/72	30-03	29-03	29-03
	HDD074-03	04/73	30-04	29-04	
	HDD074-04	04/74	30-05	29-05	29-05
	HDD074-05	04/75	30-06/Spare	29-06/Spare	29-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (118/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-075	HDD075-00	05/70	30-01	29-01	29-01
	HDD075-01	05/71	30-02	29-02	
	HDD075-02	05/72	30-03	29-03	29-03
	HDD075-03	05/73	30-04	29-04	
	HDD075-04	05/74	30-05	29-05	29-05
	HDD075-05	05/75	30-06/Spare	29-06/Spare	29-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (119/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-076	HDD076-00	06/70	30-01	29-01	29-01
	HDD076-01	06/71	30-02	29-02	
	HDD076-02	06/72	30-03	29-03	29-03
	HDD076-03	06/73	30-04	29-04	
	HDD076-04	06/74	30-05	29-05	29-05
	HDD076-05	06/75	30-06/Spare	29-06/Spare	29-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (120/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-077	HDD077-00	07/70	30-01	29-01	29-01
	HDD077-01	07/71	30-02	29-02	
	HDD077-02	07/72	30-03	29-03	29-03
	HDD077-03	07/73	30-04	29-04	
	HDD077-04	07/74	30-05	29-05	29-05
	HDD077-05	07/75	30-06/Spare	29-06/Spare	29-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (121/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-170	HDD170-00	08/70	31-01	31-01	31-01
	HDD170-01	08/71	31-02	31-02	
	HDD170-02	08/72	31-03	31-03	31-03
	HDD170-03	08/73	31-04	31-04	
	HDD170-04	08/74	31-05	31-05	31-05
	HDD170-05	08/75	31-06/Spare	31-06/Spare	31-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (122/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDU-171	HDD171-00	09/70	31-01	31-01	31-01
	HDD171-01	09/71	31-02	31-02	
	HDD171-02	09/72	31-03	31-03	31-03
	HDD171-03	09/73	31-04	31-04	
	HDD171-04	09/74	31-05	31-05	31-05
	HDD171-05	09/75	31-06/Spare	31-06/Spare	31-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (123/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-172	HDD172-00	0A/70	31-01	31-01	31-01
	HDD172-01	0A/71	31-02	31-02	
	HDD172-02	0A/72	31-03	31-03	31-03
	HDD172-03	0A/73	31-04	31-04	
	HDD172-04	0A/74	31-05	31-05	31-05
	HDD172-05	0A/75	31-06/Spare	31-06/Spare	31-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (124/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-173	HDD173-00	0B/70	31-01	31-01	31-01
	HDD173-01	0B/71	31-02	31-02	
	HDD173-02	0B/72	31-03	31-03	31-03
	HDD173-03	0B/73	31-04	31-04	
	HDD173-04	0B/74	31-05	31-05	31-05
	HDD173-05	0B/75	31-06/Spare	31-06/Spare	31-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (125/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-174	HDD174-00	0C/70	32-01	31-01	31-01
	HDD174-01	0C/71	32-02	31-02	
	HDD174-02	0C/72	32-03	31-03	31-03
	HDD174-03	0C/73	32-04	31-04	
	HDD174-04	0C/74	32-05	31-05	31-05
	HDD174-05	0C/75	32-06/Spare	31-06/Spare	31-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (126/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDDU-175	HDD175-00	0D/70	32-01	31-01	31-01
	HDD175-01	0D/71	32-02	31-02	
	HDD175-02	0D/72	32-03	31-03	31-03
	HDD175-03	0D/73	32-04	31-04	
	HDD175-04	0D/74	32-05	31-05	31-05
	HDD175-05	0D/75	32-06/Spare	31-06/Spare	31-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (127/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-176	HDD176-00	0E/70	32-01	31-01	31-01
	HDD176-01	0E/71	32-02	31-02	
	HDD176-02	0E/72	32-03	31-03	31-03
	HDD176-03	0E/73	32-04	31-04	
	HDD176-04	0E/74	32-05	31-05	31-05
	HDD176-05	0E/75	32-06/Spare	31-06/Spare	31-05/Spare

RELATIONSHIP BETWEEN DISK DRIVE# AND PARITY GROUP# (FBX DKU) (128/128)

HDD BOX Number	Disk Drive Number	C# / R#	Parity Group Number (RAID5 3D+1P) (RAID1 2D+2D)	Parity Group Number (RAID5 7D+1P) (RAID6 6D+2P)	Parity Group Number (RAID6 14D+2P)
HDD-177	HDD177-00	0F/70	32-01	31-01	31-01
	HDD177-01	0F/71	32-02	31-02	
	HDD177-02	0F/72	32-03	31-03	31-03
	HDD177-03	0F/73	32-04	31-04	
	HDD177-04	0F/74	32-05	31-05	31-05
	HDD177-05	0F/75	32-06/Spare	31-06/Spare	31-05/Spare