

# ***REPLACEMENT SECTION***

## Contents

|                                                                         |                  |
|-------------------------------------------------------------------------|------------------|
| DRIVE REPLACEMENT PROCESSING - RDK1 .....                               | (REP(RDK1)00-00) |
| Controller Board REPLACEMENT PROCESSING - RCTL .....                    | (REP(RCTL)00-00) |
| Cache Memory REPLACEMENT PROCESSING - RCM1 .....                        | (REP(RCM1)00-00) |
| BKMF REPLACEMENT PROCESSING - RBKM .....                                | (REP(RBKM)00-00) |
| Battery REPLACEMENT PROCESSING - RBTR .....                             | (REP(RBTR)00-00) |
| Cache Flash Memory (CFM) REPLACEMENT PROCESSING - RCFM .....            | (REP(RCFM)00-00) |
| LAN Board REPLACEMENT PROCESSING - RLAB .....                           | (REP(RLAB)00-00) |
| Channel Board (CHB) REPLACEMENT PROCESSING - RCHB .....                 | (REP(RCHB)00-00) |
| SFP REPLACEMENT PROCESSING - RSFP .....                                 | (REP(RSFP)00-00) |
| DKB REPLACEMENT PROCESSING - RDKB .....                                 | (REP(RDKB)00-00) |
| PSU REPLACEMENT PROCESSING - RPSU .....                                 | (REP(RPSU)00-00) |
| ENC REPLACEMENT PROCESSING - RENC .....                                 | (REP(RENC)00-00) |
| BOX REPLACEMENT PROCESSING - HBOX .....                                 | (REP(HBOX)00-00) |
| Bezel REPLACEMENT PROCESSING - HBZL .....                               | (REP(HBZL)00-00) |
| PDU REPLACEMENT PROCESSING - HPDU .....                                 | (REP(HPDU)00-00) |
| SAS/NVMe Cables REPLACEMENT PROCESSING - RSC1 .....                     | (REP(RSC1)00-00) |
| SVP REPLACEMENT PROCESSING - RSVP .....                                 | (REP(RSVP)00-00) |
| HSNPANEL REPLACEMENT PROCESSING - RPNL .....                            | (REP(RPNL)00-00) |
| SSVP REPLACEMENT PROCESSING - RSSV .....                                | (REP(RSSV)00-00) |
| ISW REPLACEMENT PROCESSING - RISW .....                                 | (REP(RISW)00-00) |
| HSNBX REPLACEMENT PROCESSING - HSNB .....                               | (REP(HSNB)00-00) |
| HIE REPLACEMENT PROCESSING - RHIE .....                                 | (REP(RHIE)00-00) |
| ISWFAN REPLACEMENT PROCESSING - RFNI .....                              | (REP(RFNI)00-00) |
| ISWPS REPLACEMENT PROCESSING - RIPS .....                               | (REP(RIPS)00-00) |
| X-path cable REPLACEMENT PROCESSING - RXPC .....                        | (REP(RXPC)00-00) |
| X-path related parts REPLACEMENT PROCESSING (Restore) - RXRS .....      | (REP(RXRS)00-00) |
| X-path related parts REPLACEMENT PROCESSING (Skip Restore) - RXSR ..... | (REP(RXSR)00-00) |
| LAN cable REPLACEMENT PROCESSING - RLAN .....                           | (REP(RLAN)00-00) |